




RKB133030

Reference:A0001-001001


Page:A0001-001001

PW98MR-11E0 (ITA) S/N F40001-UP
ENGINE ASSEMBLY

Index	Code	Part Number	Description	Qty	Serial No.
1		6401-B0-RA10	ENGINE, ASSEMBLY	1	F40001-


Reference:A0001-001001

Page:A0001-001001




PW98MR-11E0 (ITA) S/N F40001-UP
EXHAUST MUFFLER

Index	Code	Part Number	Description	Qty	Serial No.
1		22P-01-32211	PIPE	1	F40001-
2		01010-D1225	BOLT	3	F40001-
3		11Y-54-11370	WASHER	3	F40001-



PW98MR-11E0 (ITA) S/N F40001-UP
ENGINE MOUNTING

Index	Code	Part Number	Description	Qty	Serial No.
1		113-01-21120	WASHER	3	F40001-
2		22P-01-31980	CUSHION	8	F40001-
3		01011-81625	BOLT	4	F40001-
4		22P-01-31870	STOPPER	1	F40001-
5		01643-31645	WASHER	1	F40001-



JY106479

Reference:B0200-001001


Page:B0200-001001

PW98MR-11E0 (ITA) S/N F40001-UP
AIR CLEANER

Index	Code	Part Number	Description	Qty	Serial No.
1	C1	6401-81-7100	AIR CLEANER	1	F40001-
2		600-184-1160	• BODY	1	F40001-
3		600-184-1350	• COVER, ASSEMBLY	1	F40001-
4		600-185-2200	• • VALVE	1	F40001-
5		600-185-2210	• ELEMENT, ASSEMBLY	1	F40001-
6		600-185-2230	• • ELEMENT, OUTER	1	F40001-
7		561-02-12420	• • ELEMENT, INNER	1	F40001-
8		600-181-1920	• • O-RING	1	F40001-
			• CAP	1	F40001-
			• PLATE, AIR FILTER	1	F40001-
			[C1]-This part cannot be supplied as an individual part. It is supplied as an assembly.		

Reference:B0200-001001

Page:B0200-001001



JA106866

Reference: B0200-001002


Page: B0200-001002

PW98MR-11E0 (ITA) S/N F40001-UP
AIR CLEANER, AIR CLEANER RELATED PARTS

Index	Code	Part Number	Description	Qty	Serial No.
1		01010-80820	BOLT	2	F40001-
2		01643-30823	WASHER	2	F40001-
3		22P-01-31211	BRACKET	1	F40001-
4		7861-93-1430	SENSOR, SWITCH	1	F40001-
5		6252-81-7800	SENSOR, AIRFLOW	1	F40001-
6		01252-B0410	BOLT	2	F40001-
7		01640-20408	WASHER	2	F40001-
8		6156-81-8990	NIPPLE	1	F40001-
9		07005-01012	SEAL, WASHER	2	F40001-
10		07206-30710	JOINT	1	F40001-
11		6206-71-1770	JOINT	1	F40001-
12		22P-01-31260	HOSE, ASSEMBLY	1	F40001-
13		07285-00125	CLAMP	2	F40001-
14		6131-81-8820	NIPPLE	1	F40001-
15		08211-00720	CLIP	1	F40001-
16		04434-51410	CLAMP	1	F40001-
17		01010-81025	BOLT	1	F40001-
18		01643-31032	WASHER	1	F40001-
19		07289-00080	CLAMP	1	F40001-
20		01010-81025	BOLT	2	F40001-
21		01643-31032	WASHER	2	F40001-
22		22P-01-31390	HOSE	1	F40001-
23		07289-00080	CLAMP	1	F40001-

Reference: B0200-001002

Page: B0200-001002



RKB133020

Reference: B0600-001001


Page: B0600-001001

PW98MR-11E0 (ITA) S/N F40001-UP
DUMPER

Index	Code	Part Number	Description	Qty	Serial No.
1		21D-01-51110	COUPLING	1	F40001-
2		01010-81045	BOLT	8	F40001-
3		01643-31032	WASHER	8	F40001-
4		21D-01-51120	FLANGE	1	F40001-
5		01010-81075	BOLT	12	F40001-
6		01643-31032	WASHER	12	F40001-
7		22L-09-R3980	PLUG	1	F40001-
8		07002-11423	* O-RING	1	F40001-
9		21D-01-51130	TUBE	1	F40001-
10		07260-20928	HOSE	1	F40001-
11		07285-00150	CLIP, HOSE	1	F40001-
12		01010-81025	BOLT	1	F40001-
13		01643-31032	WASHER	1	F40001-
14		21D-01-51160	BRACKET	1	F40001-
15		01010-81025	BOLT	2	F40001-
16		01643-31032	WASHER	2	F40001-
17		21D-01-51141	BRACKET	1	F40001-
18		01010-81025	BOLT	2	F40001-
19		01643-31032	WASHER	2	F40001-
20		07286-01658	HOSE	1	F40001-
21		07285-00180	CLIP	1	F40001-
22		04434-52110	CLIP	1	F40001-
23		01010-81025	BOLT	1	F40001-
24		01643-31032	WASHER	1	F40001-
25		227-01-11150	ELBOW	1	F40001-
26		07030-00252	VALVE	1	F40001-
27		21D-01-51150	SHEET	1	F40001-
28		203-54-56960	COLLAR	2	F40001-
29		01010-81030	BOLT	2	F40001-
30		01643-31032	WASHER	2	F40001-

Reference: B0600-001001

Page: B0600-001001



Reference: C0100-001001

Page: C0100-001001

PW98MR-11E0 (ITA) S/N F40001-UP
COOLING SYSTEM, RADIATOR, AFTERCOOLER AND OIL COOLER


Index	Code	Part Number	Description	Qty	Serial No.
1		22P-03-31141	FRAME	1	F40001-
2		22B-03-12590	CUSHION	3	F40001-
3		20Y-03-41580	CUSHION	2	F40001-
4		22P-03-31151	BRACKET	1	F40001-
5		01010-81025	BOLT	2	F40001-
6		01643-31032	WASHER	2	F40001-
		22P-03-32521	RADIATOR, ASSEMBLY	1	F40001-
7		22P-03-31631	• SHEET	4	F40001-
8		22P-03-31750	• SHEET	1	F40001-
9		22P-03-31760	• SHEET	1	F40001-
10		22P-03-31850	• SHEET	2	F40001-
11		22P-03-32130	• SHEET	1	F40001-
12	C1		• RADIATOR	1	F40001-
13		2A4-03-21790	• SHEET	1	F40001-
14		2A4-03-21830	• SHEET	1	F40001-
15		01010-81025	BOLT	2	F40001-
16		01643-31032	WASHER	2	F40001-
17		203-03-71360	CUSHION	4	F40001-
18		203-03-71370	COLLAR	2	F40001-
19		415-64-13120	WASHER	2	F40001-
20		01010-81035	BOLT	2	F40001-
21		22P-03-31691	BRACKET	1	F40001-
		22P-03-32542	AFTERCOOLER, ASSEMBLY	1	F40001-
22		22P-03-31641	• SHEET	2	F40001-
23		22P-03-31721	• SHEET	1	F40001-
24		22P-03-31731	• SHEET	1	F40001-
25		22P-03-31781	• SHEET	1	F40001-
26		22P-03-31811	• SHEET	1	F40001-
27		22P-03-31871	• SHEET	1	F40001-
28	C1		• AFTERCOOLER	1	F40001-
29		2A4-03-22440	• SHEET	1	F40001-

Reference: C0100-001001

Page: C0100-001001

PW98MR-11E0 (ITA) S/N F40001-UP
COOLING SYSTEM, RADIATOR, AFTERCOOLER AND OIL COOLER


Index	Code	Part Number	Description	Qty	Serial No.
30	C1	2A4-03-22450	• SHEET	1	F40001-
31		01010-D1040	BOLT	1	F40001-
32		22P-03-31130	COLLAR	1	F40001-
33		201-03-81191	SPACER	1	F40001-
34		201-03-81221	CUSHION	2	F40001-
35		201-03-81650	WASHER	1	F40001-
		21W-03-61131	OIL COOLER, ASSEMBLY	1	F40001-
36			• OIL COOLER, ASSEMBLY	1	F40001-
37		21W-03-61880	• SHEET	4	F40001-
38		22P-03-11880	• SHEET	2	F40001-
39		21W-03-61820	• SHEET	1	F40001-
40		21W-03-61831	• SHEET	1	F40001-
41		01010-81025	BOLT	2	F40001-
42		203-54-56970	WASHER	2	F40001-
43		21U-03-31370	BOSS	1	F40001-
44		01010-D1020	BOLT	2	F40001-
45		01643-71032	WASHER	2	F40001-
46		22P-03-31410	HOSE	1	F40001-
47		07285-00125	CLAMP	2	F40001-
48		01010-81025	BOLT	2	F40001-
49		01643-31032	WASHER	2	F40001-
50		04434-51310	CLIP	2	F40001-
51		20Y-03-21981	PLUG	1	F40001-
		07000-11007	• O-RING	1	F40001-
52		22P-03-11410	HOSE	1	F40001-
53		20Y-03-11330	CLIP	1	F40001-
54		01164-51030	STUD	2	F40001-
55		07040-11409	PLUG	1	F40001-
56		07002-11423	O-RING	1	F40001-
		22P-03-32751	BRACKET, ASSEMBLY	1	F40001-
57		22P-03-31512	• BRACKET	1	F40001-
58		22P-03-32690	• SHEET	1	F40001-
59		01010-80820	BOLT	2	F40001-
60		01643-30823	WASHER	2	F40001-
61		22P-03-31561	BRACKET	1	F40001-
62		21W-03-61240	SHEET	1	F40001-
63		22P-03-21620	SHEET	1	F40001-
64		01010-81025	BOLT	2	F40001-
65		01643-31032	WASHER	2	F40001-
			[C1]-This part cannot be supplied as an individual part. It is supplied as an assembly.		



JA106875

PW98MR-11E0 (ITA) S/N F40001-UP
COOLING SYSTEM, FUEL COOLER

Index	Code	Part Number	Description	Qty	Serial No.
1		208-03-71161	OIL COOLER	1	F40001-
2		01010-80820	BOLT	4	F40001-
3		01643-30823	WASHER	4	F40001-
4		02782-10315	ELBOW	2	F40001-
5		07002-62034	O-RING	2	F40001-
6		02896-61009	O-RING	2	F40001-



JA108094

Reference: C0100-001003

Page: C0100-001003

PW98MR-11E0 (ITA) S/N F40001-UP
COOLING SYSTEM, NET AND SHROUD

Index	Code	Part Number	Description	Qty	Serial No.
1	C1	22P-03-31581	NET, ASSEMBLY	1	F40001-
2		22P-03-32760	• NET	1	F40001-
3		22B-46-24180	• SHEET	1	F40001-
4		01023-10408	SPRING	1	F40001-
5		01023-10408	SCREW	2	F40001-
6		22P-03-31161	SHROUD	1	F40001-
7		01010-80820	BOLT	7	F40001-
8		01643-30823	WASHER	7	F40001-
9		22P-03-31171	PLATE	1	F40001-
10		01010-80816	BOLT	2	F40001-
11		01643-30823	WASHER	2	F40001-
12		22P-03-31181	PLATE	1	F40001-
13		01010-80816	BOLT	2	F40001-
14		01643-30823	WASHER	2	F40001-
15		22P-03-31590	BRACKET	1	F40001-
16		01010-80820	BOLT	2	F40001-
17		01643-30823	WASHER	2	F40001-
18		2A5-979-1282	CONDENSER, ASSEMBLY	1	F40001-
19		20Y-810-1251	• FILTER	1	F40001-
20		01010-80835	BOLT	4	F40001-
21		01643-30823	WASHER	4	F40001-
22		20Y-810-1240	CUSHION	4	F40001-
23		22P-979-3251	BRACKET	1	F40001-
24		198-06-62820	• HINGE	2	F40001-
25	C1	01010-81020	BOLT	2	F40001-
26		01643-31032	WASHER	2	F40001-
27		22P-03-32611	BRACKET, ASSEMBLY	1	F40001-
28		22P-03-32551	• SHEET	1	F40001-
			• BRACKET	1	F40001-
		01010-80820	BOLT	2	F40001-
		01643-30823	WASHER	2	F40001-

Reference: C0100-001003

Page: C0100-001003

Get the complete PDF catalogue

Komatsu PW98MR-11E0 (ITA) S/N F40001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 selected catalogue pages.