




RKB132070

Reference:A0000-001001


Page:A0000-001001

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, ENGINE ASSEMBLY

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-01-55100	ENGINE, ASSEMBLY	1	F20001-

Reference:A0000-001001

Page:A0000-001001



JY103832

Reference:A0000-001002


Page:A0000-001002

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, BRACKET

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-01-25213	BRACKET	1	F20001-
2		22J-01-25223	BRACKET	1	F20001-
3		22J-01-25340	BOLT	6	F20001-
4		01643-31032	WASHER	6	F20001-
5		07270-01217	TUBE	1	F20001-
6		07285-00130	CLAMP	1	F20001-

Reference:A0000-001002

Page:A0000-001002



RKB145460

Reference:A0000-001003


Page:A0000-001003

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, EXHAUST MUFFLER RELATED PARTS

Index	Code	Part Number	Description	Qty	Serial No.
1		203-54-56960	COLLAR	2	F20001-
2		22J-01-25280	PIPE, EXHAUST	1	F20001-
3		22J-01-25310	SLEEVE	1	F20001-
4		22J-01-R5321	SHEET	1	F20001-
5		22J-01-R5331	SHEET	1	F20001-
6		22J-01-55410	BRACKET	1	F20001-
7		22J-01-55420	SHEET	1	F20001-
8		22J-01-25262	BRACKET	1	F20001-
9		07289-00035	CLAMP	1	F20001-
10		22L-01-21440	CLAMP	8	F20001-
11		01010-80816	BOLT	2	F20001-
12		01643-30823	WASHER	2	F20001-
13		01010-81020	BOLT	4	F20001-
14		01643-31032	WASHER	4	F20001-
15		01010-81025	BOLT	2	F20001-
16		01643-31032	WASHER	2	F20001-
17		01597-01009	NUT	2	F20001-
18		01643-31032	WASHER	2	F20001-
19		07283-33450	CLIP	1	F20001-
20		07283-53444	SEAT	1	F20001-

Reference:A0000-001003

Page:A0000-001003



JY105679

Reference:A0000-001004


Page:A0000-001004

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, AIR CLEANER RELATED PARTS

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-01-55310	HOSE	1	F20001-
2		22J-01-55330	HOSE	1	F20001-
3		07289-00055	CLAMP	2	F20001-
4		07281-00549	CLAMP	1	F20001-

Reference:A0000-001004

Page:A0000-001004



JY103838

Reference:A0000-001005


Page:A0000-001005

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, DAMPER

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-01-25231	COVER	1	F20001-
		22L-01-21700	POWER TAKE OFF, ASSEMBLY	1	F20001-
2		22L-01-21710	• RUBBER	1	F20001-
3		22L-01-21720	• BOSS	1	F20001-
4		04025-00512	• PIN, SPRING	6	F20001-
5		01252-71240	• BOLT, HEXAGON SOCKET HEAD	3	F20001-
6		01010-80825	BOLT	6	F20001-
7		01643-30823	WASHER	6	F20001-
8		01010-80835	BOLT	1	F20001-
9		01643-30823	WASHER	1	F20001-
10		01124-50835	STUD	1	F20001-
11		01252-31240	BOLT, HEXAGON SOCKET HEAD	3	F20001-
12		01580-10806	NUT	1	F20001-
13		01640-20816	WASHER	1	F20001-
14		04020-00820	PIN, DOWEL	1	F20001-

Reference:A0000-001005

Page:A0000-001005



JY105762

Reference:A0000-001006


Page:A0000-001006

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, BATTERY CABLE

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-06-55610	CABLE	1	F20001-
2		01010-80816	BOLT	1	F20001-
3		01643-30823	WASHER	1	F20001-
4		01580-10806	NUT	1	F20001-
5		01643-30823	WASHER	1	F20001-
6		04434-51910	CLAMP	1	F20001-
7		07095-20213	GROMMET	1	F20001-
8		08038-04030	CAP	1	F20001-

Reference:A0000-001006

Page:A0000-001006



JY105763

Reference:A0000-001007


Page:A0000-001007

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, WIRING HARNESS

Index	Code	Part Number	Description	Qty	Serial No.
1		22J-06-56180	WIRING HARNESS, ALTERNATOR	1	F20001-
2		22J-06-35540	BRACKET	1	F20001-
3		7861-93-3320	TEMPERATURE SENSOR	1	F20001-
4		22J-06-55310	CABLE	1	F20001-
5		7875-12-2650	COLLAR	1	F20001-
6		01010-80835	BOLT	1	F20001-
7		01643-30823	WASHER	1	F20001-
8		08193-20010	CLIP	1	F20001-
9		01010-80816	BOLT	1	F20001-
10		01643-30823	WASHER	1	F20001-
11		01580-10605	NUT	1	F20001-
12		01640-20610	WASHER	1	F20001-
13		08034-40521	BAND	1	F20001-
14		08038-10519	CAP	1	F20001-

Reference:A0000-001007

Page:A0000-001007



RKB156150

Reference:A0000-001008

Page:A0000-001008


PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, PLUG AND HOSE

Index	Code	Part Number	Description	Qty	Serial No.
1		423-62-R2290	PLUG	3	F20001-
2		07002-11023	• O-RING	1	F20001-
3		20C-62-32121	TUBE	1	F20001-

Reference:A0000-001008

Page:A0000-001008

JY103820



JY103820

Reference:A0000-001009


Page:A0000-001009

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, INNER PARTS, LS VALVE

Index	Code	Part Number	Description	Qty	Serial No.
	C2	22J-60-55300 (708-1S-03850)	PUMP, ASSEMBLY	1	F20001-
	C1		• VALVE ASSEMBLY, LS	1	F20001-
1	C1		• • PISTON	1	F20001-
2	C1		• • SLEEVE	1	F20001-
3	C1		• • SPOOL	1	F20001-
4	C1		• • SEAT	1	F20001-
5	C1		• • SPRING	1	F20001-
6	C1		• • SEAT	1	F20001-
7	C1		• • PLUG	1	F20001-
8	C1		• • O-RING	1	F20001-
9	C1		• • RING, BACK-UP	1	F20001-
10	C1		• • NUT	1	F20001-
11		07002-62034	• • O-RING	1	F20001-
12		708-2L-35690	• • SEAL	1	F20001-
13		02896-61008	• • O-RING	1	F20001-
14		02789-00210	• • PLUG	1	F20001-
[C1]-This part cannot be supplied as an individual part. It is supplied as an assembly.					
[C2]-This part is supplied for authorized Komatsu distributors only. It cannot be supplied as an individual part. It is supplied as an assembly.					

Reference:A0000-001009

Page:A0000-001009



JY103864

Reference:A0000-001010

Page:A0000-001010

PC18MR-5 (ITA) S/N F20001-UP
ENGINE RELATED PARTS, INNER PARTS, GEAR PUMP

Index	Code	Part Number	Description	Qty	Serial No.
		22J-60-55300	PUMP, ASSEMBLY	1	F20001-
		705-49-01140	• GEAR PUMP, ASSEMBLY	1	F20001-
1	C2	(705-49-82011)	• • BRACKET, ASSEMBLY	1	F20001-
	C2	(705-48-80612)	• • • BUSHING, PLANE	2	F20001-
2	C2	(705-48-80710)	• • PLATE	2	F20001-
3	C2	(705-48-80730)	• • SEAL	2	F20001-
4	C2	(705-48-80630)	• • O-RING	1	F20001-
5		705-48-80750	• • BOLT	4	F20001-
6		01643-50823	• • WASHER	4	F20001-
7	C2	(705-48-48111)	• • HOUSING, ASSEMBLY	1	F20001-
	C2	(705-48-80612)	• • • BUSHING, PLANE	2	F20001-
8	C2	(04020-00514)	• • PIN, DOWEL	2	F20001-
9	C2	(705-48-48611)	• • GEAR	1	F20001-
10	C2	(705-48-48510)	• • GEAR	1	F20001-
[C2]-This part is supplied for authorized Komatsu distributors only. It cannot be supplied as an individual part. It is supplied as an assembly.					

Reference:A0000-001010

Page:A0000-001010

Get the complete PDF catalogue

Komatsu PC18MR-5 (ITA) S/N F20001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 selected catalogue pages.