





Reference: 1001

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	22T-01-12160	BRACKET	2	SN: 10001-UP
2	01010-31265	BOLT	8	SN: 10001-UP
3	01643-31232	WASHER	8	SN: 10001-UP
4	22T-01-12110	BRACKET	2	SN: 10001-UP
5	01010-31035	BOLT	8	SN: 10001-UP
6	01643-31032	WASHER	8	SN: 10001-UP
7	04020-01228	PIN	4	SN: 10001-UP
8	22T-15-12130	CUSHION	8	SN: 10001-UP
9	22T-01-12140	PLATE	4	SN: 10001-UP
10	01010-31695	BOLT	4	SN: 10001-UP
11	01643-31645	WASHER	4	SN: 10001-UP
12	22T-01-11510	COVER	1	SN: 10001-UP
13	01010-51020	BOLT	4	SN: 10001-UP
14	01643-31032	WASHER	4	SN: 10001-UP

Reference: 1001




Reference: 1021

030020 AIR CLEANER CONNECTION

Item	Part No.	Part Name	Qty	Options
1	08670-02001	INJECTOR	1	SN: 10001-UP
2	22T-02-11120	HOSE	1	SN: 10001-UP
3	22T-02-11130	TUBE	1	SN: 10001-UP
4	22T-02-11140	HOSE	1	SN: 10001-UP
5	07281-01159	CLAMP	1	SN: 10001-UP
6	07281-00809	CLAMP	3	SN: 10001-UP
7	22T-02-11150	BRACKET	1	SN: 10001-UP
8	01010-51025	BOLT	1	SN: 10001-UP
9	01643-31032	WASHER	1	SN: 10001-UP
10	07283-26155	CLIP	1	SN: 10001-UP
11	01599-01011	NAT	2	SN: 10001-UP
12	01643-31032	WASHER	2	SN: 10001-UP

Reference: 1021




Reference: 1041

030030 EXHAUST CONNECTION

Item	Part No.	Part Name	Qty	Options
1	22T-02-12110	TUBE	1	SN: 10001-UP
2	22T-02-12120	CLAMP	1	SN: 10001-UP
3	01435-01230	BOLT	2	SN: 10001-UP
4	01584-01210	NAT	2	SN: 10001-UP
5	22T-02-12140	TUBE	1	SN: 10001-UP
6	22W-02-11180	COUPLING	1	SN: 10001-UP
7	22T-02-12620	GASKET	2	SN: 10001-UP
8	22T-02-12180	COVER	1	SN: 10001-UP
9	22T-02-12221	BRACKET	1	SN: 10001-UP
10	22T-02-12231	BRACKET	1	SN: 10001-UP
11	01010-51020	BOLT	6	SN: 10001-UP
12	01643-31032	WASHER	6	SN: 10001-UP
13	22T-02-12211	COVER	1	SN: 10001-UP
14	01010-51020	BOLT	4	SN: 10001-UP
15	01643-31032	WASHER	4	SN: 10001-UP
16	22T-02-12310	PAD	1	SN: 10001-UP
17	22T-02-12320	PAD	1	SN: 10001-UP
18	22T-02-12330	PAD	1	SN: 10001-UP
19	04431-30000	PLATE	1	SN: 10001-UP
20	22T-02-12240	COVER	1	SN: 10001-UP
21	01010-51020	BOLT	3	SN: 10001-UP
22	01643-31032	WASHER	3	SN: 10001-UP
23	22T-02-12251	COVER	1	SN: 10001-UP
24	01010-51020	BOLT	2	SN: 10001-UP
25	01643-31032	WASHER	2	SN: 10001-UP
26	22T-02-12170	TUBE	1	SN: 10001-UP
27	01010-51020	BOLT	1	SN: 10001-UP
28	01643-31032	WASHER	1	SN: 10001-UP

Reference: 1041




Reference: 1101

030040 ACCELERATOR PEDAL

Item	Part No.	Part Name	Qty	Options
	22T-43-17100	PEDAL ASSEMBLY	1	SN: 10001-UP
1	22T-43-17110	• PEDAL	1	SN: 10001-UP
2	22T-42-11220	•• BUSH	2	SN: 10001-UP
3	22T-43-17190	•• PAD	1	SN: 10001-UP
4	22T-42-11230	•• STOP	2	SN: 10001-UP
5	22T-43-17120	• BRACKET	1	SN: 10001-UP
6	22T-42-11150	• COLLAR	1	SN: 10001-UP
7	22T-42-11130	• BOLT	1	SN: 10001-UP
8	22T-43-14320	• NAT	1	SN: 10001-UP
9	22T-43-17220	• SPRING	1	SN: 10001-UP
10	01016-50830	• BOLT	1	SN: 10001-UP
11	01580-10806	• NAT	1	SN: 10001-UP
12	22T-05-19310	• SWITCH	1	SN: 10001-UP
13	01010-51020	BOLT	2	SN: 10001-UP
14	01643-31032	WASHER	2	SN: 10001-UP
15	04205-10825	PIN	1	SN: 10001-UP
16	04050-12015	PIN, COTTER	1	SN: 10001-UP
17	22T-43-14200	MASTER CYLINDER ASSEMBLY	1	SN: 10001-UP
18	01435-00825	BOLT	2	SN: 10001-UP
19	01580-10806	NAT	2	SN: 10001-UP
20	22T-43-17180	HOSE	1	SN: 10001-UP
21	07235-10210	ERBO	1	SN: 10001-UP
22	07230-20210	UNION	1	SN: 10001-UP
23	07002-01423	O RING	2	SN: 10001-UP
24	07260-20956	HOSE	1	SN: 10001-UP
25	07281-00197	CLAMP	2	SN: 10001-UP
26	04434-51410	CLIP	4	SN: 10001-UP
27	04434-51610	CLIP	1	SN: 10001-UP
28	01435-01016	BOLT	3	SN: 10001-UP
29	22T-43-17140	CABLE	1	SN: 10001-UP
30	22T-43-17160	YOKE	1	SN: 10001-UP
31	01580-10605	NAT	1	SN: 10001-UP
32	04205-10620	PIN	1	SN: 10001-UP
33	01641-20608	WASHER	1	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
34	04052-10633	PIN, SNAP	1	SN: 10001-UP
35	22T-43-17150	BRACKET	1	SN: 10001-UP
36	01435-01016	BOLT	2	SN: 10001-UP
37	22T-43-17170	PLATE	1	SN: 10001-UP
38	01010-51016	BOLT	2	SN: 10001-UP
39	01643-31032	WASHER	2	SN: 10001-UP
40	22T-42-11240	CUSHION	1	SN: 10001-UP
41	01580-10806	NAT	1	SN: 10001-UP
42	201-43-28440	GROMMET	1	SN: 10001-UP

Reference: 1101




Reference: 1111

030050 ENGINE CONTROL LINKAGE

Item	Part No.	Part Name	Qty	Options
1	22T-43-18410	BRACKET	1	SN: 10001-UP
2	01010-51040	BOLT	2	SN: 10001-UP
3	01010-51025	BOLT	4	SN: 10001-UP
4	01643-31032	WASHER	6	SN: 10001-UP
5	22T-43-18310	LEVER	1	SN: 10001-UP
6	363-43-27260	BEARING	1	SN: 10001-UP
7	22T-43-18320	SHAFT	1	SN: 10001-UP
8	01580-10806	NAT	1	SN: 10001-UP
9	01643-30823	WASHER	1	SN: 10001-UP
10	01643-31445	WASHER	1	SN: 10001-UP
	22T-43-18200	ABSORBER ASSEMBLY	1	SN: 10001-UP
11	22T-43-18220	• BODY	1	SN: 10001-UP
12	22T-43-18210	• ROD	1	SN: 10001-UP
13	22T-43-18230	• GUIDE	1	SN: 10001-UP
14	417-15-15820	• SPRING	1	SN: 10001-UP
15	04205-10822	PIN	1	SN: 10001-UP
16	04050-12015	PIN, COTTER	1	SN: 10001-UP
17	22T-43-18101	MASTER CYLINDER ASSEMBLY	1	SN: 10001-UP
17	22T-43-18111	• SERVICE KIT	1	SN: 10001-UP
18	01580-10806	NAT	1	SN: 10001-UP
19	01435-00825	BOLT	2	SN: 10001-UP
20	04245-40612	ROD	1	SN: 10001-UP
21	424-09-12450	JOINT	3	SN: 10001-UP
22	01580-10605	NAT	6	SN: 10001-UP
23	01643-30623	WASHER	3	SN: 10001-UP
24	22T-43-18350	LEVER	1	SN: 10001-UP
25	22T-43-18380	SHAFT	1	SN: 10001-UP
26	363-43-27260	BEARING	1	SN: 10001-UP
27	01580-10605	NAT	1	SN: 10001-UP
28	01643-30623	WASHER	1	SN: 10001-UP
29	22T-43-18370	CONNECTOR	1	SN: 10001-UP
30	363-43-31170	SPRING	1	SN: 10001-UP
31	22T-43-18450	PLATE	1	SN: 10001-UP
32	01435-01035	BOLT	2	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
33	424-64-11110	SPACER	2	SN: 10001-UP
34	04434-50810	CLIP	3	SN: 10001-UP
35	419-54-11270	SPACER	2	SN: 10001-UP
36	419-62-13390	SPACER	1	SN: 10001-UP
37	01580-11008	NAT	3	SN: 10001-UP
38	01643-31032	WASHER	3	SN: 10001-UP

Reference: 1111




Reference: 1201

030060 RADIATOR AND PIPING

Item	Part No.	Part Name	Qty	Options
	22T-03-11300	RADIATOR ASSEMBLY	1	SN: 10001-UP
1	22T-03-11310	• CORE ASSEMBLY	1	SN: 10001-UP
2	22T-03-11320	• SHROUD	1	SN: 10001-UP
3	416-03-11131	• PACKING	2	SN: 10001-UP
4	416-03-11170	• CAP	1	SN: 10001-UP
5	22T-03-11220	• HOSE	1	SN: 10001-UP
6	415-03-11150	• COCK, DRAIN	1	SN: 10001-UP
7	01435-20816	• BOLT	7	SN: 10001-UP
8	22T-03-11330	GUARD, FAN	1	SN: 10001-UP
9	01010-51025	BOLT	4	SN: 10001-UP
10	01643-31032	WASHER	4	SN: 10001-UP
11	22T-03-12210	PLATE	1	SN: 10001-UP
12	22T-03-12240	PLATE	1	SN: 10001-UP
13	416-03-11270	SPACER	2	SN: 10001-UP
14	416-03-11250	CUSHION	2	SN: 10001-UP
15	416-03-11260	CUSHION	4	SN: 10001-UP
16	01010-51245	BOLT	2	SN: 10001-UP
17	419-43-17920	WASHER	4	SN: 10001-UP
18	416-03-11282	BOLT	2	SN: 10001-UP
19	01580-11210	NAT	2	SN: 10001-UP
20	01643-31232	WASHER	4	SN: 10001-UP
21	416-03-11221	CUSHION	4	SN: 10001-UP
22	416-03-11210	WASHER	4	SN: 10001-UP
23	415-03-11210	SPACER	2	SN: 10001-UP
24	01010-51260	BOLT	2	SN: 10001-UP
25	22T-03-12230	TANK, RESERVOIR	1	SN: 10001-UP
26	22T-03-12220	BRACKET	1	SN: 10001-UP
27	01010-51020	BOLT	2	SN: 10001-UP
28	01643-31032	WASHER	2	SN: 10001-UP
29	01010-50830	BOLT	1	SN: 10001-UP
30	01643-30823	WASHER	1	SN: 10001-UP
31	22T-03-12140	HOSE	1	SN: 10001-UP
32	07281-00137	CLAMP	2	SN: 10001-UP
33	08036-10814	CLIP	2	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
34	08034-20519	BAND	3	SN: 10001-UP
35	22T-03-12110	HOSE	1	SN: 10001-UP
36	07281-00609	CLAMP	2	SN: 10001-UP
37	22T-03-12120	HOSE	1	SN: 10001-UP
38	22T-03-12150	TUBE	1	SN: 10001-UP
39	01435-01016	BOLT	2	SN: 10001-UP
40	22T-03-12130	HOSE	1	SN: 10001-UP
41	07281-00609	CLAMP	4	SN: 10001-UP
42	22T-54-18250	SEAT	2	SN: 10001-UP

Reference: 1201



Reference: 1301

030070 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
1	22T-04-11101	FUEL TANK	1	SN: 10001-UP
2	23S-04-21190	• CAP, (WITH KEY)	1	SN: 10001-UP
3	23S-04-21130	• STRAINER	1	SN: 10001-UP
4	23S-04-21140	• PACKING	1	SN: 10001-UP
5	23S-04-21150	• PLUG	1	SN: 10001-UP
6	23S-04-21160	• PACKING	1	SN: 10001-UP
7	22T-04-11320	• PLUG	1	SN: 10001-UP
8	23S-04-21180	• PACKING	1	SN: 10001-UP
9	23S-04-21110	FLOAT	1	SN: 10001-UP
10	22T-04-11210	STEERING ASSEMBLY	2	SN: 10001-UP
11	01010-51020	BOLT	8	SN: 10001-UP
12	01643-31032	WASHER	8	SN: 10001-UP
13	22T-04-11220	BAND	2	SN: 10001-UP
14	01583-11207	• NAT	2	SN: 10001-UP
15	01643-31232	• WASHER	1	SN: 10001-UP
16	07288-21025	HOSE	2	SN: 10001-UP
17	07281-00197	CLAMP	5	SN: 10001-UP
18	07288-21027	HOSE	1	SN: 10001-UP
19	07270-40404	TUBE	1	SN: 10001-UP
20	22W-04-11220	NIPPLE	1	SN: 10001-UP
21	07281-00137	CLAMP	1	SN: 10001-UP
22	07285-00085	CLIP	1	SN: 10001-UP
23	07281-00197	CLAMP	1	SN: 10001-UP
24	421-09-12211	CLIP	1	SN: 10001-UP
25	01435-01016	BOLT	1	SN: 10001-UP
26	421-09-12211	CLIP	3	SN: 10001-UP
27	423-584-11340	SPACER	3	SN: 10001-UP
28	01435-01035	BOLT	3	SN: 10001-UP
29	421-09-12211	CLIP	2	SN: 10001-UP
30	04434-51610	CLIP	1	SN: 10001-UP
31	01643-31232	WASHER	2	SN: 10001-UP
32	419-54-11270	SPACER	1	SN: 10001-UP
33	01643-31032	WASHER	3	SN: 10001-UP
34	01580-11008	NAT	3	SN: 10001-UP

Get the complete PDF catalogue

Komatsu LW80-1H (JPN) HYDRAULIC EXCAVATOR S/N 10001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.