





Reference: 1001

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	22T-01-12160	BRACKET	2	SN: 18001-UP
2	01010-61265	BOLT	8	SN: 18001-UP
3	01643-31232	WASHER	8	SN: 18001-UP
4	22T-01-16110	BRACKET	2	SN: 18001-UP
5	01010-61035	BOLT	8	SN: 18001-UP
6	01643-31032	WASHER	8	SN: 18001-UP
7	04020-01228	PIN, DOWEL	4	SN: 18001-UP
8	22T-15-12130	CUSHION	8	SN: 18001-UP
9	22T-01-12140	PLATE	4	SN: 18001-UP
10	01010-61695	BOLT	4	SN: 18001-UP
11	01643-31645	WASHER	4	SN: 18001-UP
12	22T-01-11510	COVER	1	SN: 18001-UP
13	01010-81020	BOLT	4	SN: 18001-UP
14	01643-31032	WASHER	4	SN: 18001-UP

Reference: 1001





PM49116

Reference: 1021

030020 AIR CLEANER CONNECTION

Item	Part No.	Part Name	Qty	Options
1	08670-02001	INDICATOR, DUST	1	SN: 18001-UP
2	22T-02-11120	HOSE	1	SN: 18001-UP
3	22T-02-11130	TUBE	1	SN: 18001-UP
4	22T-02-11140	HOSE	1	SN: 18001-UP
5	07281-01159	CLAMP	1	SN: 18001-UP
6	07281-00809	CLAMP	3	SN: 18001-UP
7	22T-02-11150	BRACKET	1	SN: 18001-UP
8	01010-81025	BOLT	1	SN: 18001-UP
9	01643-31032	WASHER	1	SN: 18001-UP
10	07283-26155	CLIP	1	SN: 18001-UP
11	01597-01009	NAT	2	SN: 18001-UP
12	01643-31032	WASHER	2	SN: 18001-UP

Reference: 1021




PM48523

Reference: 1031

030030 TURBOCHARGER GUARD

Item	Part No.	Part Name	Qty	Options
1	22T-02-12260	COVER	1	SN: 18001-UP
2	01010-81020	BOLT	2	SN: 18001-UP
3	01643-31032	WASHER	2	SN: 18001-UP
4	01010-80845	BOLT	1	SN: 18001-UP
5	01643-30823	WASHER	1	SN: 18001-UP
6	417-54-12260	SPACER	1	SN: 18001-UP


Reference: 1031



Reference: 1041

030040 EXHAUST CONNECTION

Item	Part No.	Part Name	Qty	Options
1	22T-02-16130	TUBE	1	SN: 18001-UP
2	22W-02-11180	COUPLING	2	SN: 18001-UP
3	22T-02-12620	GASKET	4	SN: 18001-UP
4	22T-02-12110	TUBE	1	SN: 18001-UP
5	22T-02-12120	CLAMP	1	SN: 18001-UP
6	01435-01230	BOLT	2	SN: 18001-UP
7	01584-01210	NAT	2	SN: 18001-UP
8	22T-02-12140	TUBE	1	SN: 18001-UP
9	22T-02-12180	COVER	1	SN: 18001-UP
10	07283-27671	CLIP	1	SN: 18001-UP
11	01582-11008	NAT	2	SN: 18001-UP
12	01643-31032	WASHER	2	SN: 18001-UP
13	22T-02-16120	COVER	1	SN: 18001-UP
14	01435-01016	BOLT	4	SN: 18001-UP
15	22T-02-16110	BRACKET	1	SN: 18001-UP
16	01010-81025	BOLT	4	SN: 18001-UP
17	01643-31032	WASHER	4	SN: 18001-UP
18	22T-02-12211	COVER	1	SN: 18001-UP
19	01010-81020	BOLT	4	SN: 18001-UP
20	01643-31032	WASHER	4	SN: 18001-UP
21	22T-02-12310	PAD	1	SN: 18001-18048
22	22T-02-12320	PAD	1	SN: 18001-18048
23	22T-02-12330	PAD	1	SN: 18001-18048
24	04431-30000	PLATE	28	SN: 18001-18048
25	22T-02-12240	COVER	1	SN: 18001-UP
26	01010-81020	BOLT	3	SN: 18001-UP
27	01643-31032	WASHER	3	SN: 18001-UP
28	22T-02-12251	COVER	1	SN: 18001-UP
29	01010-81020	BOLT	2	SN: 18001-UP
30	01643-31032	WASHER	2	SN: 18001-UP
31	22T-02-16140	TUBE	1	SN: 18001-UP
32	01010-81020	BOLT	1	SN: 18001-UP
33	01643-31032	WASHER	1	SN: 18001-UP




PM49118

Reference: 1101

030050 ACCELERATOR PEDAL AND THROTTLE LEVER

Item	Part No.	Part Name	Qty	Options
	22T-43-17100	PEDAL ASSEMBLY	1	SN: 18001-UP
1	22T-43-17110	• PEDAL	1	SN: 18001-UP
2	22T-42-11220	• • BUSH	2	SN: 18001-UP
3	22T-43-17190	• • PAD	1	SN: 18001-UP
4	22T-42-11230	• • STOP	2	SN: 18001-UP
5	22T-43-17120	• BRACKET	1	SN: 18001-UP
6	22T-42-11150	• COLOR	1	SN: 18001-UP
7	22T-42-11130	• BOLT	1	SN: 18001-UP
8	22T-43-14320	• NAT	1	SN: 18001-UP
9	22T-43-17220	• SPRING	1	SN: 18001-UP
10	01016-50830	• BOLT	1	SN: 18001-UP
11	01580-10806	• NAT	1	SN: 18001-UP
12	22T-05-19310	• SWITCH	1	SN: 18001-UP
13	01010-81020	BOLT	2	SN: 18001-UP
14	01643-31032	WASHER	2	SN: 18001-UP
15	22T-43-17140	CABLE	1	SN: 18001-UP
16	22T-43-17160	YOKE	1	SN: 18001-UP
17	01580-10605	NAT	1	SN: 18001-UP
18	04205-10620	PIN	1	SN: 18001-UP
19	01641-20608	WASHER	1	SN: 18001-UP
20	04052-10633	PIN, SNAP	1	SN: 18001-UP
21	22T-43-17150	BRACKET	1	SN: 18001-UP
22	01435-01016	BOLT	2	SN: 18001-UP
23	22T-43-17170	PLATE	1	SN: 18001-UP
24	01010-81016	BOLT	2	SN: 18001-UP
25	01643-31032	WASHER	2	SN: 18001-UP
26	22T-42-11240	CUSHION	1	SN: 18001-UP
27	01580-10806	NAT	1	SN: 18001-UP

Reference: 1101




PM48119

Reference: 1103

030060 ACCELERATOR PIPING

Item	Part No.	Part Name	Qty	Options
1	22T-43-14200	MASTER CYLINDER ASSEMBLY	1	SN: 18001-UP
2	01435-00825	BOLT	2	SN: 18001-UP
3	01580-10806	NAT	2	SN: 18001-UP
4	04205-10825	PIN	1	SN: 18001-UP
5	04050-12015	PIN, COTTER	1	SN: 18001-UP
6	07260-20956	HOSE	1	SN: 18001-UP
7	07281-00197	CLAMP	2	SN: 18001-UP
8	22T-43-17180	HOSE	1	SN: 18001-UP
9	07235-10210	ERBO	1	SN: 18001-UP
10	07230-20210	UNION	1	SN: 18001-UP
11	07002-11423	O RING	2	SN: 18001-UP
12	04434-51610	CLIP	1	SN: 18001-UP
13	04434-51410	CLIP	4	SN: 18001-UP
14	01435-01016	BOLT	3	SN: 18001-UP
15	201-43-28440	GROMMET	1	SN: 18001-UP

Reference: 1103



PN49120


Reference: 1105

030070 MASTER CYLINDER (FOR ACCELERATOR PEDAL)

Item	Part No.	Part Name	Qty	Options
	22T-43-14200	MASTER CYLINDER ASSEMBLY	1	SN: 18001-UP
1		• ☆ CYLINDER	1	SN: 18001-UP
2		• ☆ PISTON ASSEMBLY (K1)	1	SN: 18001-UP
3		• ☆ SPRING (K1)	1	SN: 18001-UP
4	22T-43-14410	• PIN	1	SN: 18001-UP
5		• ☆ GASKET (K1)	1	SN: 18001-UP
6		• ☆ O RING (K1)	1	SN: 18001-UP
7	22T-43-14450	• ROD	1	SN: 18001-UP
8	22T-43-14420	• PLATE	1	SN: 18001-UP
9		• ☆ WIRE (K1)	1	SN: 18001-UP
10		• ☆ BOOT (K1)	1	SN: 18001-UP
11	22T-43-14490	• YOKE	1	SN: 18001-UP
12	22T-43-14460	• NAT	1	SN: 18001-UP
13	22T-43-14440	• PLUG	1	SN: 18001-UP
14	22T-43-14430	• GASKET	1	SN: 18001-UP
15	22T-43-14480	• COUPLING	1	SN: 18001-UP
16	22T-43-14470	• CLAMP	1	SN: 18001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1105




PW49121

Reference: 1111

030080 ENGINE CONTROL LINKAGE

Item	Part No.	Part Name	Qty	Options
1	22T-43-18910	BRACKET	1	SN: 18001-UP
2	01010-81040	BOLT	2	SN: 18001-UP
3	01010-81025	BOLT	4	SN: 18001-UP
4	01643-31032	WASHER	6	SN: 18001-UP
5	22T-43-18920	LEVER	1	SN: 18001-UP
6	06123-01614	BEARING	2	SN: 18001-UP
7	22T-43-18930	LEVER	1	SN: 18001-UP
8	01306-10820	SCREW	1	SN: 18001-UP
9	04059-01020	WOW	1	SN: 18001-UP
	22T-43-18200	ABSORBER ASSEMBLY	1	SN: 18001-UP
10	22T-43-18220	• BODY	1	SN: 18001-UP
11	22T-43-18210	• ROD	1	SN: 18001-UP
12	22T-43-18230	• GUIDE	1	SN: 18001-UP
13	417-15-15820	• SPRING	1	SN: 18001-UP
14	04205-10822	PIN	1	SN: 18001-UP
15	04050-12015	PIN, COTTER	1	SN: 18001-UP
16	22T-43-18101	MASTER CYLINDER ASSEMBLY	1	SN: 18001-UP
16	22T-43-18111	• SERVICE KIT	1	SN: 18001-UP
17	01580-10806	NAT	1	SN: 18001-UP
18	01435-00825	BOLT	2	SN: 18001-UP
19	04245-40612	ROD	1	SN: 18001-UP
20	04256-40615	JOINT	2	SN: 18001-UP
21	01580-10605	NAT	4	SN: 18001-UP
22	01643-30623	WASHER	4	SN: 18001-UP
23	22T-43-18350	LEVER	1	SN: 18001-UP
24	22T-43-18380	SHAFT	1	SN: 18001-UP
25	363-43-27260	BEARING	1	SN: 18001-UP
26	01580-10605	NAT	1	SN: 18001-UP
27	01643-30623	WASHER	1	SN: 18001-UP
28	22T-43-18370	CONNECTOR	1	SN: 18001-UP
29	363-43-31170	SPRING	1	SN: 18001-UP

Reference: 1111



PM49122

Reference: 1121

030090 ENGINE STOP MOTOR MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	22T-43-18450	PLATE	1	SN: 18001-UP
2	01435-01035	BOLT	2	SN: 18001-UP
3	424-64-11110	SPACER	2	SN: 18001-UP
4	04256-40615	JOINT	1	SN: 18001-UP
5	01580-10605	NAT	2	SN: 18001-UP
6	01643-30623	WASHER	1	SN: 18001-UP
7	04434-50810	CLIP	3	SN: 18001-UP
8	419-54-11270	SPACER	2	SN: 18001-UP
9	419-62-13390	SPACER	1	SN: 18001-UP
10	01580-11008	NAT	2	SN: 18001-UP
11	01643-31032	WASHER	2	SN: 18001-UP
12	01435-01050	BOLT	1	SN: 18001-UP

Reference: 1121

Get the complete PDF catalogue

Komatsu LW80-1X (JPN) X BULLDOZER S/N 18001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.

Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.