




P 030010

Reference: F2320-51A0

030010 TRANSMISSION INPUT SHAFT (#10001-10117)

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-@
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-@
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-@
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-@
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-@
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-@
		THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.		
1	772-19-12413	• SHAFT ASSEMBLY	1	SN: 10094-@
1	772-19-12412	• SHAFT ASSEMBLY	1	SN: 10090-10093
1	772-19-12411	• SHAFT ASSEMBLY, INPUT	1	SN: 10001-10089
1		• ☆ SHAFT, INPUT	1	SN: 10001-@
1		• ☆ GEAR	1	SN: 10094-@
1		• ☆ GEAR	1	SN: 10090-10093
1		• ☆ GEAR, FORWARD	1	SN: 10001-10089
1		• ☆ ORIFICE	1	SN: 10001-@
1		• ☆ PLUG	1	SN: 10001-@
1		• ☆ BALL	1	SN: 10001-@
1		• ☆ SCREW	2	SN: 10090-10093
1		• ☆ SCREW	2	SN: 10001-10089
2	7720-65-2430	• RING, STOPPER	1	SN: 10001-@
3	772-19-12470	• WASHER, THRUST	1	SN: 10001-@
4	772-19-12450	• BEARING, WAVE	1	SN: 10001-@
5	772-19-12680	• SPRING	8	SN: 10001-@
6	772-13-12691	• DISK	8	SN: 10001-@
7	772-10-12720	• PLATE, SEPARATOR	9	SN: 10001-@
8	772-19-12630	• PLATE, END	1	SN: 10001-@
9	419-15-12140	• RING, SNAP	1	SN: 10001-@
10	772-19-12470	• WASHER, THRUST	1	SN: 10001-@
11	772-19-12440	• BEARING	1	SN: 10001-@
12	772-19-12512	• PISTON	1	SN: 10094-@
12	772-19-12511	• PISTON	1	SN: 10090-10093
12	772-19-12510	• PISTON	1	SN: 10001-10089
13	7720-70-2520	• SEAL, RING (K1)	1	SN: 10001-@
14	7720-50-2530	• SEAL, RING (K1)	1	SN: 10001-@
15	07018-00402	• LINK	2	SN: 10001-@
16	01310-11216	• SCREW	2	SN: 10001-@
17	772-13-12860	• BEARING	1	SN: 10001-@
18	772-19-15110	• GEAR ASSEMBLY, (1.59)	1	SN: 10001-@
18	772-19-15210	• GEAR ASSEMBLY, (2.10)	1	SN: 10001-@
18	772-19-15310	• GEAR ASSEMBLY, (2.56)	1	SN: 10001-@
18	772-19-15410	• GEAR ASSEMBLY, (3.13)	1	SN: 10001-@
18	772-19-15511	• GEAR ASSEMBLY, (3.52)	1	SN: 10001-@
18	772-19-15630	• GEAR ASSEMBLY, (2.92)	1	SN: 10001-@
18		• ☆ GEAR, TEETH 37, (1.59)	1	SN: 10001-@
18		• ☆ GEAR, TEETH 31, (2.10)	1	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
18		••☆ GEAR, HELICAL 27, (2.56)	1	SN: 10001-@
18		••☆ GEAR, TEETH 23, (3.13)	1	SN: 10001-@
18		••☆ GEAR, BUSHING 21, (3.52)	1	SN: 10001-@
18		••☆ GEAR, TEETH 24, (2.92)	1	SN: 10001-@
18		••☆ BUSH	1	SN: 10001-@
18		••☆ SPACER	1	SN: 10001-@

Catalog signs: ☆ not supplied separately: assembly only

Reference: F2320-51A0



Reference: F2320-51A0A


030020 TRANSMISSION INPUT SHAFT (#10118-)

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-UP
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-UP
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-UP
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-UP
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-UP
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-UP
		THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.		
	772-19-02410	• SHAFT ASSEMBLY (1.59), FORWARD	1	SN: 10118-UP
	772-19-02420	• SHAFT ASSEMBLY (2.10), FORWARD	1	SN: 10118-UP
	772-19-02430	• SHAFT ASSEMBLY (2.56), FORWARD	1	SN: 10118-UP
	772-19-02450	• SHAFT ASSEMBLY (3.13), FORWARD	1	SN: 10118-UP
	772-19-02460	• SHAFT ASSEMBLY (3.52), FORWARD	1	SN: 10118-UP
	772-19-02440	• SHAFT ASSEMBLY (2.92), FORWARD	1	SN: 10118-UP
1	772-19-12413	•• SHAFT ASSEMBLY	1	SN: 10094-UP
1		••• ☆ SHAFT, INPUT	1	SN: 10001-UP
1		••• ☆ GEAR	1	SN: 10094-UP
1		••• ☆ ORIFICE	1	SN: 10001-UP
1		••• ☆ PLUG	1	SN: 10001-UP
1		••• ☆ BALL	1	SN: 10001-UP
2	7720-65-2430	•• RING, STOPPER	1	SN: 10001-UP
3	772-19-12470	•• WASHER, THRUST	1	SN: 10001-UP
4	772-19-12450	•• BEARING, WAVE	1	SN: 10001-UP
5	772-19-12681	•• SPRING, WAVE	8	SN: 10001-UP
5	772-19-12680	•• ☒ SPRING, WAVE	8	SN: (10001-(110209))
6	772-13-12691	•• DISK	8	SN: 10001-UP
7	772-10-12720	•• PLATE, SEPARATOR	9	SN: 10001-UP
8	772-19-12630	•• PLATE, END	1	SN: 10001-UP
9	419-15-12140	•• RING, SNAP	1	SN: 10001-UP
10	772-19-12470	•• WASHER, THRUST	1	SN: 10001-UP
11	772-19-12440	•• BEARING	1	SN: 10001-UP
12	772-19-12512	•• PISTON	1	SN: 10094-UP
13	7720-70-2520	•• SEAL, RING (K1)	1	SN: 10001-UP
14	7720-50-2530	•• SEAL, RING (K1)	1	SN: 10001-UP
15	07018-00402	•• LINK	2	SN: 10001-UP
16	01310-11216	•• SCREW	2	SN: 10001-UP
17	772-13-12860	•• BEARING	1	SN: 10001-UP
18	772-19-15110	•• GEAR ASSEMBLY, (1.59)	1	SN: 10001-UP
18	772-19-15210	•• GEAR ASSEMBLY, (2.10)	1	SN: 10001-UP
18	772-19-15310	•• GEAR ASSEMBLY, (2.56)	1	SN: 10001-UP
18	772-19-15410	•• GEAR ASSEMBLY, (3.13)	1	SN: 10001-UP
18	772-19-15511	•• GEAR ASSEMBLY, (3.52)	1	SN: 10001-UP
18	772-19-15630	•• GEAR ASSEMBLY, (2.92)	1	SN: 10001-UP
18		••• ☆ GEAR, TEETH 37, (1.59)	1	SN: 10001-UP
18		••• ☆ GEAR, TEETH 31, (2.10)	1	SN: 10001-UP
18		••• ☆ GEAR, HELICAL 27, (2.56)	1	SN: 10001-UP
18		••• ☆ GEAR, TEETH 23, (3.13)	1	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
18		••• ☆ GEAR, BUSHING 21, (3.52)	1	SN: 10001-UP
18		••• ☆ GEAR, TEETH 24, (2.92)	1	SN: 10001-UP
18		••• ☆ BUSH	1	SN: 10001-UP
18		••• ☆ SPACER	1	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only ☒ discontinued: use part above

Reference: F2320-51A0A



Reference: F2320-52A0


030030 TRANSMISSION REVERSE SHAFT (#10001-10117)

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-@
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-@
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-@
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-@
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-@
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-@
		THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.		
1	772-19-12813	• SHAFT ASSEMBLY	1	SN: 10094-@
1	772-19-12812	• SHAFT ASSEMBLY	1	SN: 10090-10093
1	772-19-12811	• SHAFT ASSEMBLY, REVERSE	1	SN: 10001-10089
1		• ☆ SHAFT, REVERSE	1	SN: 10001-@
1	772-19-12843	• GEAR	1	SN: 10094-@
1	772-19-12842	• GEAR	1	SN: 10090-10093
1	772-19-12841	• GEAR, REVERSE	1	SN: 10001-10089
1		• ☆ ORIFICE	1	SN: 10001-@
1		• ☆ BALL	1	SN: 10001-@
1	772-19-12611	• SCREW	2	SN: 10090-10093
1	772-19-12610	• SCREW	2	SN: 10001-10089
2	772-19-12860	• BEARING	1	SN: 10001-@
3	772-19-12830	• COLLAR	1	SN: 10001-@
4	772-19-12480	• WASHER, THRUST	1	SN: 10001-@
5	772-19-12680	• SPRING, WAVE	8	SN: 10001-@
6	772-13-12691	• DISK	8	SN: 10001-@
7	772-10-12720	• PLATE, SEPARATOR	9	SN: 10001-@
8	772-19-12630	• PLATE, END	1	SN: 10001-@
9	419-15-12140	• RING, SNAP	1	SN: 10001-@
10	772-19-12470	• WASHER, THRUST	1	SN: 10001-@
11	772-19-12440	• BEARING, THRUST	1	SN: 10001-@
12	772-19-12512	• PISTON	1	SN: 10094-@
12	772-19-12511	• PISTON	1	SN: 10090-10093
12	772-19-12510	• PISTON	1	SN: 10001-10089
13	7720-70-2520	• SEAL, RING (K1)	1	SN: 10001-@
14	7720-50-2530	• SEAL, RING (K1)	1	SN: 10001-@
15	07018-00402	• LINK	2	SN: 10001-@
16	419-22-11820	• BEARING	1	SN: 10001-@
17	772-19-15610	• GEAR ASSEMBLY, (1.59)	1	SN: 10001-@
17	772-19-15710	• GEAR ASSEMBLY, (2.10)	1	SN: 10001-@
17	772-19-15810	• GEAR ASSEMBLY, (2.56)	1	SN: 10001-@
17	772-19-15910	• GEAR ASSEMBLY, (3.13)	1	SN: 10001-@
17	772-19-15621	• GEAR ASSEMBLY, (3.52)	1	SN: 10001-@
17	772-19-15640	• GEAR ASSEMBLY, (2.92)	1	SN: 10001-@
17		• ☆ GEAR, TEETH 37, (1.59)	1	SN: 10001-@
17		• ☆ GEAR, TEETH 31, (2.10)	1	SN: 10001-@
17		• ☆ GEAR, HELICAL 27, (2.56)	1	SN: 10001-@
17		• ☆ GEAR, TEETH 23, (3.13)	1	SN: 10001-@
17		• ☆ GEAR, BUSHING 21, (3.52)	1	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
17		••☆ GEAR, TEETH 24, (2.92)	1	SN: 10001-@
17		••☆ BUSH	1	SN: 10001-@
18	772-19-12870	• SPACER	2	SN: 10001-@

Catalog signs: ☆ not supplied separately: assembly only

Reference: F2320-52A0



Reference: F2320-52A0A


030040 TRANSMISSION REVERSE SHAFT (#10118-)

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-UP
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-UP
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-UP
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-UP
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-UP
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-UP
	THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.			
	772-19-02811	• SHAFT ASSEMBLY (1.59)	1	SN: 10140-UP
	772-19-02810	• SHAFT ASSEMBLY (1.59), REVERSE	1	SN: 10118-10139
	772-19-02821	• SHAFT ASSEMBLY (2.10)	1	SN: 10140-UP
	772-19-02820	• SHAFT ASSEMBLY (2.10), REVERSE	1	SN: 10118-10139
	772-19-02831	• SHAFT ASSEMBLY (2.56)	1	SN: 10140-UP
	772-19-02830	• SHAFT ASSEMBLY (2.56), REVERSE	1	SN: 10118-10139
	772-19-02841	• SHAFT ASSEMBLY (2.92)	1	SN: 10140-UP
	772-19-02840	• SHAFT ASSEMBLY (2.92), REVERSE	1	SN: 10118-10139
	772-19-02851	• SHAFT ASSEMBLY (3.13)	1	SN: 10140-UP
	772-19-02850	• SHAFT ASSEMBLY (3.13), REVERSE	1	SN: 10118-10139
	772-19-02861	• SHAFT ASSEMBLY (3.52)	1	SN: 10140-UP
	772-19-02860	• SHAFT ASSEMBLY (3.52), REVERSE	1	SN: 10118-10139
1	772-19-12814	•• SHAFT ASSEMBLY	1	SN: 10140-UP
1	772-19-12813	•• SHAFT ASSEMBLY, REVERSE	1	SN: 10094-10139
1		•• ☆ SHAFT	1	SN: 10140-UP
1		•• ☆ SHAFT, REVERSE	1	SN: 10001-10139
1		•• ☆ GEAR	1	SN: 10094-UP
1		•• ☆ ORIFICE	1	SN: 10001-10139
1		•• ☆ BALL	1	SN: 10001-UP
1A	772-19-18211	•• JOINT	1	SN: 10140-UP
1B	04065-02612	•• LINK	1	SN: 10140-UP
2	772-19-12860	•• BEARING	1	SN: 10001-UP
3	772-19-12830	•• COLLAR	1	SN: 10001-UP
4	772-19-12480	•• WASHER, THRUST	1	SN: 10001-UP
5	772-19-12681	•• SPRING, WAVE	8	SN: 10001-UP
5	772-19-12680	•• ☒ SPRING, WAVE	8	SN: (10001-(110209))
6	772-13-12691	•• DISK	8	SN: 10001-UP
7	772-10-12720	•• PLATE, SEPARATOR	9	SN: 10001-UP
8	772-19-12630	•• PLATE, END	1	SN: 10001-UP
9	419-15-12140	•• RING, SNAP	1	SN: 10001-UP
10	772-19-12470	•• WASHER, THRUST	1	SN: 10001-UP
11	772-19-12440	•• BEARING, THRUST	1	SN: 10001-UP
12	772-19-12512	•• PISTON	1	SN: 10094-UP
13	7720-70-2520	•• SEAL, RING (K1)	1	SN: 10001-UP
14	7720-50-2530	•• SEAL, RING (K1)	1	SN: 10001-UP
15	07018-00402	•• LINK	2	SN: 10001-UP
16	419-22-11820	•• BEARING	1	SN: 10001-UP
17	772-19-15610	•• GEAR ASSEMBLY, (1.59)	1	SN: 10001-UP
17	772-19-15710	•• GEAR ASSEMBLY, (2.10)	1	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
17	772-19-15810	•• GEAR ASSEMBLY, (2.56)	1	SN: 10001-UP
17	772-19-15910	•• GEAR ASSEMBLY, (3.13)	1	SN: 10001-UP
17	772-19-15621	•• GEAR ASSEMBLY, (3.52)	1	SN: 10001-UP
17	772-19-15640	•• GEAR ASSEMBLY, (2.92)	1	SN: 10001-UP
17		••• ☆ GEAR, TEETH 37, (1.59)	1	SN: 10001-UP
17		••• ☆ GEAR, TEETH 31, (2.10)	1	SN: 10001-UP
17		••• ☆ GEAR, HELICAL 27, (2.56)	1	SN: 10001-UP
17		••• ☆ GEAR, TEETH 23, (3.13)	1	SN: 10001-UP
17		••• ☆ GEAR, BUSHING 21, (3.52)	1	SN: 10001-UP
17		••• ☆ GEAR, TEETH 21, (2.92)	1	SN: 10001-UP
17		••• ☆ GEAR, TEETH 24	1	SN: 10001-UP
18	772-19-12870	•• SPACER	2	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only ☒ discontinued: use part above

Reference: F2320-52A0A



PV3M274


Reference: F2320-53A0

030050 TRANSMISSION OUTPUT SHAFT

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-UP
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-UP
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-UP
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-UP
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-UP
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-UP
		THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.		
1	772-19-13210	• BEARING	1	SN: 10001-UP
2	7720-65-3220	• BEARING	1	SN: 10001-UP
3	772-19-15150	• SHAFT ASSEMBLY, (1.59)	1	SN: 10001-UP
3	772-19-15250	• SHAFT ASSEMBLY, (2.10)	1	SN: 10001-UP
3	772-19-15350	• SHAFT ASSEMBLY, (2.56)	1	SN: 10001-UP
3	772-19-15450	• SHAFT ASSEMBLY, (3.13)	1	SN: 10001-UP
3	772-19-15550	• SHAFT ASSEMBLY, (3.52)	1	SN: 10001-UP
3	772-19-15750	• SHAFT ASSEMBLY, (2.92)	1	SN: 10001-UP
3		• ☆ GEAR, TEETH 59, (1.59)	1	SN: 10001-UP
3		• ☆ GEAR, TEETH 65, (2.10)	1	SN: 10001-UP
3		• ☆ GEAR, TOOTH COUNT 69, (2.56)	1	SN: 10001-UP
3		• ☆ GEAR, TOOTH COUNT 72, (3.13)	1	SN: 10001-UP
3		• ☆ GEAR, HELICAL 74, (3.52)	1	SN: 10001-UP
3		• ☆ GEAR, TEETH 74, (2.92)	1	SN: 10001-UP
3		• ☆ SHAFT	1	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: F2320-53A0



Reference: F2320-54A0

030060 TRANSMISSION FLYWHEEL

Item	Part No.	Part Name	Qty	Options
	772-19-20T00	MARINE GEAR ASSEMBLY (1.59)	1	SN: 10001-UP
	772-19-20T10	MARINE GEAR ASSEMBLY (2.10)	1	SN: 10001-UP
	772-19-20T20	MARINE GEAR ASSEMBLY (2.56)	1	SN: 10001-UP
	772-19-20T30	MARINE GEAR ASSEMBLY (3.13)	1	SN: 10001-UP
	772-19-20T40	MARINE GEAR ASSEMBLY (3.52)	1	SN: 10001-UP
	772-19-20T50	MARINE GEAR ASSEMBLY (2.92)	1	SN: 10001-UP
		THE CONFIGURATION OF THE COLLAR ASSEMBLY INCLUDES FIG.F2320-51A0 TO FIG.F2320-65A0.		
1	772-19-11310	• LINK	1	SN: 10001-UP
2	772-19-11210	• HOUSING	1	SN: 10001-UP
3	04020-01228	• PIN	2	SN: 10001-UP
4	01010-81240	• BOLT	13	SN: 10001-UP
5	01643-31232	• WASHER	13	SN: 10001-UP
6	7720-30-2111	• DUMPER	24	SN: 10001-UP
	772-19-12110	• SPIDER ASSEMBLY	1	SN: 10001-UP
7		• ☆ SPIDER	1	SN: 10001-UP
8		• ☆ BUSHING, SPIDER	1	SN: 10001-UP
9		• ☆ LINK	1	SN: 10001-UP
10		• ☆ PLUG	1	SN: 10001-UP
11	772-19-12180	• BEARING	1	SN: 10001-UP
12	7720-65-2150	• COLLAR	1	SN: 10001-UP
13	04064-09030	• RING, SNAP	1	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: F2320-54A0

Get the complete PDF catalogue

Komatsu M650-2 (JPN) 6M137A-1 S/N 10001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.

Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.