


FIG. 101 シリンダヘッド
CYLINDER HEAD



Reference: 101

030010 CYLINDER HEAD


Item	Part No.	Part Name	Qty	Options
	6610-10-1001	CYLINDER HEAD A.	3	SN: .-UP
	6610-10-1000	□ CYLINDER HEAD A.	3	SN: 18566-.
	6610-10-1101	• CYLINDER HEAD A.	1	SN: .-UP
	6610-10-1100	• □ CYLINDER HEAD A.	1	SN: 18566-.
1		• ☆ HEAD,CYLINDER	1	SN: 18566-UP
2	6610-11-1311	• • GUIDE,VALVE	8	SN: .-UP
	6610-11-1310	• • □ GUIDE,VALVE	8	SN: 18566-.
3	6610-11-1140	• • GUIDE,CROSSHEAD	4	SN: 18566-UP
4	6610-11-1220	• • INSERT (STD)	4	SN: .-UP
	6610-11-1120	• • □ INSERT (STD)	4	SN: 18566-.
	6610-19-1220	• • INSERT ? 0.13MM (OS)	4	SN: .-UP
	6610-19-1120	• • □ INSERT ? 0.13MM (OS)	4	SN: 18566-.
	6610-18-1220	• • INSERT ? 0.25MM (OS)	4	SN: .-UP
	6610-18-1120	• • □ INSERT ? 0.25MM (OS)	4	SN: 18566-.
	6610-17-1220	• • INSERT ? 0.50MM (OS)	4	SN: .-UP
	6610-17-1120	• • □ INSERT ? 0.50MM (OS)	4	SN: 18566-.
	6610-16-1220	• • INSERT ? 0.75MM (OS)	4	SN: .-UP
	6610-16-1120	• • □ INSERT ? 0.75MM (OS)	4	SN: 18566-.
	6610-15-1220	• • INSERT ? 1.00MM (OS)	4	SN: .-UP
	6610-15-1120	• • □ INSERT ? 1.00MM (OS)	4	SN: 18566-.
5	6610-11-1130	• • SLEEVE,INJECTOR	2	SN: 18566-UP
6	02720-11616	• • PLUG	6	SN: 18566-UP
7	6610-11-1460	• • PLUG	2	SN: 18566-UP
8	6610-11-1470	• • PLUG	1	SN: 18566-UP
9	6610-11-1420	• • PIN,DOWEL	2	SN: 18566-UP
10	6610-41-4210	• VALVE,EXHAUST	4	SN: 18566-UP
11	6610-41-4110	• VALVE,INTAKE	4	SN: 18566-UP
12	6610-41-4410	• SPRING,VALVE	8	SN: 18566-UP
13	6610-41-4510	• GUIDE,VALVE SPRING	8	SN: 18566-UP
14	6600-01-3910	• COLLET,HALF ? VALVE	16	SN: 18566-UP
15	6610-41-5610	CROSSHEAD,ADJUSTING	12	SN: 18566-UP
16	6610-41-5620	SCREW	12	SN: 18566-UP
17	6600-01-2520	NUT	12	SN: 18566-UP
18	6610-21-2610	PIPE,OIL	3	SN: 18566-UP

Item	Part No.	Part Name	Qty	Options
19	6610-11-1711	GASKET (K2)	3	SN: .-UP
	6610-11-1710	GASKET (K2)	3	SN: 18566-.
	6610-11-1080	GASKET ASS'Y,CYLINDER HEAD (K2)	3	SN: 18566-UP
20		• ☆ GASKET (K2)	1	SN: 18566-UP
21	6610-11-1840	• • GROMMET (K2)	1	SN: 18566-UP
22	6610-11-1830	• • RING (K2)	2	SN: 18566-UP
23	6610-11-1820	• • GROMMET (K2)	8	SN: 18566-UP
24	6610-11-1850	• RETAINER (K2)	8	SN: 18566-UP

Catalog signs: ☐ part above may be used instead ☆ not supplied separately: assembly only

Reference: 101

FIG. 102 ROCKER ARM AND HOUSING



Reference: 102

030020 ROCKER ARM AND HOUSING


Item	Part No.	Part Name	Qty	Options
	6620-11-7010	HOUSING ASS'Y,ROCKER ARM	3	SN: 18566-UP
	6610-11-7020	• HOUSING ASS'Y,ROCKER ARM	1	SN: 18566-UP
1	6610-11-7110	•• HOUSING,ROCKER ARM	1	SN: 18566-UP
2	6610-11-7150	•• PLUG,EXPANSION	2	SN: 18566-UP
3	6610-11-7140	• PLUG,VENTILATOR	1	SN: 18566-UP
4	6610-11-7330	• SCREW	1	SN: 18566-UP
5	6610-11-7340	• PLATE,LOCK (K2)	1	SN: 18566-UP
	6610-41-5020	• SHAFT ASS'Y,ROCKER ARM	1	SN: 18566-UP
6		•• ☆ SHAFT,ROCKER ARM	1	SN: 18566-UP
7	6610-41-5220	•• PLUG	2	SN: 18566-UP
	6610-41-5030	• ARM ASS'Y,EXHAUST VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
	6610-41-5050	• ARM ASS'Y,EXHAUST VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
	6620-41-5030	• ARM ASS'Y,INTAKE VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
	6620-41-5050	• ARM ASS'Y,INTAKE VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
	6610-41-5040	•• ARM ASS'Y,EXHAUST VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
	6610-41-5060	•• ARM ASS'Y,EXHAUST VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
	6620-41-5040	•• ARM ASS'Y,INTAKE VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
	6620-41-5060	•• ARM ASS'Y,INTAKE VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
8		••• ☆ ARM,EXHAUST VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
9		••• ☆ ARM,EXHAUST VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
10		••• ☆ ARM,INTAKE VALVE ? NO.1 ?3 ?5	1	SN: 18566-UP
11		••• ☆ ARM,INTAKE VALVE ? NO.2 ?4 ?6	1	SN: 18566-UP
12	6610-41-5330	••• BUSHING,ARM	1	SN: 18566-UP
13	6610-41-5360	•• NUT	1	SN: 18566-UP
14	6610-41-5350	•• SCREW,ADJUSTING	1	SN: 18566-UP
	6610-41-5070	• ARM ASS'Y,INJECTOR	2	SN: 18566-UP
	6610-41-5080	•• ARM ASS'Y,INJECTOR	1	SN: 18566-UP
15		••• ☆ ARM,INJECTOR	1	SN: 18566-UP
16	6610-41-5530	••• BUSHING,ROCKER ARM	1	SN: 18566-UP
17	6610-41-5540	••• SOCKET,INJECTOR	1	SN: 18566-UP
18	6600-01-2510	•• NUT	1	SN: 18566-UP
19	6610-41-5550	•• SCREW,ADJUSTING	1	SN: 18566-UP
20	6610-11-7310	CAP,OIL PIPE	3	SN: 18566-UP
21	6610-11-7320	GASKET (K2)	3	SN: 18566-UP

Item	Part No.	Part Name	Qty	Options
22	6610-11-7811	GASKET (K2)	3	SN: 18566-UP
23	02010-30889	BOLT	19	SN: 18566-UP
24	02310-11632	WASHER,SPRING	19	SN: 18566-.

Catalog signs: ☆ not supplied separately: assembly only

Reference: 102

FIG. 103 ロッカー アーム ハウジング カバー
ROCKER ARM HOUSING COVER



Reference: 103

030030 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6610-11-8120	COVER,ROCKER HOUSING	2	SN: 18566-UP
2	6610-11-8810	GASKET (K2)	3	SN: 18566-UP
3	6610-11-8110	COVER,ROCKER HOUSING	1	SN: 18566-UP
	6620-21-7501	BREATHER ASS'Y,CRANKCASE	1	SN: 18566-UP
4	6620-21-7511	• BODY	1	SN: 18566-UP
5	6620-21-7550	• ELEMENT,BREATHER	1	SN: 18566-UP
6	6620-21-7560	• GASKET (K2)	1	SN: 18566-UP
7	6620-21-7540	• NUT,WING	1	SN: 18566-UP
8	6620-21-7520	• COVER,BREATHER	1	SN: 18566-UP
9	6620-21-7530	• GASKET (K2)	1	SN: 18566-UP
10	02010-20632	BOLT	9	SN: 18566-UP
11	02310-11224	WASHER,SPRING	9	SN: 18566-UP
12	02300-11320	WASHER	9	SN: 18566-UP


Reference: 103



Item	Part No.	Part Name	Qty	Options
1	6623-41-8113	SHAFT,COMPRESSION RELEASE	1	SN: 18566-UP
2	02891-02016	O-RING (K2)	2	SN: 18566-UP
3	6610-41-8710	BOLT	1	SN: 18566-UP
4	6600-01-2620	WASHER	1	SN: 18566-UP
5	6610-41-8214	LEVER,COMPRESSION RELEASE	1	SN: 18566-UP
6	01010-31240	BOLT	1	SN: 18566-UP
7	01602-01236	WASHER,SPRING	1	SN: 18566-UP
8	6610-41-8220	SPRING	1	SN: 18566-UP
9	02030-20516	BOLT	1	SN: 18566-UP
10	02300-11120	WASHER	2	SN: 18566-UP
12	02310-11020	WASHER,SPRING	1	SN: 18566-UP

Open this exact parts catalogue on K-Part

FIG. 109 WATER MANIFOLD



Reference: 109


030050 WATER MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6610-11-6131	MANIFOLD,WATER ? REAR	1	SN: 18566-UP
2	6610-11-6121	MANIFOLD,WATER ? CENTER	1	SN: 18566-UP
3	6610-11-6111	MANIFOLD,WATER ? FRONT	1	SN: 18566-UP
4	02720-20810	PLUG	1	SN: 18566-UP
4A	6631-11-6231	ELBOW	1	SN: .-UP
	6631-11-6230	□ ELBOW	1	SN: 18566-.
5	02720-21213	PLUG	1	SN: 18566-UP
6	02720-20204	PLUG	1	SN: 18566-UP
7	6610-11-6140	COUPLING	1	SN: 18566-UP
7A	6631-11-6140	COUPLING	1	SN: 21023-UP
	6693-12-6140	COUPLING	1	SN: 18566-21022
8	02893-05043	O-RING (K2)	4	SN: 18566-UP
	6610-11-6080	GASKET ASS'Y,WATER MANIFOLD (K2)	6	SN: 18566-UP
9	6610-11-6810	• PLATE,RETAINING (K2)	1	SN: 18566-UP
10	6610-11-6820	• RING,SEAL (K2)	1	SN: 18566-UP
11	02030-30522	BOLT	12	SN: 18566-UP
12	02310-11020	WASHER,SPRING	12	SN: 18566-UP
13	6672-12-6290	PLUG	1	SN: 21023-UP
14	07003-01621	GASKET	1	SN: 21023-UP

Catalog signs: ☐ part above may be used instead

Reference: 109

エア・インテーク・マニホールド・および・コネクタ
FIG. 110B AIR INTAKE MANIFOLD AND CONNECTION



Reference: 110B

030060 AIR INTAKE MANIFOLD AND CONNECTION

Item	Part No.	Part Name	Qty	Options
1	6631-11-4110	MANIFOLD,AIR INTAKE	1	SN: 36048-UP
	6675-14-4110	□ MANIFOLD,AIR INTAKE	1	SN: 18566-36047
2	02720-20204	PLUG	1	SN: 18566-UP
3	6110-83-9610	INDICATOR,DUST	1	SN: 18566-24001
4	600-181-0330	ELBOW	1	SN: .-UP
	6110-83-9620	ADAPTER	1	SN: 18566-.
5	6610-11-4811	GASKET,INTAKE MANIFOLD (K2)	3	SN: 18566-UP
6	02010-70657	BOLT	9	SN: 18566-UP
7	02310-11224	WASHER,SPRING	9	SN: 18566-UP
8	02300-11320	WASHER	9	SN: 18566-UP
9	6631-11-4211	CONNECTOR,AIR INTAKE	1	SN: 21190-UP
	6631-11-4210	CONNECTOR,AIR INTAKE	1	SN: 18566-21189
10	6685-11-4222	GASKET,CONNECTOR (K2)	1	SN: 18566-UP
11	01010-31235	BOLT	5	SN: 18566-UP
12	01602-01236	WASHER,SPRING	5	SN: 18566-UP
13	01641-21223	WASHER	5	SN: 18566-UP
14	6631-11-4511	BRACKET,AIR CLEANER	1	SN: .-UP
	6631-11-4510	□ BRACKET,AIR CLEANER	1	SN: 18566-.
15	6675-11-4950	COVER,COLD START	1	SN: 18566-UP
15A	6610-21-2720	PLUG	1	SN: 18566-UP
16	6675-11-4960	GASKET (K2)	1	SN: 18566-UP
17	01010-30830	BOLT	4	SN: 26818-UP
	01000-30830	BOLT	4	SN: 18566-26817
18	01602-00825	WASHER,SPRING	4	SN: 18566-UP
19	01641-20812	WASHER	4	SN: 18566-UP
20	6610-81-4211	GLOW PLUG ASS'Y,PREHEATER	1	SN: 18566-UP
21	6610-81-4230	• GASKET (K2)	1	SN: 18566-UP
	6610-81-4103	NOZZLE ASS'Y,PREHEATER	1	SN: 18566-UP
22	6610-81-4150	• GASKET (K2)	1	SN: 18566-UP
23	6610-81-4112	• NOZZLE ASS'Y	1	SN: 18566-UP
24	6610-81-4120	• PLATE (K2)	1	SN: 18566-UP
25	6610-81-4140	• PIN,SPRING	1	SN: 18566-UP
26	6610-81-4240	• O-RING (K2)	1	SN: 18566-UP
27	6610-81-4132	• ADAPTER,NOZZLE	1	SN: 18566-UP
28	6610-81-8820	ELBOW	1	SN: 18566-UP
29	01010-31030	BOLT	2	SN: .-UP
	01010-31030	BOLT	4	SN: 18566-.
30	01602-01030	WASHER,SPRING	2	SN: .-UP
	01602-01030	WASHER,SPRING	4	SN: 18566-.
	600-181-5111	KOMACLON ASS'Y	1	SN: 21325-UP
	600-181-5110	□ KOMACLON ASS'Y	1	SN: 18566-21324
31A	600-181-5210	• BODY	1	SN: 21325-UP
31B	600-181-5220	• COVER	1	SN: 21325-UP
31C	600-181-5230	• WASHER	1	SN: 21325-UP
31D	01541-51050	• NUT	1	SN: 21325-UP
31E	01010-31035	• BOLT	1	SN: 21325-UP
31F	01580-01008	• NUT	1	SN: 21325-UP


Item	Part No.	Part Name	Qty	Options
32	6685-11-4850	COVER	2	SN: 18566-36047
33	6127-11-4640	GASKET (K2)	2	SN: 18566-36047
34	01010-31025	BOLT	8	SN: 18566-36047
35	01602-01030	WASHER,SPRING	8	SN: 18566-36047

Catalog signs: ☐ part above may be used instead

Reference: 110B



エキゾースト マニホールド および マフラ
FIG. 115B EXHAUST MANIFOLD AND MUFFLER



Reference: 115B

030070 EXHAUST MANIFOLD AND MUFFLER

Item	Part No.	Part Name	Qty	Options
1	6643-11-5130	MANIFOLD,EXHAUST ? REAR	1	SN: 18566-UP
2	6643-11-5120	MANIFOLD,EXHAUST ? CENTER	1	SN: 18566-UP
3	6643-11-5110	MANIFOLD,EXHAUST ? FRONT	1	SN: 18566-UP
4	6620-11-5810	GASKET,EXHAUST MANIFOLD (K2)	6	SN: 18566-UP
5	6610-11-1420	PIN,DOWEL	6	SN: 18566-UP
6	6610-11-5211	CLAMP	6	SN: 21194-UP
	6610-11-5210	□ CLAMP	6	SN: 18566-21193
7	6610-11-5350	BOLT	12	SN: 21194-UP
	02011-40702	BOLT	12	SN: 18566-21193
8	6610-11-5220	PLATE,LOCK (K2)	12	SN: 18566-UP
9	6631-11-5711	MUFFLER	1	SN: 18566-UP
10	6643-11-5750	GASKET,MUFFLER (K2)	1	SN: 18566-UP
11	01050-61245	BOLT	4	SN: 18566-UP
12	6685-11-5550	NUT	4	SN: 18566-UP
13	6631-11-5721	BRACKET	1	SN: 18566-UP
14	01010-31020	BOLT	2	SN: 18566-UP
15	01602-01030	WASHER,SPRING	2	SN: 18566-UP
16	01642-21016	WASHER	2	SN: 18566-UP
17	01050-31020	BOLT	2	SN: 18566-UP
18	01602-01030	WASHER,SPRING	2	SN: 18566-UP
18A	01643-01032	WASHER	2	SN: 18566-UP
19	6631-12-5730	PIPE,EXHAUST	1	SN: 118436-UP
	6693-12-5730	PIPE,EXHAUST	1	SN: 18566-118435
20	6620-11-5742	CLAMP	1	SN: 18566-UP
21	01641-21423	WASHER	2	SN: 18566-UP
22	01051-61415	BOLT	1	SN: 26818-UP
	01001-61415	BOLT	1	SN: 18566-26817
23	01582-21411	NUT,LOCK	1	SN: 26818-UP
	01501-61408	NUT,LOCK	1	SN: 18566-26817
24	01582-21411	NUT	1	SN: 26818-UP
	01500-61411	NUT	1	SN: 18566-26817
25	6631-11-5920	PLATE,SHELTER	1	SN: 18566-UP
26	07260-04111	HOSE	1	SN: 18566-UP
29	07280-05729	CLAMP	2	SN: 18566-UP

Get the complete PDF catalogue

Komatsu NH-220-CI-1F S/N 18566-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.