




Reference: 101

030010 CYLINDER HEAD


Item	Part No.	Part Name	Qty	Options
	6711-11-1010	CYLINDER HEAD ASS'Y,WITH VALVE	3	SN: 163093-UP
	6710-11-1004	• CYLINDER HEAD A.,VALVE LESS	1	SN: .-UP
	6711-11-1100	• □ CYLINDER HEAD ASS'Y,VALVE LESS	1	SN: 163093-.
1		• ☆ HEAD,CYLINDER	1	SN: 163093-UP
2	6710-11-1311	• • GUIDE	8	SN: 163093-UP
3	6610-11-1140	• • GUIDE	4	SN: 163093-UP
4	6710-11-1120	• • INSERT,EXHAUST VALVE (STD)	4	SN: 163093-UP
	6710-19-1120	• • INSERT ? 0.13MM,EXHAUST VALVE (OS)	4	SN: 163093-UP
	6710-18-1120	• • INSERT ? 0.25MM,EXHAUST VALVE (OS)	4	SN: 163093-UP
	6710-17-1120	• • INSERT ? 0.51MM,EXHAUST VALVE (OS)	4	SN: 163093-UP
	6710-16-1120	• • INSERT ? 0.76MM,EXHAUST VALVE (OS)	4	SN: 163093-UP
	6710-15-1120	• • INSERT ? 1.02MM,EXHAUST VALVE (OS)	4	SN: 163093-UP
5	6711-11-1120	• • INSERT,INTAKE VALVE (STD)	4	SN: 163093-UP
6	6710-11-1130	• • SLEEVE	2	SN: 163093-UP
7	6710-11-3220	• • O-RING (K1)	2	SN: 163093-UP
8	6710-11-1421	• • PLUG	6	SN: 163093-UP
9	02720-40607	• • PLUG	2	SN: .-UP
	02720-20607	• • □ PLUG	2	SN: 163093-.
10	02720-40204	• • PLUG	4	SN: .-UP
	02720-20204	• • □ PLUG	4	SN: 163093-.
11	6710-11-1411	• • PLUG	1	SN: 163093-UP
12	6610-11-1420	• • PIN	2	SN: 163093-UP
13	02720-40104	• • PLUG	2	SN: .-UP
	02720-20104	• • □ PLUG	2	SN: 163093-.
14	6710-11-1431	• • PLUG	2	SN: 163093-UP
15	6712-41-4110	• VALVE,INTAKE	4	SN: 163093-UP
	6710-41-4210	• VALVE,EXHAUST	4	SN: 163093-UP
16	6710-41-4530	• GUIDE	8	SN: 163093-UP
17	6710-41-4410	• SPRING	8	SN: 163093-UP
18	6710-41-4511	• GUIDE	8	SN: 163093-UP
19	6710-41-3910	• COLLET	16	SN: 163093-UP
20	6710-41-5610	CROSSHEAD	12	SN: 163093-UP
21	6610-41-5620	SCREW	12	SN: 163093-UP
22	6710-41-5630	NUT	12	SN: 163093-UP
23	6710-11-1812	GASKET (K1)	3	SN: 194314-UP
	6710-11-1811	□ GASKET (K1)	3	SN: 163093-194313
24	6710-11-1860	• GROMMET	1	SN: 163093-UP
25	6710-11-1830	• RING	1	SN: 163093-UP
26	6710-11-1850	• RING	1	SN: 163093-UP
27	6710-11-1840	GROMMET,OIL (K1)	3	SN: 163093-UP
28	6610-11-1822	GROMMET (K1)	24	SN: 194314-UP
	6610-11-1821	□ GROMMET,WATER	8	SN: 163093-194313
29	6710-71-8310	TUBE	2	SN: 163093-UP
30	6710-71-8320	SCREW	8	SN: 163093-UP
31	6710-71-8330	O-RING (K1)	8	SN: 163093-UP
32	02720-40104	PLUG	4	SN: .-UP
	02720-20104	□ PLUG	4	SN: 163093-.

Item	Part No.	Part Name	Qty	Options
33	6710-11-1610	BOLT	36	SN: 163093-UP
34	6710-11-1650	WASHER	36	SN: 163093-UP
35	6711-11-3011	INJECTOR ASS'Y	6	SN: 163093-UP
36	6710-11-3920	CLAMP	6	SN: 163093-UP
37	6710-11-3910	BOLT	12	SN: 163093-UP

Catalog signs: ☐ part above may be used instead ☆ not supplied separately: assembly only

Reference: 101

ロ ッ カ アーム およびハウジング 適用 号 機
FIG. 103 ROCKER ARM AND HOUSING (ENGINE NO. 163093 -)



Reference: 103

030020 ROCKER ARM AND HOUSING


Item	Part No.	Part Name	Qty	Options
	6710-11-7012	HOUSING ASS'Y,ROCKER ARM	3	SN: 163093-UP
	6710-11-7021	• HOUSING ASS'Y	1	SN: 163093-UP
1		• ☆ HOUSING	1	SN: 163093-UP
2	6710-11-7150	• PLUG	2	SN: 163093-UP
3	6711-11-7330	• SCREW	1	SN: 163093-UP
	6610-41-5020	• SHAFT ASS'Y	1	SN: 163093-UP
4		• ☆ SHAFT	1	SN: 163093-UP
5	6610-41-5220	• PLUG	2	SN: 163093-UP
	6710-41-5031	• ARM ASS'Y,EXHAUST VALVE ? (A)	1	SN: 163093-UP
	6710-41-5041	• ARM ASS'Y,EXHAUST VALVE ? (B)	1	SN: 163093-UP
	6710-41-5070	• ARM ASS'Y,INTAKE VALVE ? (C)	1	SN: 163093-UP
	6710-41-5080	• ARM ASS'Y,INTAKE VALVE ? (D)	1	SN: 163093-UP
	6710-41-5311	• ☆ ARM ASS'Y,EXHAUST ? (A)	1	SN: 163093-UP
	6710-41-5411	• ☆ ARM ASS'Y,EXHAUST ? (B)	1	SN: 163093-UP
	6710-41-5710	• ☆ ARM ASS'Y,INTAKE ? (C)	1	SN: 163093-UP
	6710-41-5810	• ☆ ARM ASS'Y,INTAKE ? (D)	1	SN: 163093-UP
6		• ☆ ARM,EXHAUST ? (A)	1	SN: 163093-UP
7		• ☆ ARM,EXHAUST ? (B)	1	SN: 163093-UP
8		• ☆ ARM,INTAKE ? (C)	1	SN: 163093-UP
9		• ☆ ARM,INTAKE ? (D)	1	SN: 163093-UP
10	6610-41-5330	• BUSHING	1	SN: 163093-UP
11	6710-41-5340	• RIVET,(FOR EXHAUST)	1	SN: 163093-UP
12	6710-41-5360	• NUT	1	SN: 163093-UP
13	6710-41-5351	• SCREW	1	SN: 163093-UP
	6710-41-5050	• ARM ASS'Y	2	SN: 163093-UP
	6710-41-5510	• ARM ASS'Y	1	SN: 163093-UP
14		• ☆ ARM	1	SN: 163093-UP
15	6710-41-5531	• BUSHING	1	SN: 163093-UP
16	6710-41-5540	• SOCKET	1	SN: 163093-UP
17	6710-41-5360	• NUT	1	SN: 163093-UP
18	6710-41-5351	• SCREW	1	SN: 163093-UP
19	6710-11-7810	GASKET (K1)	3	SN: 163093-UP
20	6710-11-7350	BOLT	15	SN: 163093-UP
21	6710-11-7160	WASHER	16	SN: 163093-UP

Item	Part No.	Part Name	Qty	Options
23	02011-70827	BOLT	3	SN: 163093-UP
24	02310-11632	WASHER,SPRING	2	SN: 163093-UP

Catalog signs: ☆ not supplied separately; assembly only

Reference: 103

ロ ッ カ アーム ハウジング カバー 適用 号 機
FIG. 106 ROCKER ARM HOUSING COVER (ENGINE NO. 180214 -)



Reference: 106

030030 ROCKER ARM HOUSING COVER


Item	Part No.	Part Name	Qty	Options
1	6710-11-8120	COVER	1	SN: 163093-UP
2	6711-11-8110	COVER	1	SN: 163093-UP
	6710-11-8201	BREATHER ASS'Y	1	SN: 163093-UP
3	6710-11-8111	• COVER	1	SN: 163093-UP
4	6710-11-8212	• BAFFLE	1	SN: 163093-UP
5	04400-00616	• RIVET	2	SN: 163093-UP
6	6711-11-8810	GASKET (K1)	2	SN: 189936-UP
	6711-11-8810	GASKET (K1)	3	SN: 163093-189935
6A	6710-11-8810	GASKET (K1)	1	SN: 189936-UP
7	02010-70625	BOLT	4	SN: 163093-UP
8	02010-70651	BOLT	6	SN: 163093-UP
9	02010-70616	BOLT	5	SN: 163093-UP
10	02310-11224	WASHER,SPRING	10	SN: 163093-UP
11	02300-11320	WASHER	15	SN: 163093-UP
12	07025-00200	CAP	1	SN: 163093-UP
	6710-21-7400	BREATHER ASS'Y	1	SN: 163093-UP
13	6685-21-7410	• BODY	1	SN: 163093-UP
14	6685-21-7420	• COVER	1	SN: 163093-UP
15	6685-21-7430	• GASKET (K1)	1	SN: 163093-UP
16	02010-70422	• BOLT	3	SN: 163093-UP
17	02310-10916	• WASHER,SPRING	3	SN: 163093-UP
18	02300-10920	• WASHER	3	SN: 163093-UP
19	6710-21-7620	PIPE	1	SN: 163093-UP
20	07000-03020	O-RING (K1)	1	SN: 163093-UP
21	02010-70522	BOLT	2	SN: 163093-UP
22	02310-11020	WASHER,SPRING	2	SN: 163093-UP
23	07260-22090	HOSE	1	SN: 186783-UP
	07261-22011	□ HOSE	1	SN: 180214-186782
	07260-22055	□ HOSE	1	SN: 163093-180213
24	07280-03423	CLAMP	1	SN: 163093-UP
25	6693-22-7640	CLAMP	1	SN: 163093-UP
26	02010-70825	BOLT	1	SN: 163093-UP
27	01602-01338	WASHER,SPRING	1	SN: 163093-UP
28	01640-21323	WASHER	1	SN: 163093-UP

Item	Part No.	Part Name	Qty	Options
29	6710-21-7640	CLIP	1	SN: 163093-UP

Catalog signs: ☐ part above may be used instead

Reference: 106

エアークマニホールドおよびリボンヒーター
FIG. 113 AIR INTAKE MANIFOLD AND RIBBON HEATER
適用機種
(ENGINE NO. 163093 -)



Reference: 113


030040 AIR INTAKE MANIFOLD AND RIBBON HEATER

Item	Part No.	Part Name	Qty	Options
1	6711-11-4160	MANIFOLD,AIR INTAKE	1	SN: 163093-UP
2	600-815-2810	HEATER	3	SN: 163093-UP
3	6610-11-4812	GASKET (K1)	6	SN: 163093-UP
4	02010-70651	BOLT	9	SN: 163093-UP
5	01602-00929	WASHER,SPRING	9	SN: 163093-UP
6	01640-21016	WASHER	9	SN: 163093-UP
7	600-815-2870	HEATER	1	SN: 163093-UP
8	6711-11-4370	CONNECTOR	1	SN: 163093-UP
9	07042-00108	PLUG	1	SN: 163093-UP
10	6645-11-4230	GASKET (K1)	2	SN: 163093-UP
11	02010-70676	BOLT	4	SN: 163093-UP
12	01602-00929	WASHER,SPRING	4	SN: 163093-UP
13	01642-21016	WASHER	4	SN: 163093-UP
14	6711-11-4720	HOSE	1	SN: 163093-UP
15	07281-01029	CLAMP	2	SN: 172662-UP
	07281-01159	☐ CLAMP	2	SN: 163093-172661
16	6678-81-4330	WIRE ? 350MM	2	SN: 163093-UP
17	6678-81-4340	WIRE ? 170MM	2	SN: 163093-UP
18	08038-00519	CAP	8	SN: 163093-UP

Catalog signs: ☐ part above may be used instead

Reference: 113

エキゾースト マニホールド 適用 号 機
FIG. 122 EXHAUST MANIFOLD (ENGINE NO. 163093 -)




Reference: 122

030050 EXHAUST MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6685-11-5111	MANIFOLD,EXHAUST ? REAR	1	SN: 163093-UP
2	6710-11-5120	MANIFOLD,EXHAUST ? CENTER	1	SN: 163093-UP
3	6685-11-5330	STUD	4	SN: 163093-UP
4	6685-11-5341	NUT	4	SN: 163093-UP
5	02720-20206	PLUG	2	SN: 163093-UP
6	6710-11-5111	MANIFOLD,EXHAUST ? FRONT	1	SN: 163093-UP
7	6685-11-5811	GASKET (K1)	6	SN: 163093-UP
8	6610-11-5211	CLAMP	2	SN: 163093-UP
9	02010-80795	BOLT	4	SN: 168050-UP
	6685-11-5360	BOLT	4	SN: 163093-168049
10	02010-80738	BOLT	8	SN: 163093-UP
11	6685-11-5220	PLATE (K1)	6	SN: 163093-UP
12	6685-11-5230	WASHER	8	SN: 163093-UP
13	6711-81-9201	TURBOCHARGER ASS'Y,(SEE FIG.141)	1	SN: 163093-UP
14	6711-81-9510	GASKET (K1)	1	SN: 163093-UP

Reference: 122

ウォーターマニホールド 適用機種
FIG. 131 WATER MANIFOLD (ENGINE NO. 163093 -)




Reference: 131

030060 WATER MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6711-11-6111	MANIFOLD,WATER ? FRONT	1	SN: 163093-UP
2	02720-20810	PLUG	1	SN: 163093-UP
3	02720-40204	PLUG	1	SN: 163093-UP
4	02720-21214	PLUG	1	SN: 163093-UP
5	02720-20607	PLUG	1	SN: 163093-UP
6	6711-11-6120	MANIFOLD,WATER ? CENTER	1	SN: 163093-UP
7	6710-11-6131	MANIFOLD,WATER ? REAR	1	SN: 163093-UP
	6711-14-6140	MANIFOLD,WATER ? REAR ? (A)	1	SN: 163093-UP
8	07043-00415	PLUG	1	SN: 163093-UP
	07043-01019	PLUG,(A)	1	SN: 163093-UP
9	6710-11-6140	COUPLING	1	SN: 163093-UP
10	6712-11-6140	COUPLING	1	SN: 163093-UP
11	02893-05043	O-RING (K1)	4	SN: 163093-UP
12	6710-11-6820	RING (K1)	6	SN: 163093-UP
13	02010-70632	BOLT	12	SN: 163093-UP
14	01602-20929	WASHER,SPRING	12	SN: 163093-UP
15	09482-20000	VALVE	1	SN: 163093-UP
16	6711-11-6231	ELBOW	1	SN: 163093-UP

Reference: 131

サーモスタット 適用機種
FIG. 135 THERMOSTAT (ENGINE NO. 163093 -)



Reference: 135

030070 THERMOSTAT

Item	Part No.	Part Name	Qty	Options
1	6711-11-6411	HOUSING,THERMOSTAT	1	SN: 163093-UP
3	6710-11-6451	SEAL (K1)	1	SN: 163093-UP
4	600-421-6610	THERMOSTAT	1	SN: .-UP
	6610-11-6500	THERMOSTAT	1	SN: 163093-.
5	6711-11-6430	GASKET (K1)	1	SN: 163093-UP
6	02010-70689	BOLT	1	SN: 163093-UP
7	02010-70695	BOLT	3	SN: 163093-UP
8	01602-00929	WASHER,SPRING	4	SN: 163093-UP
9	6711-11-6360	CONNECTOR,WATER ? OUTLET	1	SN: 163093-UP
10	6610-11-6330	GASKET (K1)	2	SN: 163093-UP
11	02010-70632	BOLT	2	SN: 163093-UP
12	01602-00929	WASHER,SPRING	2	SN: 163093-UP
13	6711-11-6380	COVER	1	SN: 163093-UP
14	02010-70625	BOLT	2	SN: 163093-UP
15	01602-00929	WASHER,SPRING	2	SN: 163093-UP

Reference: 135

Get the complete PDF catalogue

Komatsu NT-855-1E S/N 163093-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.