


Fig. 101 エンジン 取付部品
ENGINE MOUNTING PARTS




Reference: 101

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	20M-01-15510	BRACKET	1	SN: 1001-1685
1A	20M-01-15570	BRACKET	1	SN: 1686-UP
1B	20M-01-15580	BRACKET	1	SN: 1686-UP
2	01010-31230	BOLT	6	SN: 1001-UP
3	01602-01236	WASHER,SPRING	6	SN: 1001-UP
4	01640-21223	WASHER	6	SN: 1001-UP
5	20M-01-15530	BRACKET	2	SN: 1001-UP
6	01010-31030	BOLT	6	SN: 1001-UP
7	01602-01030	WASHER,SPRING	6	SN: 1001-UP
8	20M-01-15540	CUSHION	4	SN: 1001-UP
9	20R-01-12140	SPACER	4	SN: 1001-UP
10	20M-01-15550	STOPPER	4	SN: 1001-UP
11	01580-11210	NUT	4	SN: 1001-UP
12	01602-01236	WASHER,SPRING	4	SN: 1001-UP

Reference: 101

Fig. 105 パワー テーク オフ
POWER TAKE OFF




Reference: 105

030020 POWER TAKE OFF

Item	Part No.	Part Name	Qty	Options
1	20M-01-15520	HOUSING	1	SN: 1001-UP
2	01010-30885	BOLT	7	SN: 1001-UP
3	01602-00825	WASHER,SPRING	7	SN: 1001-UP
4	04025-00620	PIN,SPRING	2	SN: 1001-UP
5	20M-01-16610	PLATE	1	SN: 1001-UP
6	20M-01-16620	BOSS	1	SN: 1001-UP
7	20M-01-16630	BOLT	6	SN: 1001-UP
8	20R-01-11210	RUBBER	1	SN: 1001-UP
9	04025-00408	PIN,SPRING	9	SN: 1001-UP
10	01010-31230	BOLT	3	SN: 1001-UP
11	01602-01236	WASHER,SPRING	3	SN: 1001-UP

Reference: 105

Fig. 117 マフラー
MUFFLER




Reference: 117

030030 MUFFLER

Item	Part No.	Part Name	Qty	Options
1	20M-02-11110	MUFFLER	1	SN: 1001-UP
2	01580-00806	NUT	4	SN: 1001-UP
3	01602-00825	WASHER,SPRING	4	SN: 1001-UP
4	20M-02-12210	BRACKET	1	SN: 1001-UP
5	01010-30820	BOLT	2	SN: 1001-UP
6	01602-00825	WASHER,SPRING	2	SN: 1001-UP
7	20M-02-12220	BAND	2	SN: 1001-UP
8	01010-30820	BOLT	4	SN: 1001-UP
9	01602-00825	WASHER,SPRING	4	SN: 1001-UP
10	01643-30823	WASHER	4	SN: 1001-UP
11	01010-30830	BOLT	2	SN: 1001-UP
12	01580-00806	NUT	2	SN: 1001-UP
13	01602-00825	WASHER,SPRING	2	SN: 1001-UP

Reference: 117

Fig. 121
FUEL CONTROL LEVER
フュエル コントロール レバー




Reference: 121

030040 FUEL CONTROL LEVER

Item	Part No.	Part Name	Qty	Options
	20M-43-00042	LEVER ASS'Y	1	SN: 1596-UP
	20M-43-00041	LEVER ASS'Y	1	SN: 1001-1595
1	20M-43-12111	• LEVER	1	SN: 1596-UP
	20M-43-12110	• LEVER	1	SN: 1001-1595
2	113-43-23420	• KNOB	1	SN: 1001-UP
3	20M-43-12120	LEVER	1	SN: 1001-UP
4	FF8733-44530	WASHER	2	SN: 1001-UP
5	101-854-9355	SPRING	2	SN: 1001-UP
6	01583-01610	NUT	2	SN: 1001-UP
7	04205-10616	PIN	1	SN: 1001-UP
8	04050-11610	PIN,COTTER	1	SN: 1001-UP
9	01640-10610	WASHER	1	SN: 1001-UP
10	20M-43-12130	WIRE	1	SN: 1001-UP
11	01252-41275	BOLT	1	SN: 1001-UP
12	20M-43-12210	COLLAR	1	SN: 1001-UP
13	FF8733-44550	SPRING	1	SN: 1001-UP
14	01580-01210	NUT	1	SN: 1001-UP
15	20T-43-11280	BUSHING	1	SN: 1001-UP
16	01016-31035	BOLT	1	SN: 1001-UP
17	01580-01008	NUT	1	SN: 1001-UP

Reference: 121

Fig. 131 ラジエータ および パイピング 適用機種 (Serial No. 1001-1595)
RADIATOR AND PIPING (Serial No. 1001-1595)



Reference: 131


030050 RADIATOR AND PIPING(#1001-1595)

Item	Part No.	Part Name	Qty	Options
	20M-03-11100	RADIATOR ASS'Y	1	SN: 1001-1595
1		• ☆ CORE	1	SN: 1001-1595
2	20M-03-11130	• CAP	1	SN: 1001-@
3	20M-03-11140	• HOSE	1	SN: 1001-@
4	20M-03-11120	SHROUD	1	SN: 1001-@
5	20M-03-11190	NET	1	SN: 1001-@
6	01010-30816	BOLT	4	SN: 1001-@
7	01602-00825	WASHER,SPRING	4	SN: 1001-@
8	01640-20816	WASHER	4	SN: 1001-@
9	20M-03-12210	BRACKET	1	SN: 1001-@
10	20M-03-12220	BRACKET	1	SN: 1001-@
11	01010-31025	BOLT	4	SN: 1001-@
12	01602-01030	WASHER,SPRING	4	SN: 1001-@
13	20R-03-11190	CUSHION	4	SN: 1001-@
14	01580-00806	NUT	4	SN: 1001-@
15	01602-00825	WASHER,SPRING	4	SN: 1001-@
16	01640-20816	WASHER	4	SN: 1001-@
17	20M-03-12240	HOSE	1	SN: 1001-@
18	20M-03-12230	HOSE	1	SN: 1001-@
19	07281-00419	CLAMP	4	SN: 1001-1595
20	07281-00137	CLAMP	4	SN: 1001-1595
21	08034-00536	BAND	1	SN: 1001-1595
22	01010-50816	BOLT	2	SN: 1001-1595
23	01602-20825	WASHER,SPRING	2	SN: 1001-1595

Catalog signs: ☆ not supplied separately: assembly only

Reference: 131

ラジエータ および パイピング 適用機種
Fig. 131A RADIATOR AND PIPING (Serial No. 1596-)



Reference: 131A


030060 RADIATOR AND PIPING(#1596-)

Item	Part No.	Part Name	Qty	Options
	20M-03-11101	RADIATOR ASS'Y	1	SN: 1596-UP
1		• ☆ CORE	1	SN: 1596-UP
2	20M-03-11130	• CAP	1	SN: 1001-UP
3	20M-03-11140	• HOSE	1	SN: 1001-UP
4	20N-03-11181	• PLUG,DRAIN	1	SN: 1596-UP
5	07000-01007	• O-RING	1	SN: 1596-UP
6	07270-00810	• TUBE	1	SN: 1596-UP
7	20M-03-11120	SHROUD	1	SN: 1001-UP
8	20M-03-11190	NET	1	SN: 1001-UP
9	01010-30816	BOLT	4	SN: 1001-UP
10	01602-00825	WASHER,SPRING	4	SN: 1001-UP
11	01640-20816	WASHER	4	SN: 1001-UP
12	20M-03-12210	BRACKET	1	SN: 1001-UP
13	20M-03-12220	BRACKET	1	SN: 1001-UP
14	01010-31025	BOLT	4	SN: 1001-UP
15	01602-01030	WASHER,SPRING	4	SN: 1001-UP
16	20R-03-11190	CUSHION	4	SN: 1001-UP
17	01580-00806	NUT	4	SN: 1001-UP
18	01602-00825	WASHER,SPRING	4	SN: 1001-UP
19	01640-20816	WASHER	4	SN: 1001-UP
20	20M-03-12240	HOSE	1	SN: 1001-UP
21	20M-03-12230	HOSE	1	SN: 1001-UP
22	07280-03826	CLAMP	4	SN: 1596-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 131A

Fig. 141 フュエル タンク および パイピング
FUEL TANK AND PIPING



Reference: 141


030070 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
	20M-04-11100	FUEL TANK ASS'Y	1	SN: 1001-UP
1	20M-04-11110	• TANK,FUEL	1	SN: 1001-UP
2	07050-20920	• CAP ASS'Y	1	SN: 1001-UP
	07091-00920	• CAP ASS'Y,(FOR VANDALISM)	1	SN: 1001-UP
3	07056-16415	• STRAINER	1	SN: 1001-UP
4	07057-03266	• RING	1	SN: 1001-UP
5	07270-01032	• TUBE	1	SN: 1001-UP
6	20R-04-21210	• BALL	1	SN: 1001-UP
7	07281-00167	• CLAMP	2	SN: 1001-UP
8	20M-04-12210	NIPPLE	1	SN: 1001-UP
9	07700-40240	VALVE,DRAIN	1	SN: 1001-UP
10	113-04-22150	NIPPLE	1	SN: 1001-1595
11	07270-01208	TUBE	1	SN: 1001-1595
12	01010-31020	BOLT	4	SN: 1001-UP
13	01602-01030	WASHER,SPRING	4	SN: 1001-UP
14	20M-04-12220	HOSE	1	SN: 1001-UP
15	20M-04-12230	HOSE	1	SN: 1001-UP
16	20M-04-12240	HOSE	1	SN: 1001-UP
17	20M-04-12251	HOSE	1	SN: .-UP
	20M-04-12250	□ HOSE	1	SN: 1001-.
18	20M-04-12260	HOSE	1	SN: 1001-UP
19	07281-00137	CLAMP	10	SN: 1001-UP
20	08034-00310	BAND	1	SN: 1001-UP
21	08034-00414	BAND	1	SN: 1001-UP
22	01010-30865	BOLT	2	SN: 1001-UP
23	01641-20812	WASHER	2	SN: 1001-UP

Catalog signs: □ part above may be used instead

Reference: 141

Fig. 151 バッテリ
BATTERY




Reference: 151

030080 BATTERY

Item	Part No.	Part Name	Qty	Options
1	08000-31206	BATTERY ? WET(46B24R)	1	SN: 1001-UP
	08000-02208	BATTERY ? WET(75D31R) (OP)	1	SN: 1001-UP
2	08000-00000	TERMINAL ? (+)	1	SN: 1001-UP
3	08000-00001	TERMINAL ? (-)	1	SN: 1001-UP
4	01010-30830	BOLT	2	SN: 1001-UP
5	01580-00806	NUT	2	SN: 1001-UP
6	01050-31018	BOLT	2	SN: 1001-UP
7	01640-01016	WASHER	2	SN: 1001-UP
8	FF7820-06170	CAP,TERMINAL	1	SN: 1001-UP
	FF7810-06290	COVER,TERMINAL (OP)	1	SN: 1001-UP
9	FF7820-06180	COVER,TERMINAL	1	SN: 1001-UP
	FF7810-06270	COVER,TERMINAL (OP)	1	SN: 1001-UP
10	FF8732-06410	HOLDER	1	SN: 1001-UP
11	20M-06-11230	RUBBER	1	SN: 1001-1595
12	20M-06-11220	ROD	2	SN: 1001-UP
	FF7810-06210	ROD (OP)	2	SN: 1001-UP
13	01580-00806	NUT	4	SN: 1001-UP

Reference: 151

Fig. 155 インストルメント パネル 適用号機
INSTRUMENT PANEL (Serial No. 1001-1595)




Reference: 155

030090 INSTRUMENT PANEL(#1001-1595)

Item	Part No.	Part Name	Qty	Options
1	20M-06-11110	DASHBOARD	1	SN: 1001-1595
2	01010-30820	BOLT	4	SN: 1001-@
3	01602-00825	WASHER,SPRING	4	SN: 1001-@
4	01643-00823	WASHER	4	SN: 1001-@
5	FF7810-06350	METER,SERVICE	1	SN: 1001-@
6	08086-10000	SWITCH,STARTING	1	SN: 1001-@
7	08043-04000	BOX,FUSE	1	SN: 1001-@
8	08040-02000	FUSE ? 20A	2	SN: 1001-@
9	08040-01000	FUSE ? 10A	2	SN: 1001-@
10	150-06-14290	TERMINAL	1	SN: 1001-@
11	01220-40520	SCREW	2	SN: 1001-@
12	01601-00513	WASHER,SPRING	2	SN: 1001-@
13	20N-06-11120	SWITCH,LAMP	1	SN: 1001-@
14	20M-06-11120	LAMP,BATTERY CHARGE	1	SN: 1001-@
15	20M-06-11120	LAMP,WATER TEMPERATURE	1	SN: 1001-@
16	20M-06-11120	LAMP,OIL CAUTION	1	SN: 1001-@
17	20M-06-11120	LAMP,THERMOSTAT	1	SN: 1001-@

Reference: 155

Fig. 155A インストルメント パネル 適用号機
INSTRUMENT PANEL (Serial No. 1596-)



Reference: 155A

030100 INSTRUMENT PANEL(#1596-)

Item	Part No.	Part Name	Qty	Options
1	20M-06-11111	DASHBOARD	1	SN: 1596-UP
2	01010-30820	BOLT	4	SN: 1001-UP
3	01602-00825	WASHER,SPRING	4	SN: 1001-UP
4	01643-00823	WASHER	4	SN: 1001-UP
5	FF7810-06350	METER,SERVICE	1	SN: 1001-UP
6	08086-10000	SWITCH,STARTING	1	SN: 1001-UP
7	08043-04000	BOX,FUSE	1	SN: 1001-UP
8	08040-02000	FUSE ? 20A	2	SN: 1001-UP
9	08040-01000	FUSE ? 10A	2	SN: 1001-UP
10	150-06-14290	TERMINAL	1	SN: 1001-UP
11	01220-40520	SCREW	2	SN: 1001-UP
12	01601-00513	WASHER,SPRING	2	SN: 1001-UP
13	20N-06-11120	SWITCH,LAMP	1	SN: 1001-UP
14	20M-06-11120	LAMP,BATTERY CHARGE	1	SN: 1001-UP
15	20M-06-11120	LAMP,WATER TEMPERATURE	1	SN: 1001-UP
16	20M-06-11120	LAMP,OIL CAUTION	1	SN: 1001-UP
17	20M-06-11120	LAMP,THERMOSTAT	1	SN: 1001-UP

Reference: 155A

Get the complete PDF catalogue

Komatsu PC05-1 S/N 1001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.