





Reference: 1001

030010 ENGINE MOUNTING PARTS(#5001-5222)

Item	Part No.	Part Name	Qty	Options
1	20W-01-12120	BRACKET	2	SN: 5001-5222
2	20W-01-12110	BRACKET,L.H.	1	SN: 5001-5222
3	20W-01-12130	BRACKET,R.H.	1	SN: 5001-5222
4	01010-51025	BOLT	8	SN: 5001-5222
5	01602-21030	WASHER,SPRING	8	SN: 5001-5222
6	01643-31032	WASHER	8	SN: 5001-5222
7	20M-01-15540	CUSHION	4	SN: 5001-@
8	01580-11210	NUT	8	SN: 5001-@
9	01643-31232	WASHER	8	SN: 5001-@

Reference: 1001




Reference: 1001A

030020 ENGINE MOUNTING PARTS(#5223-)

Item	Part No.	Part Name	Qty	Options
1	20W-01-12121	BRACKET	2	SN: 5223-UP
2	20W-01-12111	BRACKET,L.H.	1	SN: 5223-UP
3	20W-01-12131	BRACKET,R.H.	1	SN: 5223-UP
4	01010-51025	BOLT	12	SN: 5223-UP
5	01602-21030	WASHER,SPRING	12	SN: 5223-UP
6	01643-31032	WASHER	12	SN: 5223-UP
7	20M-01-15540	CUSHION	4	SN: 5001-UP
8	01580-11210	NUT	8	SN: 5001-UP
9	01643-31232	WASHER	8	SN: 5001-UP

Reference: 1001A




Reference: 1011

030030 POWER TAKE OFF

Item	Part No.	Part Name	Qty	Options
	20N-01-43700	COUPLING ASS'Y	1	SN: 5001-UP
1	20N-01-43710	• BOSS	1	SN: 5001-UP
2	20R-01-11210	• RUBBER	1	SN: 5001-UP
3	04025-00408	• PIN, SPRING	6	SN: 5001-UP
4	20M-01-16630	• BOLT	3	SN: 5001-UP
5	20N-01-43251	BOLT	3	SN: 5612-UP
	01252-41035	□ BOLT	3	SN: 5001-5611
6	20W-01-15111	COVER	1	SN: 5321-UP
	20N-01-43510	COVER	1	SN: 5001-5320
7	01010-51020	BOLT	6	SN: 5001-UP
8	01643-31032	WASHER	6	SN: 5001-UP

Catalog signs: □ part above may be used instead

Reference: 1011




Reference: 1101

030040 ENGINE RELATED PARTS

Item	Part No.	Part Name	Qty	Options
1	20M-01-31210	HOSE	1	SN: 5001-UP
2	07280-05429	CLAMP	1	SN: 5001-UP
3	20M-01-48110	HOSE	1	SN: 5001-UP
4	07281-00609	CLAMP	2	SN: 5001-UP
5	20L-02-11113	BRACKET	1	SN: 5001-UP
6	01641-20812	WASHER	1	SN: 5001-UP
7	01580-10806	NUT	1	SN: 5001-UP
8	01010-50816	BOLT	2	SN: 5001-UP
9	01643-30823	WASHER	2	SN: 5001-UP
10	20M-02-48111	PIPE,EXHAUST	1	SN: 5001-UP
11	20N-01-41120	CLAMP	1	SN: 5001-UP
12	01010-50860	BOLT	1	SN: 5001-UP
13	01580-10806	NUT	1	SN: 5001-UP
14	01643-30823	WASHER	2	SN: 5001-UP
15	20M-02-32210	BRACKET	1	SN: 5001-UP
16	01010-50820	BOLT	2	SN: 5001-UP
17	01643-30823	WASHER	2	SN: 5001-UP
18	20N-01-22180	CLAMP	1	SN: 5001-UP
19	01010-51020	BOLT	2	SN: 5001-UP
20	01643-30823	WASHER	2	SN: 5001-UP

Reference: 1101




Reference: 1201

030050 RADIATOR AND PIPING

Item	Part No.	Part Name	Qty	Options
1	20M-03-11111	CORE	1	SN: 5001-UP
2	20M-03-11130	CAP	1	SN: 5001-UP
3	20M-03-11140	HOSE	1	SN: 5001-UP
4	20N-03-11181	PLUG,DRAIN	1	SN: 5001-UP
5	07000-01007	O-RING	1	SN: 5001-UP
6	20M-03-11120	SHROUD	1	SN: 5001-UP
7	01010-30816	BOLT	4	SN: 5001-UP
8	01602-00825	WASHER,SPRING	4	SN: 5001-UP
9	01643-30823	WASHER	4	SN: 5001-UP
10	20M-03-48111	BRACKET	1	SN: 5001-UP
11	20M-03-48121	BRACKET	1	SN: 5001-UP
12	01010-50820	BOLT	4	SN: 5001-UP
13	01643-30823	WASHER	4	SN: 5001-UP
14	01010-50816	BOLT	4	SN: 5001-UP
15	01643-30823	WASHER	4	SN: 5001-UP
16	20M-03-32230	HOSE	1	SN: 5001-UP
17	20M-03-32240	HOSE	1	SN: 5001-UP
18	07280-03826	CLAMP	4	SN: 5001-UP

Reference: 1201




Reference: 1301

030060 FUEL TANK AND PIPING(#5001-5320)

Item	Part No.	Part Name	Qty	Options
1	20W-04-11111	TANK,FUEL	1	SN: 5001-@
2	07056-16415	STRAINER	1	SN: 5001-@
3	20Y-04-11160	CAP	1	SN: 5001-@
4	07270-01022	TUBE	1	SN: 5001-@
5	20R-04-21210	BALL	1	SN: 5001-@
6	07281-00167	CLAMP	2	SN: 5001-@
7	07700-40240	VALVE	1	SN: 5001-@
8	01010-50820	BOLT	4	SN: 5001-@
9	01643-30823	WASHER	4	SN: 5001-@
10	20M-04-31210	BRACKET	1	SN: 5001-@
11	01010-51020	BOLT	2	SN: 5001-@
12	01643-31032	WASHER	2	SN: 5001-@
13	01010-50870	BOLT	1	SN: 5001-@
14	01641-20812	WASHER	1	SN: 5001-@
15	20M-04-48211	HOSE	1	SN: 5001-5320
16	20M-04-32270	HOSE	1	SN: 5001-@
17	20M-04-32251	HOSE	1	SN: 5001-@
18	07281-00137	CLAMP	6	SN: 5001-5320
19	20M-04-48221	HOSE	1	SN: 5001-@
20	07285-00080	CLIP	2	SN: 5001-@
21	08034-00536	BAND	2	SN: 5001-@
22	08034-00519	BAND	2	SN: 5001-5320


Reference: 1301



Reference: 1301A

030070 FUEL TANK AND PIPING(#5321-)

Item	Part No.	Part Name	Qty	Options
1	20W-04-11111	TANK,FUEL	1	SN: 5001-UP
2	07056-16415	STRAINER	1	SN: 5001-UP
3	20Y-04-11160	CAP	1	SN: 5001-UP
4	07270-01022	TUBE	1	SN: 5001-UP
5	20R-04-21210	BALL	1	SN: 5001-UP
6	07281-00167	CLAMP	2	SN: 5001-UP
7	07700-40240	VALVE	1	SN: 5001-UP
8	01010-50820	BOLT	4	SN: 5001-UP
9	01643-30823	WASHER	4	SN: 5001-UP
10	YM129335-55700	WATER SEPARATOR A.	1	SN: 5321-UP
11	01010-50870	BOLT	1	SN: 5321-UP
12	01641-20812	WASHER	1	SN: 5321-UP
13	YM119225-52100	FEED PUMP ASS'Y,FUEL	1	SN: 5321-UP
14	01010-50616	BOLT	2	SN: 5321-UP
15	01641-20608	WASHER	2	SN: 5321-UP
16	20M-04-31210	BRACKET	1	SN: 5001-UP
17	01010-51020	BOLT	2	SN: 5001-UP
18	01643-31032	WASHER	2	SN: 5001-UP
19	01010-50870	BOLT	1	SN: 5001-UP
20	01641-20812	WASHER	1	SN: 5001-UP
21	20M-04-32270	HOSE	1	SN: 5321-UP
22	20W-04-12110	HOSE	1	SN: 5321-UP
23	20M-04-32270	HOSE	1	SN: 5001-UP
24	20M-04-32251	HOSE	1	SN: 5001-UP
25	FF7820-04210	CLAMP	2	SN: 6006-UP
	07281-00137	CLAMP	3	SN: 5321-6005
26	07285-00115	CLIP	5	SN: 6006-UP
	07281-00137	CLAMP	5	SN: 5321-6005
27	20M-04-48221	HOSE	1	SN: 5001-UP
28	07285-00080	CLIP	2	SN: 5001-UP
29	08034-00536	BAND	2	SN: 5001-UP
30	08034-00519	BAND	1	SN: 5321-UP




Reference: 1401

030080 BATTERY

Item	Part No.	Part Name	Qty	Options
1	08000-31206	BATTERY ? WET(46B24R)	1	SN: 5001-UP
2	08000-00000	TERMINAL ? (+)	1	SN: 5001-UP
3	08000-00001	TERMINAL ? (-)	1	SN: 5001-UP
4	20M-06-48410	HOLDER	1	SN: 5001-UP
5	20M-06-48421	ROD	2	SN: 5001-UP
6	01580-10605	NUT	4	SN: 5001-UP
7	01641-20608	WASHER	2	SN: 5001-UP

Reference: 1401



Reference: 1411

030090 INSTRUMENT PANEL

Item	Part No.	Part Name	Qty	Options
1	20W-06-11120	PANEL	1	SN: 5001-UP
2	20S-06-31130	STARTING SWITCH,STARTING	1	SN: 5692-UP
	08086-20000	□ SWITCH,STARTING	1	SN: 5001-5691
3	09415-01008	CAP	1	SN: 5001-UP
4	20M-06-31120	LAMP,COMBINATION	1	SN: 5001-UP
	20M-06-31130	• BULB ? 4W	3	SN: 5001-UP
5	01220-40516	SCREW	2	SN: 5001-UP
6	01601-20513	WASHER,SPRING	2	SN: 5001-UP
7	01580-10504	NUT	2	SN: 5001-UP
8	20S-06-14130	LAMP,THERMOSTAT	1	SN: 5001-UP
	08111-01230	• BULB ? 4W	1	SN: 5001-UP
9	20N-06-41580	METER,SERVICE	1	SN: 5001-UP
10	20M-06-31150	PLUG	1	SN: 5001-UP
11	20N-06-11120	SWITCH,LAMP	1	SN: 5001-UP
12	20R-06-22210	BOX,FUSE	1	SN: 5001-UP
13	01220-40520	SCREW	2	SN: 5001-UP
14	01601-20513	WASHER,SPRING	2	SN: 5001-UP
15	08040-01500	FUSE ? 15A	2	SN: 5321-UP
	08040-01000	FUSE ? 10A	2	SN: 5001-5320
	08040-02000	FUSE ? 20A	2	SN: 5001-UP
16	20N-06-41130	SCREW	6	SN: 5001-UP

Catalog signs: □ part above may be used instead

Reference: 1411

Get the complete PDF catalogue

Komatsu PC05-6 S/N 5001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.