




Reference: B0100-01A1


030010 ENGINE MOUNTING(#10011-11001)

Item	Part No.	Part Name	Qty	Options
1	21T-01-71111	BRACKET,L.H.	2	SN: 10001-@
2	21T-01-71170	BRACKET,R.H.	2	SN: 10001-11001
3	01010-82070	BOLT	16	SN: 10001-@
4	15R-70-16370	WASHER	16	SN: 10001-@
5	04020-01842	PIN	8	SN: 10001-@
6	21T-01-11210	COLLAR	8	SN: 10001-@
7	21T-01-11150	CUSHION	16	SN: 10001-@
8	21T-01-11220	COLLAR	8	SN: 10001-@
9	209-01-51133	STOPPER	4	SN: 10001-@
10	209-01-51142	STOPPER	4	SN: 10001-@
11	21T-01-11180	WASHER	4	SN: 10001-@
12	21T-01-11190	WASHER	4	SN: 10001-@
13	208-01-11181	BOLT	8	SN: 10001-@
14	01643-32460	WASHER	8	SN: 10001-@
15	21T-01-11230	PLATE	4	SN: 10001-@
16	21T-01-11210	COLLAR	4	SN: 10001-@
17	21T-01-11150	CUSHION	8	SN: 10001-@
18	21T-01-11220	COLLAR	4	SN: 10001-@
19	209-01-51133	STOPPER	4	SN: 10001-@
20	209-01-51190	STOPPER	4	SN: 10006-@
21	208-01-11181	BOLT	4	SN: 10001-@
22	01643-32460	WASHER	4	SN: 10001-@
23	21T-01-67330	PLATE	4	SN: 10001-@
24	209-01-51210	SPACER	4	SN: 10006-@
25	209-01-51220	PLATE	4	SN: 10006-@
26	01010-81235	BOLT	16	SN: 10006-@
27	01643-31232	WASHER	16	SN: 10006-@
28	209-01-00020	SHIM ASS'Y	4	SN: 10006-@
28		• ☆ SHIM, 1.0MM	5	SN: 10006-@
28		• ☆ SHIM, 0.5MM	1	SN: 10006-@
29	21T-01-00010	SHIM ASS'Y	2	SN: 10001-@
29		• ☆ SHIM, 0.1MM	9	SN: 10001-@
29		• ☆ SHIM, 0.3MM	6	SN: 10001-@
29		• ☆ SHIM, 0.5MM	6	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
29		• ☆ SHIM, 1.0MM	6	SN: 10001-@

Catalog signs: ☆ not supplied separately: assembly only

Reference: B0100-01A1



00023151

Reference: B0100-01A1A


030020 ENGINE MOUNTING(#11002-)

Item	Part No.	Part Name	Qty	Options
1	21T-01-71111	BRACKET,L.H.	2	SN: 10001-UP
2	21T-01-64220	BRACKET,R.H.	2	SN: 11002-UP
3	01010-82070	BOLT	16	SN: 10001-UP
4	15R-70-16370	WASHER	16	SN: 10001-UP
5	04020-01842	PIN	8	SN: 10001-UP
6	21T-01-11210	COLLAR	8	SN: 10001-UP
7	21T-01-11150	CUSHION	16	SN: 10001-UP
8	21T-01-11220	COLLAR	8	SN: 10001-UP
9	209-01-51133	STOPPER	4	SN: 10001-UP
10	209-01-51142	STOPPER	4	SN: 10001-UP
11	21T-01-11180	WASHER	4	SN: 10001-UP
12	21T-01-11190	WASHER	4	SN: 10001-UP
13	208-01-11181	BOLT	8	SN: 10001-UP
14	01643-32460	WASHER	8	SN: 10001-UP
15	21T-01-11230	PLATE	4	SN: 10001-UP
16	21T-01-11210	COLLAR	4	SN: 10001-UP
17	21T-01-11150	CUSHION	8	SN: 10001-UP
18	21T-01-11220	COLLAR	4	SN: 10001-UP
19	209-01-51133	STOPPER	4	SN: 10001-UP
20	209-01-51190	STOPPER	4	SN: 10006-UP
21	208-01-11181	BOLT	4	SN: 10001-UP
22	01643-32460	WASHER	4	SN: 10001-UP
23	21T-01-67330	PLATE	4	SN: 10001-UP
24	209-01-51210	SPACER	4	SN: 10006-UP
25	209-01-51220	PLATE	4	SN: 10006-UP
26	01010-81235	BOLT	16	SN: 10006-UP
27	01643-31232	WASHER	16	SN: 10006-UP
28	209-01-00020	SHIM ASS'Y	4	SN: 10006-UP
28		• ☆ SHIM, 1.0MM	5	SN: 10006-UP
28		• ☆ SHIM, 0.5MM	1	SN: 10006-UP
29	21T-01-00010	SHIM ASS'Y	2	SN: 10001-UP
29		• ☆ SHIM, 0.1MM	9	SN: 10001-@
29		• ☆ SHIM, 0.3MM	6	SN: 10001-@
29		• ☆ SHIM, 0.5MM	6	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
29		• ☆ SHIM, 1.0MM	6	SN: 10001-@
30	07049-03645	PLUG	8	SN: 11017-UP

Catalog signs: ☆ not supplied separately; assembly only

Reference: B0100-01A1A




PW1C139

Reference: B0100-02A1

030030 ENGINE RELATED PARTS(#10011-11001)

Item	Part No.	Part Name	Qty	Options
1	21T-01-64110	BRACKET	1	SN: 10011-11001
2	01010-81230	BOLT	4	SN: 10001-@
3	01643-31232	WASHER	4	SN: 10001-@
4	6217-21-5610	VALVE	2	SN: 10011-@
4A	07005-02216	SEAL, WASHER, WASHER	2	SN: 10011-@
5	07260-21471	HOSE	1	SN: 10011-@
6	07281-00259	CLAMP	2	SN: 10011-@
7	07261-21419	HOSE	1	SN: 10011-@
8	07281-00259	CLAMP	2	SN: 10011-@
9	08036-03014	CLIP	1	SN: 10001-@
10	01010-81220	BOLT	1	SN: 10001-@
11	01643-31232	WASHER	1	SN: 10001-@
12	07261-22013	HOSE	2	SN: 10001-@
13	07281-00359	CLAMP	2	SN: 10001-@

Reference: B0100-02A1




Reference: B0100-02A1A

030040 ENGINE RELATED PARTS(#11002-)

Item	Part No.	Part Name	Qty	Options
1	21T-01-64111	BRACKET	1	SN: 11002-UP
2	01010-81230	BOLT	4	SN: 10001-UP
3	01643-31232	WASHER	4	SN: 10001-UP
4	6217-21-5610	VALVE	2	SN: 11001-UP
5	07005-02216	SEAL, WASHER,WASHER	2	SN: 11001-UP
6	07260-21471	HOSE	1	SN: 11001-UP
7	07281-00259	CLAMP	2	SN: 11001-UP
8	07261-21419	HOSE	1	SN: 11001-UP
9	07281-00259	CLAMP	2	SN: 11001-UP
10	08036-03014	CLIP	1	SN: 10001-UP
11	01010-81220	BOLT	1	SN: 10001-UP
12	01643-31232	WASHER	1	SN: 10001-UP
13	07261-22013	HOSE	2	SN: 10001-11011
14	07281-00359	CLAMP	2	SN: 10001-11011

Reference: B0100-02A1A




Reference: B0100-02A2

030050 ENGINE RELATED PARTS (COLD WEATHER A SPEC.)(#11002-)

Item	Part No.	Part Name	Qty	Options
1	21T-01-64290	BRACKET	1	SN: 11002-UP
2	01010-81230	BOLT	4	SN: 11002-UP
3	01643-31232	WASHER	4	SN: 11002-UP
4	6217-21-5610	VALVE	2	SN: 11002-UP
5	07005-02216	SEAL, WASHER,WASHER	2	SN: 11002-UP
6	07260-21471	HOSE	1	SN: 11002-UP
7	07281-00259	CLAMP	2	SN: 11002-UP
8	07261-21419	HOSE	1	SN: 11002-UP
9	07281-00259	CLAMP	2	SN: 11002-UP
10	08036-03014	CLIP	1	SN: 11002-UP
11	01010-81220	BOLT	1	SN: 11002-UP
12	01643-31232	WASHER	1	SN: 11002-UP
13	07261-22013	HOSE	2	SN: 11002-11011
14	07281-00359	CLAMP	2	SN: 11002-11011

Reference: B0100-02A2




Reference: B0300-01A2

030060 INTAKE AND EXHAUST (INTAKE)(#10011-11001)

Item	Part No.	Part Name	Qty	Options
1	21T-01-67111	BRACKET	2	SN: 10001-11001
2	01010-81230	BOLT	8	SN: 10001-@
3	01643-31232	WASHER	8	SN: 10001-@
4	21T-01-64170	BRACKET	2	SN: 10011-11001
5	01010-81230	BOLT	4	SN: 10001-@
6	01643-31232	WASHER	4	SN: 10001-@
7	561-02-62500	AIR CLEANER ASS'Y	2	SN: 10001-@
8	6151-11-9970	BAND ASS'Y	2	SN: 10001-@
9	6643-11-4641	BOLT	2	SN: 10001-@
10	600-181-3960	CAP	2	SN: 10001-@
11	561-02-12150	ELBOW	2	SN: 10001-@
12	561-02-62280	CLAMP	4	SN: 10001-@
13	21T-01-64160	CONNECTOR	2	SN: 10011-@
14	21T-01-64150	BRACKET	2	SN: 10011-@
15	01010-81225	BOLT	4	SN: 10001-@
16	01643-31232	WASHER	4	SN: 10001-@
17	21T-62-87870	BAND	4	SN: 10001-@
18	01643-31232	WASHER	8	SN: 10001-@
19	01599-01214	NUT	8	SN: 10001-@
20	600-181-0670	HOSE	2	SN: 10001-@
21	07289-00170	CLAMP,HOSE	4	SN: 10011-@
22	02895-67081	O-RING	4	SN: 10001-@
23	07261-25823	HOSE	2	SN: 10001-@
24	07289-00070	CLAMP	2	SN: 10001-@
25	281-03-11710	CLIP	4	SN: 10002-@
26	203-06-61730	BRACKET	4	SN: 10001-@
27	01010-81225	BOLT	8	SN: 10001-@
28	01643-31232	WASHER	8	SN: 10001-@

Reference: B0300-01A2




Reference: B0300-01A2A

030070 INTAKE AND EXHAUST (INTAKE)(#11002-)

Item	Part No.	Part Name	Qty	Options
1	21T-01-64230	BRACKET	2	SN: 11002-UP
2	01010-81230	BOLT	8	SN: 10001-UP
3	01643-31232	WASHER	8	SN: 10001-UP
4	21T-01-64180	BRACKET	2	SN: 11002-UP
5	01010-81230	BOLT	4	SN: 10001-UP
6	01643-31232	WASHER	4	SN: 10001-UP
7	21T-01-64260	AIR CLEANER,(SEE FIG.Y0010-01A0)	2	SN: 11002-UP
8	6151-11-9970	BAND ASS'Y	2	SN: 10001-UP
9	6643-11-4641	BOLT	2	SN: 10001-UP
10	600-181-3960	CAP	2	SN: 10001-UP
11	561-02-12150	ELBOW	2	SN: 10001-UP
12	561-02-62280	CLAMP	4	SN: 10001-UP
13	21T-01-64160	CONNECTOR	2	SN: 11001-UP
14	21T-01-64150	BRACKET	2	SN: 11001-UP
15	01010-81225	BOLT	4	SN: 10001-UP
16	01643-31232	WASHER	4	SN: 10001-UP
17	21T-62-87870	BAND	4	SN: 10001-UP
18	01643-31232	WASHER	8	SN: 10001-UP
19	01599-01214	NUT	8	SN: 10001-UP
20	600-181-0670	HOSE	2	SN: 10001-UP
21	07289-00170	CLAMP,HOSE	4	SN: 11001-UP
22	02895-67081	O-RING	4	SN: 10001-11005
23	07261-25823	HOSE	2	SN: 10001-UP
24	07289-00070	CLAMP	2	SN: 10001-UP
25	281-03-11710	CLIP	4	SN: 10002-UP
26	203-06-61730	BRACKET	4	SN: 10001-UP
27	01010-81225	BOLT	8	SN: 10001-UP
28	01643-31232	WASHER	8	SN: 10001-UP

Reference: B0300-01A2A



PW1C103

Reference: B0300-02A2

030080 INTAKE AND EXHAUST (EXHAUST)(#10011-11001)

Item	Part No.	Part Name	Qty	Options
1	6211-11-5890	GASKET	1	SN: 10001-@
2	6631-11-5630	SPACER	1	SN: 10001-@
3	01010-81050	BOLT	4	SN: 10002-@
4	01580-11008	NUT	4	SN: 10001-@
5	6136-51-6190	SPACER	2	SN: 10002-@
6	6131-12-5920	SPACER	1	SN: 10002-@
7	209-62-11810	SPACER	1	SN: 10002-@
8	21T-01-67163	PIPE	1	SN: 10001-11001
9	01010-81025	BOLT	2	SN: 10001-@
10	01580-11008	NUT	2	SN: 10002-@
11	01643-31032	WASHER	4	SN: 10001-@
12	21T-01-67191	BRACKET	1	SN: 10001-@
13	21T-01-67231	COVER	1	SN: 10001-@
14	01010-81075	BOLT	2	SN: 10001-@
15	01643-31032	WASHER	2	SN: 10001-@
16	01010-81020	BOLT	1	SN: 10001-@
17	01643-31032	WASHER	1	SN: 10001-@
18	21T-01-67211	COVER	1	SN: 10001-@
19	21T-01-67221	COVER	1	SN: 10001-@
20	01010-81020	BOLT	4	SN: 10001-@
21	01643-31032	WASHER	4	SN: 10001-@
22	6211-11-5890	GASKET	1	SN: 10001-@
23	6631-11-5630	SPACER	1	SN: 10001-@
24	01010-81050	BOLT	4	SN: 10002-@
25	01580-11008	NUT	4	SN: 10001-@
26	6136-51-6190	SPACER	2	SN: 10002-@
27	6131-12-5920	SPACER	1	SN: 10002-@
28	209-62-11810	SPACER	1	SN: 10002-@
29	21T-01-67173	PIPE	1	SN: 10001-11001
30	01010-81025	BOLT	2	SN: 10001-@
31	01580-11008	NUT	2	SN: 10001-@
32	01643-31032	WASHER	4	SN: 10001-@
33	21T-01-67241	BRACKET	1	SN: 10001-@
34	21T-01-67271	COVER	1	SN: 10001-@

Get the complete PDF catalogue

Komatsu PC1800-6 S/N 10001-UP (SAA6D140E-3 (TIER 2) Eng. Installed)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.

Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.