





RKB132070

Reference: A0100-002001

A0100-002001 ENGINE RELATED PARTS, ENGINE ASSEMBLY

Item	Part No.	Part Name	Qty	Options
1	22J-01-55100	ENGINE, ASSEMBLY	1	SN: F10001-UP

Reference: A0100-002001




JY103832

Reference: A0100-002002

A0100-002002 ENGINE RELATED PARTS, BRACKET

Item	Part No.	Part Name	Qty	Options
1	22J-01-25213	BRACKET	1	SN: F10001-UP
2	22J-01-25223	BRACKET	1	SN: F10001-UP
3	22J-01-25340	BOLT	6	SN: F10001-UP
4	01643-31032	WASHER	6	SN: F10001-UP
5	07270-01217	TUBE	1	SN: F10001-UP
6	07285-00130	CLAMP	1	SN: F10001-UP

Reference: A0100-002002




JY102836

Reference: A0100-002003

A0100-002003 ENGINE RELATED PARTS, EXHAUST MUFFLER RELATED PARTS

Item	Part No.	Part Name	Qty	Options
1	203-54-56960	COLLAR	2	SN: F10001-UP
2	22J-01-R5252	PIPE, EXHAUST	1	SN: F10001-UP
3	22J-01-25310	SLEEVE	1	SN: F10001-UP
4	22J-01-R5321	SHEET	1	SN: F10001-UP
5	22J-01-R5331	SHEET	1	SN: F10001-UP
6	22J-01-55410	BRACKET	1	SN: F10001-UP
7	22J-01-55420	SHEET	1	SN: F10001-UP
8	22J-01-55430	BRACKET	1	SN: F10001-UP
9	07289-00035	CLAMP	1	SN: F10001-UP
10	Z781702420	WIRE	8	SN: F10001-UP
11	01010-80816	BOLT	2	SN: F10001-UP
12	01643-30823	WASHER	2	SN: F10001-UP
13	01010-81020	BOLT	4	SN: F10001-UP
14	01643-31032	WASHER	4	SN: F10001-UP
15	01010-81025	BOLT	2	SN: F10001-UP
16	01643-31032	WASHER	2	SN: F10001-UP
17	01597-01009	NUT	2	SN: F10001-UP
18	01643-31032	WASHER	2	SN: F10001-UP
19	07283-33442	CLIP	1	SN: F10001-UP

Reference: A0100-002003




JY105079

Reference: A0100-002004

A0100-002004 ENGINE RELATED PARTS, AIR CLEANER RELATED PARTS

Item	Part No.	Part Name	Qty	Options
1	22J-01-55310	HOSE	1	SN: F10001-UP
2	22J-01-55330	HOSE	1	SN: F10001-UP
3	07289-00055	CLAMP	2	SN: F10001-UP
4	07281-00549	CLAMP	1	SN: F10001-UP

Reference: A0100-002004




JY103838

Reference: A0100-002005

A0100-002005 ENGINE RELATED PARTS, DAMPER

Item	Part No.	Part Name	Qty	Options
1	22J-01-25231	COVER	1	SN: F10001-UP
	22L-01-21700	POWER TAKE OFF, ASSEMBLY	1	SN: F10001-UP
2	22L-01-21710	• RUBBER	1	SN: F10001-UP
3	22L-01-21720	• BOSS	1	SN: F10001-UP
4	04025-00512	• PIN, SPRING	6	SN: F10001-UP
5	01252-71240	• BOLT, HEXAGON SOCKET HEAD	3	SN: F10001-UP
6	01010-80825	BOLT	6	SN: F10001-UP
7	01643-30823	WASHER	6	SN: F10001-UP
8	01010-80835	BOLT	1	SN: F10001-UP
9	01643-30823	WASHER	1	SN: F10001-UP
10	01124-50835	STUD	1	SN: F10001-UP
11	01252-31240	BOLT, HEXAGON SOCKET HEAD	3	SN: F10001-UP
12	01580-10806	NUT	1	SN: F10001-UP
13	01640-20816	WASHER	1	SN: F10001-UP
14	04020-00820	PIN, DOWEL	1	SN: F10001-UP

Reference: A0100-002005




Reference: A0100-002006

A0100-002006 ENGINE RELATED PARTS, BATTERY CABLE

Item	Part No.	Part Name	Qty	Options
1	22J-06-55610	CABLE	1	SN: F10001-UP
2	01010-80816	BOLT	1	SN: F10001-UP
3	01643-30823	WASHER	1	SN: F10001-UP
4	01580-10806	NUT	1	SN: F10001-UP
5	01643-30823	WASHER	1	SN: F10001-UP
6	04434-52108	CLIP	1	SN: F10001-UP
7	07095-20314	RUBBER	1	SN: F10001-UP
8	08038-04030	CAP	1	SN: F10001-UP

Reference: A0100-002006




JY105760

Reference: A0100-002007

A0100-002007 ENGINE RELATED PARTS, WIRING HARNESS

Item	Part No.	Part Name	Qty	Options
1	22J-06-26180	WIRING HARNESS, ALTERNATOR	1	SN: F10001-UP
2	22J-06-35540	BRACKET	1	SN: F10001-UP
3	7861-93-3320	TEMPERATURE SENSOR	1	SN: F10001-UP
4	22J-06-55310	CABLE	1	SN: F10001-UP
5	7875-12-2650	COLLAR	1	SN: F10001-UP
6	01010-80835	BOLT	1	SN: F10001-UP
7	01643-30823	WASHER	1	SN: F10001-UP
8	08193-20010	CLIP	1	SN: F10001-UP
9	01010-80816	BOLT	1	SN: F10001-UP
10	01643-30823	WASHER	1	SN: F10001-UP
11	01580-10605	NUT	1	SN: F10001-UP
12	01640-20610	WASHER	1	SN: F10001-UP
13	08034-40521	BAND	1	SN: F10001-UP
14	08038-10519	CAP	1	SN: F10001-UP

Reference: A0100-002007




JY103867

Reference: A0100-002008

A0100-002008 ENGINE RELATED PARTS, PLUG AND HOSE

Item	Part No.	Part Name	Qty	Options
1	201-62-R1150	PLUG	3	SN: F10001-UP
2	20C-62-32121	TUBE	1	SN: F10001-UP

Reference: A0100-002008



JY103820


Reference: A0100-002009

A0100-002009 ENGINE RELATED PARTS, INNER PARTS, LS VALVE

Item	Part No.	Part Name	Qty	Options
	22J-60-55300	PUMP, ASSEMBLY	1	SN: F10001-UP
	708-1S-03850	•★ VALVE ASSEMBLY, LS	1	SN: F10001-UP
1		••☆ PISTON	1	SN: F10001-UP
2		••☆ SLEEVE	1	SN: F10001-UP
3		••☆ SPOOL	1	SN: F10001-UP
4		••☆ SEAT	1	SN: F10001-UP
5		••☆ SPRING	1	SN: F10001-UP
6		••☆ SEAT	1	SN: F10001-UP
7		••☆ PLUG	1	SN: F10001-UP
8		••☆ O-RING	1	SN: F10001-UP
9		••☆ RING, BACK-UP	1	SN: F10001-UP
10		••☆ NUT	1	SN: F10001-UP
11	07002-62034	•• O-RING	1	SN: F10001-UP
12	708-2L-35690	•• SEAL	1	SN: F10001-UP
13	02896-61008	•• O-RING	1	SN: F10001-UP
14	02789-00210	•• PLUG	1	SN: F10001-UP

Catalog signs: ★ assembly: parts via authorized dealers ☆ not supplied separately: assembly only

Reference: A0100-002009



JY103864

Reference: A0100-002010

A0100-002010 ENGINE RELATED PARTS, INNER PARTS, GEAR PUMP

Item	Part No.	Part Name	Qty	Options
	22J-60-55300	PUMP, ASSEMBLY	1	SN: F10001-UP
	705-49-01140	• GEAR PUMP, ASSEMBLY	1	SN: F10001-UP
1	705-49-82011	••★ BRACKET, ASSEMBLY	1	SN: F10001-UP
1	705-48-80612	•••★ BUSHING, PLANE	2	SN: F10001-UP
2	705-48-80710	••★ PLATE	2	SN: F10001-UP
3	705-48-80730	••★ SEAL	2	SN: F10001-UP
4	705-48-80630	••★ O-RING	1	SN: F10001-UP
5	705-48-80750	•• BOLT	4	SN: F10001-UP
6	01643-50823	•• WASHER	4	SN: F10001-UP
7	705-48-48111	••★ HOUSING, ASSEMBLY	1	SN: F10001-UP
7	705-48-80612	•••★ BUSHING, PLANE	2	SN: F10001-UP
8	04020-00514	••★ PIN, DOWEL	2	SN: F10001-UP
9	705-48-48611	••★ GEAR	1	SN: F10001-UP
10	705-48-48510	••★ GEAR	1	SN: F10001-UP

Catalog signs: ★ assembly: parts via authorized dealers

Reference: A0100-002010

Get the complete PDF catalogue

Komatsu PC18MR-5 S/N F10001 AND UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.