





Reference: A0190-001001

A-002 A0190-001001 DAMPER

Item	Part No.	Part Name	Qty	Options
1	22U-01-21310	DAMPER	1	
2	203-01-51120	PIN	2	
3	01010-81020	BOLT	8	
4	01643-31032	WASHER	8	
5	01010-81050	BOLT	11	
6	01643-31032	WASHER	11	
7	2A6-62-11690	BRACKET	1	
8	01010-81085	BOLT	2	
9	01643-31032	WASHER	2	
10	2A5-06-11362	BRACKET	1	
11	01010-81090	BOLT	1	
12	01643-31032	WASHER	1	
13	22U-62-53960	BREATHER	1	
14	07005-03016	SEAL, WASHER	1	
15	20Y-62-41573	BRACKET	1	

Reference: A0190-001001




Reference: A1009-001001

A-004 A1009-001001 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6755-11-1211	CYLINDER HEAD ASSEMBLY	1	
	NSS	• HEAD, CYLINDER	1	
1	NSS	•• HEAD	1	
2	6754-11-1170	•• INSERT, INTAKE	12	
3	6754-11-1180	•• INSERT, EXHAUST	12	
4	6754-11-1150	•• PLUG, EXPANSION	7	
5	6732-21-1820	•• PLUG, EXPANSION	13	
6	6735-21-5531	•• PLUG, EXPANSION	11	
7	6744-11-1070	•• PLUG, EXPANSION	2	
8	6754-11-1160	•• PLUG, EXPANSION	2	
9	6732-21-1981	• PLUG, PIPE	4	
10	6732-11-1920	• PLUG, PIPE	2	
11	6732-61-2240	• PLUG, PIPE	1	
12	6754-41-4541	SEAL	12	
	6754-41-4100	VALVE KIT, AIR INTAKE	12	
13	6754-41-4110	• VALVE, INTAKE	1	
14	6744-11-1020	• COLLET	2	
15	6754-41-4541	• SEAL	1	
	6754-41-4200	VALVE KIT, EXHAUST	12	
16	6754-41-4210	• VALVE, EXHAUST	1	
17	6744-11-1020	• COLLET	2	
18	6754-41-4440	SPRING	24	
19	6754-41-4510	RETAINER	24	
20	6754-11-1610	BOLT	26	
21	6754-11-1811	GASKET	1	

Reference: A1009-001001




JY108249

Reference: A1009-001001A

A-006 A1009-001001A CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6755-11-1211	CYLINDER HEAD ASSEMBLY	1	
	NSS	• HEAD, CYLINDER	1	
1	NSS	•• HEAD	1	
2	6754-11-1170	•• INSERT, INTAKE	12	
3	6754-11-1180	•• INSERT, EXHAUST	12	
4	6754-11-1150	•• PLUG, EXPANSION	7	
5	6732-21-1820	•• PLUG, EXPANSION	13	
6	6735-21-5531	•• PLUG, EXPANSION	11	
7	6744-11-1070	•• PLUG, EXPANSION	2	
8	6732-21-1981	• PLUG, PIPE	4	
9	6732-11-1920	• PLUG, PIPE	2	
10	6732-61-2240	• PLUG, PIPE	1	
11	6754-41-4541	SEAL	12	
	6754-41-4100	VALVE KIT, AIR INTAKE	12	
12	6754-41-4110	• VALVE, INTAKE	1	
13	6744-11-1020	• COLLET	2	
14	6754-41-4540	• SEAL	1	
	6754-41-4200	VALVE KIT, EXHAUST	12	
15	6754-41-4210	• VALVE, EXHAUST	1	
16	6744-11-1020	• COLLET	2	
17	6754-41-4440	SPRING	24	
18	6754-41-4510	RETAINER	24	
19	6754-11-1610	BOLT	26	
20	6754-11-1811	GASKET	1	

Reference: A1009-001001A




Reference: A1210-001001

A-008 A1210-001001 COOLANT PIPING

Item	Part No.	Part Name	Qty	Options
1	6755-21-7380	JOINT	1	
2	6755-21-7110	O-RING	1	
3	6755-21-7230	JOINT	1	
4	07206-30812	BOLT, JOINT	1	
5	07005-01212	SEAL, WASHER	2	
6	6755-21-7220	PLUG	1	

Reference: A1210-001001




Reference: A1539-001001

A-010 A1539-001001 VARIABLE GEOMETRY TURBOCHARGER (VGT)

Item	Part No.	Part Name	Qty	Options
1	6741-81-8840	STUD	4	
2	6732-81-8820	NUT	4	
	6756-81-8130	TURBOCHARGER KIT	1	
3	NSS	• TURBOCHARGER	1	
4	6755-81-8410	• GASKET	1	
5	6755-81-8941	SENSOR KIT, SPEED	1	
6	6736-81-8410	• SCREW	1	

Reference: A1539-001001




Reference: A1559-001001

A-012 A1559-001001 EXHAUST GAS RE-CIRCULATION (EGR) COOLER

Item	Part No.	Part Name	Qty	Options
	6755-61-7200	EGR COOLER KIT	1	
1	6755-61-7101	• COOLER	1	
2	6216-54-8330	• SEAL	1	
3	6735-21-1970	• O-RING	2	
4	6754-11-5142	• GASKET	1	
5	6755-11-9260	• GASKET	1	
6	6735-21-5680	• O-RING	3	
7	6755-61-7170	• SEAL, WASHER	4	


Reference: A1559-001001



Reference: A2019-001001

A-014 A2019-001001 CYLINDER BLOCK

Item	Part No.	Part Name	Qty	Options
	6755-21-1310	CYLINDER BLOCK	1	
	NSS	• CYLINDER BLOCK ASSEMBLY	1	
	NSS	•• CYLINDER BLOCK	1	
1	6732-21-1831	••• PLUG	4	
	6754-21-1221	••• CAP ASSEMBLY	6	
2	NSS	•••• RING	2	
3	NSS	•••• CAP	1	
	6754-21-1241	••• CAP ASSEMBLY	1	
4	NSS	•••• RING	2	
5	NSS	•••• CAP	1	
6	6732-21-1412	••• BUSHING	2	
7	6732-21-1611	••• BOLT	14	
8	6742-01-1420	••• PLUG, EXPANSION	3	
9	NSS	••• BLOCK ASSEMBLY	1	
10	6732-21-1812	•• PLUG	2	
11	6732-21-1820	•• PLUG, EXPANSION	3	
	6755-21-1320	• BLOCK KIT	1	
12	6732-21-6140	•• RING	2	
13	6754-21-1191	•• NOZZLE	6	
14	6754-21-1180	•• JOINT	6	
15	6754-21-6221	•• PIN, DOWEL	2	
	6560-81-7110	•• PLUG ASSEMBLY	2	
16	NSS	••• PLUG	1	
17	6560-81-7130	••• O-RING	1	
	6732-21-1960	•• PLUG ASSEMBLY	1	
18	NSS	••• PLUG	1	
19	6735-21-1970	••• O-RING	1	
20	6735-21-5530	•• PLUG, EXPANSION	1	
21	6732-21-5530	•• PLUG	3	
22	6742-01-1420	•• PLUG, EXPANSION	1	
23	6732-11-1920	•• PLUG, PIPE	1	
	6735-21-1910	•• PLUG ASSEMBLY	1	
24	NSS	••• PLUG	1	
25	6735-21-1930	••• O-RING	1	



Reference: A2219-001001

A-016 A2219-001001 FLYWHEEL HOUSING

Item	Part No.	Part Name	Qty	Options
1	6736-21-4221	SEAL, REAR	1	
2	6755-21-4110	HOUSING	1	
3	6754-21-4210	SCREW	3	
4	6731-21-6220	BOLT	2	
5	6742-01-5504	BOLT	8	
6	6736-21-5350	BOLT	5	
7	6754-21-4220	SCREW	2	
8	6732-21-4150	PLUG	1	
9	6732-21-4161	O-RING	1	
10	6130-12-1961	SPACER	1	
11	6301-11-4630	PLATE	1	
12	01435-60825	BOLT	1	
13	6736-21-5320	PLUG	1	
14	6732-21-5170	WASHER	1	
15	6732-11-1920	PLUG, PIPE	1	

Reference: A2219-001001



004579

Reference: A2319-001001

Reference: A2319-001001

Reference: A2319-001001

Get the complete PDF catalogue

Komatsu PC210LCI-11 SN A10001-up

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.