


123102 111 3918 15108




2108

Reference: A1009-001001

A-002 A1009-001001 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6757-11-1210	HEAD ASSEMBLY	1	
1	6754-11-1150	• PLUG, EXPANSION	5	
2	6732-21-1820	• PLUG, EXPANSION	9	
3	6735-21-5531	• PLUG, EXPANSION	7	
4	6754-11-1170	• INSERT, INTAKE	8	
5	6757-11-1180	• INSERT, EXHAUST	8	
6	6744-11-1070	• PLUG, EXPANSION	1	
7	6754-11-1160	• PLUG, EXPANSION	2	
8	NSS	• HEAD, CYLINDER	1	
9	6732-21-1981	• PLUG, PIPE	2	
10	6732-11-1920	• PLUG, PIPE	3	
11	6732-61-2240	• PLUG, PIPE	1	
	6216-14-6820	• PLUG ASSEMBLY	1	
12	NSS	• • PLUG	1	
13	6216-14-6860	• • O-RING	1	
	6757-41-4100	VALVE KIT, INTAKE	8	
14	NSS	• VALVE, INTAKE	1	
15	6744-11-1020	• COLLET	2	
16	6754-41-4540	• SEAL	1	
	6754-41-4200	VALVE KIT, EXHAUST	8	
17	NSS	• VALVE, EXHAUST	1	
18	6744-11-1020	• COLLET	2	
19	6754-41-4540	• SEAL	1	
20	6754-41-4440	SPRING	16	
21	6754-41-4510	RETAINER	16	
22	6754-11-1610	BOLT	18	
23	6751-11-1810	GASKET	1	

Reference: A1009-001001




Reference: A1539-001001

A-004 A1539-001001 TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
1	6753-81-8810	STUD	4	
2	6746-11-5580	NUT	4	
	6757-81-8490	TURBOCHARGER KIT	1	
3	NSS	• TURBOCHARGER	1	
4	6736-11-5710	• GASKET	1	
5	6751-11-4390	• O-RING	1	
6	6753-61-7160	• SEAL, WASHER	6	
7	6751-51-7690	• GASKET	1	
8	6737-51-8760	• SEAL, WASHER	2	
9	6737-51-8770	• O-RING	1	
10	6732-81-8860	• O-RING	2	
11	6735-21-4160	• O-RING	1	
12	6738-54-8110	• SEAL	1	
13	6732-51-8330	• SEAL	2	
14	6560-81-7130	• O-RING	1	

Reference: A1539-001001

1




201405

Reference: A1570-001001

A-006 A1570-001001 COVER

Item	Part No.	Part Name	Qty	Options
1	6753-11-9130	COVER	1	

Reference: A1570-001001



Reference: A2019-001001


A-008 A2019-001001 CYLINDER BLOCK

Item	Part No.	Part Name	Qty	Options
	6757-21-1330	CYLINDER BLOCK	1	
1	NSS	• CYLINDER BLOCK	1	
2	6732-21-1812	•• PLUG, EXPANSION	2	
	NSS	•• BLOCK ASSEMBLY	1	
3	6732-21-1831	••• PLUG	4	
4	6732-21-1820	••• PLUG, EXPANSION	1	
5	6754-21-1221	••• CAP ASSEMBLY	4	
6	6754-21-1241	••• CAP ASSEMBLY	1	
7	6732-21-1412	••• BUSHING	2	
8	6732-21-1611	••• BOLT	10	
9	6756-21-5520	••• PLUG, EXPANSION	2	
	6757-21-1340	• BLOCK KIT, CYLINDER	1	
10	6732-21-6140	•• RING	2	
11	6754-21-1191	•• NOZZLE, PISTON COOLING	4	
12	6754-21-1180	•• JOINT	4	
13	6754-21-6221	•• PIN, DOWEL	2	
	6216-14-6830	•• PLUG ASSEMBLY	1	
14	NSS	••• PLUG	1	
15	6216-14-6840	••• SEAL	1	
	6735-21-1910	•• PLUG ASSEMBLY	1	
16	NSS	••• PLUG	1	
17	6735-21-1930	••• O-RING	1	
	6732-21-1960	•• PLUG ASSEMBLY	1	
18	NSS	••• PLUG	1	
19	6735-21-1970	••• O-RING	1	
20	6732-21-5530	•• PLUG	3	

F1 - THIS INDICATES A PART SUPPLIED AS SEMI-FINISHED. IT REQUIRES ADDITIONAL WORK BEFORE INSTALLATION.

Reference: A2019-001001

7345 7 51 4 2 981012
IFW



7180


Reference: A2219-001001

A-010 A2219-001001 FLYWHEEL HOUSING

Item	Part No.	Part Name	Qty	Options
1	6735-K2-3002	SEAL, REAR	1	
	6208-29-1230	SEAL, WITH SLEEVED SEAL	1	
2	6755-21-4110	HOUSING	1	
3	6754-21-4210	SCREW	3	
4	6731-21-6220	BOLT	2	
5	6742-01-5504	BOLT	8	
6	6736-21-5350	BOLT	5	
7	6754-21-4220	SCREW	2	
8	6732-21-4150	PLUG	1	
9	6732-21-4161	O-RING	1	
10	6130-12-1961	SPACER	1	
11	6301-11-4630	PLATE	1	
12	01435-60825	BOLT, FLANGED	1	
13	6736-21-5320	PLUG	1	
14	6732-21-5170	WASHER	1	

Reference: A2219-001001

4 1 6 876 523




2185

Reference: A2319-001001

A-012 A2319-001001 CRANKSHAFT

Item	Part No.	Part Name	Qty	Options
	6757-01-1310	CRANKSHAFT ASSEMBLY	1	
1	6732-21-6150	• PIN, DOWEL	1	
2	NSS	• CRANKSHAFT	1	
3	6754-31-1190	• • COLLAR	1	
4	6754-31-1330	• • GEAR	1	
5	6754-31-1340	• • GEAR	1	
	6751-22-8100	BEARING ASSEMBLY, MAIN	1	
6	NSS	• BEARING, UPPER	4	
7	NSS	• BEARING, LOWER	5	
8	NSS	• BEARING, THRUST	1	

Reference: A2319-001001




Reference: A2359-001001

A-014 A2359-001001 PISTON AND CONNECTING ROD

Item	Part No.	Part Name	Qty	Options
	6757-31-2100	PISTON KIT	4	
	6757-31-2010	• RING ASSEMBLY, PISTON	1	
1	NSS	• • RING, OIL	1	
2	NSS	• • RING, TOP	1	
3	NSS	• • RING, SECOND	1	
4	6757-31-2110	• PISTON	1	
5	6732-31-2420	• RING	2	
6	6754-31-2410	PIN	4	
	6755-31-3110	CONNECTING ROD ASSEMBLY	4	
7	6732-31-3320	• SCREW	2	
8	6755-31-3120	• BUSHING	1	
9	NSS	• ROD, CONNECTING	1	
10	6754-32-3410	BEARING, UPPER, STANDARD	4	
	6754-32-3420	BEARING, UPPER, UNDERSIZE, 0.25MM	4	
	6754-32-3430	BEARING, UPPER, UNDERSIZE, 0.50MM	4	
	6754-32-3440	BEARING, UPPER, UNDERSIZE, 0.75MM	4	
	6754-32-3450	BEARING, UPPER, UNDERSIZE, 1.00MM	4	
11	6732-31-3420	BEARING, LOWER, STANDARD	4	
	6738-39-3400	BEARING, LOWER, UNDERSIZE, 0.25MM	4	
	6738-38-3400	BEARING, LOWER, UNDERSIZE, 0.50MM	4	
	6738-37-3400	BEARING, LOWER, UNDERSIZE, 0.75MM	4	
	6738-36-3400	BEARING, LOWER, UNDERSIZE, 1.00MM	4	

F1 - THIS INDICATES A PART SUPPLIED AS SEMI-FINISHED. IT REQUIRES ADDITIONAL WORK BEFORE INSTALLATION.

Reference: A2359-001001




000

Reference: A3110-001001

A-016 A3110-001001 ENGINE OIL HOSE COVER

Item	Part No.	Part Name	Qty	Options
1	6208-51-5890	COVER	2	
2	08034-20519	BAND	2	

Reference: A3110-001001




Reference: A4019-001001

A-018 A4019-001001 FUEL SUPPLY PUMP

Item	Part No.	Part Name	Qty	Options
1	6755-71-1010	PUMP ASSEMBLY	1	
	6755-71-1310	• PUMP	1	
	6754-71-1320	•• O-RING	1	
	6755-71-1230	•• O-RING	1	
	6755-71-1240	•• O-RING	1	
	6755-71-1910	•• ACTUATOR	1	
2	6754-71-3110	• GEAR	1	
3	6754-71-1351	• WASHER, SPRING	1	
4	6754-71-1340	• NUT	1	
5	6754-71-3131	STUD	3	
6	6751-71-3130	NUT	3	

Reference: A4019-001001

5



210207

Reference: A4219-001001

A-020 A4219-001001 FUEL INJECTOR

Item	Part No.	Part Name	Qty	Options
1	6755-11-3100	INJECTOR	4	
2	6754-11-3130	• GASKET	1	
3	6754-11-3140	• O-RING	1	
4	6742-01-2630	BOLT	8	
5	6755-11-3110	CLAMP	4	

Reference: A4219-001001

Get the complete PDF catalogue

Komatsu PC220LC-12 S/N A10001

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.