


FIG. 101 CYLINDER HEAD



Reference: 101

030010 CYLINDER HEAD


Item	Part No.	Part Name	Qty	Options
	6137-12-1011	CYLINDER HEAD ASSEMBLY, WITH VALVE	1	SN: 50007-UP
	6137-12-1010	□ CYLINDER HEAD ASSEMBLY, WITH VALVE	1	SN: 50001-50006
	6137-11-1011	CYLINDER HEAD ASSEMBLY, WITH VALVE	1	SN: 10001-49999
	6137-11-1010	□ CYLINDER HEAD ASSEMBLY, WITH VALVE	1	SN: 10001-49999
	6137-12-1101	• CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 50007-UP
	6137-12-1100	• □ CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 50001-50006
	6137-11-1201	• CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 10841-49999
	6137-11-1200	• □ CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 10001-10840
1		• ☆ HEAD,CYLINDER	1	SN: 50007-UP
1		• ☆ HEAD,CYLINDER	1	SN: 50001-50006
1		• ☆ HEAD,CYLINDER	1	SN: 10001-49999
2	6136-11-1130	• SLEEVE	6	SN: 10001-UP
3	6136-12-1310	• SEAT, INTAKE VALVE (STD)	6	SN: 50001-UP
3	6136-11-1311	• SEAT, INTAKE VALVE (STD)	6	SN: 10841-49999
3	6136-11-1310	• □ SEAT, INTAKE VALVE (STD)	6	SN: 10001-10840
3	6136-19-1410	• SEAT, 0.25MM, INTAKE VALVE (OS)	6	SN: 50001-UP
3	6136-19-1311	• SEAT, 0.25MM, INTAKE VALVE (OS)	6	SN: 10841-49999
3	6136-19-1310	• □ SEAT, 0.25MM, INTAKE VALVE (OS)	6	SN: 10001-10840
3	6136-18-1410	• SEAT, 0.50MM, INTAKE VALVE (OS)	6	SN: 50001-UP
3	6136-18-1311	• SEAT, 0.50MM, INTAKE VALVE (OS)	6	SN: 10841-49999
3	6136-18-1310	• □ SEAT, 0.50MM, INTAKE VALVE (OS)	6	SN: 10001-10840
3	6136-17-1410	• SEAT, 0.75MM, INTAKE VALVE (OS)	6	SN: 50001-UP
3	6136-17-1311	• SEAT, 0.75MM, INTAKE VALVE (OS)	6	SN: 10841-49999
3	6136-17-1310	• □ SEAT, 0.75MM, INTAKE VALVE (OS)	6	SN: 10001-10840
3	6136-16-1410	• SEAT, 1.00MM, INTAKE VALVE (OS)	6	SN: 50001-UP
3	6136-16-1311	• SEAT, 1.00MM, INTAKE VALVE (OS)	6	SN: 10841-49999
3	6136-16-1310	• □ SEAT, 1.00MM, INTAKE VALVE (OS)	6	SN: 10001-10840
4	6136-12-1320	• SEAT, EXHAUST VALVE (STD)	6	SN: 50001-UP
4	6136-11-1321	• SEAT, EXHAUST VALVE (STD)	6	SN: 10841-49999
4	6136-11-1320	• □ SEAT, EXHAUST VALVE (STD)	6	SN: 10001-10840
4	6136-19-1420	• SEAT, 0.25MM, EXHAUST VALVE (OS)	6	SN: 50001-UP
4	6136-19-1321	• SEAT, 0.25MM, EXHAUST VALVE (OS)	6	SN: 10841-49999
4	6136-19-1320	• □ SEAT, 0.25MM, EXHAUST VALVE (OS)	6	SN: 10001-10840
4	6136-18-1420	• SEAT, 0.50MM, EXHAUST VALVE (OS)	6	SN: 50001-UP
4	6136-18-1321	• SEAT, 0.50MM, EXHAUST VALVE (OS)	6	SN: 10841-49999
4	6136-18-1320	• □ SEAT, 0.50MM, EXHAUST VALVE (OS)	6	SN: 10001-10840
4	6136-17-1420	• SEAT, 0.75MM, EXHAUST VALVE (OS)	6	SN: 50001-UP
4	6136-17-1321	• SEAT, 0.75MM, EXHAUST VALVE (OS)	6	SN: 10841-49999
4	6136-17-1320	• □ SEAT, 0.75MM, EXHAUST VALVE (OS)	6	SN: 10001-10840
4	6136-16-1420	• SEAT, 1.00MM, EXHAUST VALVE (OS)	6	SN: 50001-UP
4	6136-16-1321	• SEAT, 1.00MM, EXHAUST VALVE (OS)	6	SN: 10841-49999
4	6136-16-1320	• □ SEAT, 1.00MM, EXHAUST VALVE (OS)	6	SN: 10001-10840
5	6136-19-1430	• GUIDE, VALVE	12	SN: 50001-UP
5	6136-19-1330	• GUIDE, VALVE	12	SN: 10001-49999
6	07046-42816	• PLUG	13	SN: 10001-UP
7	07046-44016	• PLUG	4	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
8	07043-50108	•• PLUG	7	SN: .-UP
8	07043-00108	•• ☐ PLUG	7	SN: 10001-
9	6136-42-4110	• VALVE, INTAKE	6	SN: 50001-UP
9	6136-41-4110	• VALVE, INTAKE	6	SN: 10001-49999
10	6136-42-4210	• VALVE,EXHAUST	6	SN: 50001-UP
10	6136-41-4210	• VALVE,EXHAUST	6	SN: 10001-49999
11	6136-42-4410	• SPRING, VALVE	12	SN: 50001-UP
11	6136-41-4410	• SPRING, VALVE	12	SN: 10001-49999
12	6136-42-4510	• GUIDE, SPRING	12	SN: 50001-UP
12	6136-41-4510	• GUIDE, SPRING	12	SN: 10001-49999
13	6136-42-4520	• COTTER, VALVE	24	SN: 50001-UP
13	6136-41-4520	• COTTER, VALVE	24	SN: 10001-49999
14	6136-41-4530	• SEAT, SPRING	12	SN: 10001-UP
15	6136-11-1812	GASKET (K1)	1	SN: .-UP
15	6136-11-1811	☐ GASKET (K1)	1	SN: 14329-
15	6136-11-1810	☐ GASKET (K1)	1	SN: 10001-14328
16	6136-12-1610	BOLT	26	SN: 50001-UP
16	6136-11-1610	BOLT	26	SN: 10001-49999
17	6138-11-1620	WASHER	26	SN: 11387-49999
17	6110-11-1620	☐ WASHER	26	SN: 10001-11386
18	6136-11-1910	HANGER, FRONT	1	SN: 10001-UP
19	6136-11-1821	GASKET (K1)	1	SN: 11387-UP
19	6136-11-1820	☐ GASKET (K1)	1	SN: 10001-11386
20	6136-11-1920	HANGER, REAR	1	SN: 10001-UP
21	01010-31025	BOLT	2	SN: 10001-UP
22	01602-01030	WASHER, SPRING	2	SN: 10001-UP

Catalog signs: ☐ part above may be used instead ☆ not supplied separately: assembly only

Reference: 101

FIG. 103 ROCKER ARM



Reference: 103


030020 ROCKER ARM

Item	Part No.	Part Name	Qty	Options
	6136-42-5100	ROCKER ARM ASSEMBLY	1	SN: 50001-UP
	6136-41-5100	ROCKER ARM ASSEMBLY	1	SN: 10001-49999
1	6136-42-5110	• BRACKET	1	SN: 50001-UP
1	6136-41-5110	• BRACKET	1	SN: 10001-49999
2	6136-42-5120	• BRACKET	5	SN: 50001-UP
2	6136-41-5120	• BRACKET	5	SN: 10001-49999
	6136-42-5020	• SHAFT ASSEMBLY	1	SN: 50001-UP
	6136-41-5020	• ROCKER ARM SHAFT ASSEMBLY	1	SN: 10001-49999
3		• ☆ SHAFT	1	SN: 50001-UP
3		• ☆ SHAFT	1	SN: 10001-49999
4	6142-42-5550	• PLUG	2	SN: 10001-UP
5	6136-42-5130	• ARM, ROCKER	12	SN: 50001-UP
5	6136-41-5510	• ARM, ROCKER	12	SN: 10001-49999
6	6136-42-5140	• SCREW, ADJUST	12	SN: 50001-UP
6	6142-42-5440	• SCREW, ADJUST	12	SN: 10001-49999
7	01580-00806	• NUT, LOCK	12	SN: 10001-UP
8	6136-41-5310	• SPRING, ROCKER	5	SN: 10001-UP
9	6136-41-5320	• SPRING, CONICAL	2	SN: 10001-UP
10	6136-41-5330	• CLIP	2	SN: 10001-UP
11	6136-41-5131	STUD	4	SN: 10039-UP
11	6136-41-5130	STUD	4	SN: 10001-10038
12	01010-31280	BOLT	2	SN: 10001-UP
13	01602-01236	WASHER, SPRING	6	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 103

シリンダヘッドカバー 適用 図
FIG. 105 CYLINDER HEAD COVER (ENGINE NO.10001-49999)




Reference: 105

030030 CYLINDER HEAD COVER (#10001-49999)

Item	Part No.	Part Name	Qty	Options
1	6136-11-8111	COVER, HEAD	1	SN: 11250-49999
1	6136-11-8110	COVER, HEAD	1	SN: 10001-11249
2	6136-11-8812	O RING (K1)	1	SN: .-@
2	6136-11-8811	□ O RING (K1)	1	SN: 11250-.
2	6136-11-8810	O RING (K1)	1	SN: 10001-11249
3	6136-11-8120	NAT	4	SN: 10001-@
4	6136-11-8130	WASHER	4	SN: 10001-@
5	6136-11-8142	PACKING (K1)	4	SN: 11370-@
5	6136-11-8141	□ PACKING (K1)	4	SN: 10451-11369
5	6136-11-8140	□ PACKING (K1)	4	SN: 10001-10450
6	6130-12-8610	CAP	1	SN: 10001-49999
	6685-21-7400	BREATHER ASSEMBLY	1	SN: 10001-@
7	6685-21-7410	• BODY	1	SN: 10001-@
8	6685-21-7440	• SCREEN	4	SN: 10001-@
9	6685-21-7460	• BAFFLE	1	SN: 10001-@
10	6685-21-7420	• COVER	1	SN: 10001-@
11	6685-21-7430	• GASKET (K1)	1	SN: 10001-@
12	02010-70422	• BOLT	3	SN: .-@
12	02010-30422	• □ BOLT	3	SN: 10001-.
13	02310-10916	• WASHER, SPRING	3	SN: 10001-@
14	02300-10920	• WASHER	3	SN: 10001-@
15	6136-21-7630	PIPE, BREATHER	1	SN: 11250-@
15	6136-21-7610	PIPE, BREATHER	1	SN: 10001-11249
16	07000-03020	O RING (K1)	1	SN: 10001-@
17	02010-70522	BOLT	2	SN: 10001-@
18	01602-00825	WASHER, SPRING	2	SN: 10001-@
19	6136-11-8851	HOSE, BREATHER	1	SN: .-@
19	6136-11-8850	□ HOSE, BREATHER	1	SN: 11250-.
19	6137-11-8890	HOSE, BREATHER	1	SN: 10001-11249
20	07280-02523	CLAMP	1	SN: 10001-@
21	6600-01-5950	CLIP	1	SN: 10039-@

Catalog signs: □ part above may be used instead

シリンダヘッドカバー 適用 写真
FIG. 105A CYLINDER HEAD COVER (ENGINE NO.50001-)




Reference: 105A

030040 CYLINDER HEAD COVER(#50001-)

Item	Part No.	Part Name	Qty	Options
1	6136-11-8150	COVER, HEAD	1	SN: 50001-UP
2	6136-11-8812	O RING (K1)	1	SN: .-UP
3	6136-11-8120	NAT	4	SN: 10001-UP
4	6136-11-8130	WASHER	4	SN: 10001-UP
5	6136-11-8142	PACKING (K1)	4	SN: 11370-UP
	6685-21-7400	BREATHER ASSEMBLY	1	SN: 10001-UP
6	6685-21-7410	• BODY	1	SN: 10001-UP
7	6685-21-7440	• SCREEN	4	SN: 10001-UP
8	6685-21-7460	• BAFFLE	1	SN: 10001-UP
9	6685-21-7420	• COVER	1	SN: 10001-UP
10	6685-21-7430	• GASKET (K1)	1	SN: 10001-UP
11	02010-70422	• BOLT	3	SN: .-UP
12	02310-10916	• WASHER, SPRING	3	SN: 10001-UP
13	02300-10920	• WASHER	3	SN: 10001-UP
14	6136-21-7630	PIPE	1	SN: 11250-UP
15	07000-03020	O RING (K1)	1	SN: 10001-UP
16	02010-70522	BOLT	2	SN: 10001-UP
17	01602-00825	WASHER, SPRING	2	SN: 10001-UP
18	6136-11-8851	HOSE, BREATHER	1	SN: .-UP
19	07280-02523	CLAMP	1	SN: 10001-UP
20	6600-01-5950	CLIP	1	SN: 10039-UP

Reference: 105A

FIG. 111 エアインテークマニホールド 適用 考 機
FIG. 111 AIR INTAKE MANIFOLD (ENGINE NO.10001-17811)



Reference: 111

030050 AIR INTAKE MANIFOLD(#10001-17811)


Item	Part No.	Part Name	Qty	Options
1	6136-11-4110	MANIFOLD, INTAKE	1	SN: 10001-17811
2	600-815-2350	HEATER, COIL	2	SN: 10001-@
3	07003-02228	• GASKET (K1)	1	SN: 10001-@
4	6136-11-4811	GASKET (K1)	1	SN: 11387-@
4	6136-11-4810	□ GASKET (K1)	1	SN: 10001-11386
5	01010-30865	BOLT	10	SN: 10001-@
6	01010-30850	BOLT	2	SN: 10001-@
7	01602-00825	WASHER, SPRING	12	SN: 10001-@
8	01640-00816	WASHER	12	SN: 10001-@
9	6137-11-4311	CONNECTOR, AIR	1	SN: 10001-@
10	600-815-2341	HEATER, RIBBON	1	SN: 12036-@
10	600-815-2340	□ HEATER, RIBBON	1	SN: 10001-12035
11	6136-11-4820	GASKET (K1)	2	SN: 10001-@
12	01010-30870	BOLT	3	SN: 10001-17811
13	01010-30875	BOLT	1	SN: 10001-@
14	01602-00825	WASHER, SPRING	4	SN: 10001-@
15	01640-20816	WASHER	4	SN: 10001-@
16	07042-00108	PLUG	2	SN: 10001-@
17	6137-11-4371	HOSE	1	SN: 11250-@
17	6137-11-4370	□ HOSE	1	SN: 10001-11249
18	07281-00709	CLAMP	2	SN: 10001-@
19	6136-81-4111	PLATE	1	SN: 10027-@
19	6136-81-4110	□ PLATE	1	SN: 10001-10026
20	600-815-2170	SWITCH, RELAY	1	SN: 10001-@
20	600-815-2360	□ SWITCH, RELAY	1	SN: 10001-17811
21	01010-30620	BOLT	2	SN: 10001-@
22	01580-00605	NAT	2	SN: 10001-@
23	01602-00619	WASHER, SPRING	2	SN: 10001-@
24	01641-00608	WASHER	4	SN: 10001-@
25	6136-81-4210	WOW	1	SN: 10001-@
26	6136-81-4220	WOW	1	SN: 10001-@
27	6136-81-4230	WOW	1	SN: 10001-@
28	6136-81-4240	WOW	1	SN: 10001-@
29	08036-11210	CLIP	1	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
30	08036-10814	CLIP	2	SN: .-@
31	07042-00415	PLUG	1	SN: 10001-@

Catalog signs: ☐ part above may be used instead

Reference: 111

エアークマニホルド 適用 機種
FIG. 111A AIR INTAKE MANIFOLD (ENGINE NO.17812-)



Reference: 111A

030060 AIR INTAKE MANIFOLD(#17812-)

Item	Part No.	Part Name	Qty	Options
1	6136-11-4123	MANIFOLD, INTAKE	1	SN: 18345-UP
1	6136-11-4122	MANIFOLD, INTAKE	1	SN: 17812-18344
2	6136-11-4890	SPACER	1	SN: 17812-18344
3	6136-11-4880	GASKET	1	SN: 17812-18344
4	6136-11-4811	GASKET (K1)	1	SN: 11387-UP
5	01010-30865	BOLT	10	SN: 10001-UP
6	01010-30850	BOLT	2	SN: 10001-UP
7	01602-00825	WASHER, SPRING	12	SN: 10001-UP
8	01640-00816	WASHER	12	SN: 10001-UP
9	600-815-2341	HEATER, RIBBON	1	SN: 12036-UP
10	6137-11-4311	CONNECTOR, AIR	1	SN: 10001-UP
11	07042-00108	PLUG	2	SN: 10001-UP
12	07042-00415	PLUG	1	SN: 10001-UP
13	6136-11-4820	GASKET (K1)	2	SN: 10001-UP
14	01010-30870	BOLT	3	SN: 18345-UP
14	01010-30875	BOLT	3	SN: 17812-18344
15	01010-30875	BOLT	1	SN: 10001-UP
16	01602-00825	WASHER, SPRING	4	SN: 10001-UP
17	01640-20816	WASHER	4	SN: 10001-UP
18	6137-11-4371	HOSE	1	SN: 11250-UP
19	07281-00709	CLAMP	2	SN: 10001-UP
20	600-815-2350	HEATER, COIL	2	SN: 10001-UP
21	07003-02228	• GASKET (K1)	1	SN: 10001-UP
22	6136-81-4111	PLATE	1	SN: 10027-UP
23	600-815-2170	SWITCH, HEATER	1	SN: 17812-UP
24	01010-30620	BOLT	2	SN: 10001-UP
25	01580-00605	NAT	2	SN: 10001-UP
26	01602-00619	WASHER, SPRING	2	SN: 10001-UP
27	01641-00608	WASHER	4	SN: 10001-UP
28	6136-81-4210	WOW	1	SN: 10001-UP
29	6136-81-4220	WOW	1	SN: 10001-UP
30	6136-81-4230	WOW	1	SN: 10001-UP
31	6136-81-4240	WOW	1	SN: 10001-UP
32	08036-11210	CLIP	1	SN: 10001-UP

Item	Part No.	Part Name	Qty	Options
33	08036-10814	CLIP	2	SN: .-UP

Reference: 111A

Get the complete PDF catalogue

Komatsu S6D105-1A (JPN) S/N 10001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.