





PJ30056

Reference: 0101

030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6137-12-1020	CYLINDER HEAD ASS'Y,WITH VALVE	1	SN: 80070-UP
	6137-12-1200	• CYLINDER HEAD ASS'Y,VALVE LESS	1	SN: 80070-UP
1		• ☆ HEAD,CYLINDER	1	SN: 80070-UP
2	6136-11-1130	• SLEEVE,HOLDER	6	SN: 80070-UP
3	6138-12-1310	• SEAT,INTAKE VALVE (STD)	6	SN: 80070-UP
3	6138-19-1310	• SEAT, 0.25MM,INTAKE VALVE (OS)	6	SN: 80070-UP
3	6138-18-1310	• SEAT, 0.50MM,INTAKE VALVE (OS)	6	SN: 80070-UP
3	6138-17-1310	• SEAT, 0.75MM,INTAKE VALVE (OS)	6	SN: 80070-UP
3	6138-16-1310	• SEAT, 1.00MM,INTAKE VALVE (OS)	6	SN: 80070-UP
4	6136-12-1320	• SEAT,EXHAUST VALVE (STD)	6	SN: 80070-UP
4	6136-19-1420	• SEAT, 0.25MM,EXHAUST VALVE (OS)	6	SN: 80070-UP
4	6136-18-1420	• SEAT, 0.50MM,EXHAUST VALVE (OS)	6	SN: 80070-UP
4	6136-17-1420	• SEAT, 0.75MM,EXHAUST VALVE (OS)	6	SN: 80070-UP
4	6136-16-1420	• SEAT, 1.00MM,EXHAUST VALVE (OS)	6	SN: 80070-UP
5	6136-19-1430	• △ GUIDE,VALVE	12	SN: 80070-UP
6	07046-42816	• PLUG	13	SN: 80070-UP
7	07046-44016	• PLUG	4	SN: 80070-UP
8	07043-50108	• PLUG	7	SN: 80070-UP
9	6138-42-4110	• VALVE,INTAKE	6	SN: 80070-UP
10	6136-42-4210	• VALVE,EXHAUST	6	SN: 80070-UP
11	6136-42-4410	• SPRING,VALVE	12	SN: 80070-UP
12	6136-42-4510	• GUIDE,SPRING	12	SN: 80070-UP
13	6136-42-4520	• COTTER,VALVE	24	SN: 80070-UP
14	6136-41-4530	• SEAT,SPRING	12	SN: 80070-UP
15	6136-11-1813	GASKET,HEAD (K1)	1	SN: 80070-UP
15	6136-11-1812	☒ GASKET,HEAD (K1)	1	SN: (80070-96035)
16	6136-12-1610	BOLT	26	SN: 80070-UP
17	6136-11-1910	HANGER,FRONT	1	SN: 80070-UP
18	6136-11-1821	GASKET (K1)	1	SN: 80070-UP
19	6136-11-1930	HANGER,REAR	1	SN: 80070-UP
20	01010-31025	BOLT	2	SN: 80070-UP
21	01602-01030	WASHER,SPRING	2	SN: 80070-UP

Catalog signs: ☆ not supplied separately: assembly only △ semi-finished: additional work required ☒ discontinued: use part above



P W 2 6 7 7


Reference: 0111

030020 ROCKER ARM

Item	Part No.	Part Name	Qty	Options
	6138-42-5100	ROCKER ARM ASS'Y	1	SN: 80070-UP
1	6138-42-5110	• BRACKET	1	SN: 80070-UP
2	6138-42-5120	• BRACKET	5	SN: 80070-UP
	6138-42-5020	• ROCKER ARM SHAFT A.	1	SN: 80070-UP
3		• ☆ SHAFT	1	SN: 80070-UP
4	6142-42-5550	• • PLUG	2	SN: 80070-UP
5	6136-42-5130	• ARM	12	SN: 80070-UP
6	6136-42-5140	• SCREW,ADJUST	12	SN: 80070-UP
7	01580-00806	• NUT,LOCK	12	SN: 80070-UP
8	6136-41-5310	• SPRING	5	SN: 80070-UP
9	6136-41-5320	• SPRING	2	SN: 80070-UP
10	6136-41-5330	• CLIP	2	SN: 80070-UP
11	6136-41-5131	STUD	4	SN: 80070-UP
12	01010-31280	BOLT	2	SN: 80070-UP
13	01602-01236	WASHER,SPRING	6	SN: 80070-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0111




PJ32885

Reference: 0115

030030 CYLINDER HEAD COVER

Item	Part No.	Part Name	Qty	Options
1	6136-11-8151	COVER,HEAD	1	SN: 80070-UP
2	6150-21-6750	BREATHER	1	SN: 80070-UP
3	6114-21-5190	O-RING (K1)	1	SN: 80070-UP
4	6136-11-8814	O-RING (K1)	1	SN: 80070-UP
5	6134-11-8120	NUT	4	SN: 80070-UP
6	6136-11-8130	WASHER	4	SN: 80070-UP
7	6136-11-8142	PACKING (K1)	4	SN: 80070-UP
8	6138-11-8860	HOSE,BREATHER	1	SN: 80070-UP
9	07280-02523	CLAMP	1	SN: 80070-UP
10	6600-01-5950	CLIP	1	SN: 80070-UP

Reference: 0115




PJ31268

Reference: 0131

030040 AIR INTAKE MANIFOLD AND CONNECTION

Item	Part No.	Part Name	Qty	Options
1	6136-12-4120	MANIFOLD,INTAKE	1	SN: 82172-UP
1	6136-11-4123	MANIFOLD,INTAKE	1	SN: 80070-82171
2	6114-11-8910	PLUG	2	SN: 80070-82171
3	07005-02216	SEAL, WASHER (K1)	2	SN: 80070-82171
4	6136-11-4811	GASKET (K1)	1	SN: 80070-UP
5	01010-30850	BOLT	2	SN: 80070-UP
6	01010-30865	BOLT	8	SN: 80070-UP
7	01010-30865	BOLT	2	SN: 80070-UP
8	01602-00825	WASHER,SPRING	12	SN: 80070-UP
9	01640-20816	WASHER	12	SN: 80070-UP
10	600-815-2341	HEATER,RIBBON	1	SN: 80070-UP
11	6137-11-4311	CONNECTOR,AIR	1	SN: 80070-UP
12	07042-00108	PLUG	2	SN: 80070-UP
13	07043-00415	PLUG	1	SN: 80070-UP
14	6136-11-4820	GASKET (K1)	2	SN: 80070-UP
15	01010-30875	BOLT	1	SN: 80070-UP
16	01010-30870	BOLT	3	SN: 80070-UP
17	01602-00825	WASHER,SPRING	4	SN: 80070-UP
18	01640-20816	WASHER	4	SN: 80070-UP
19	6137-11-4371	HOSE,AIR	1	SN: 80070-UP
20	07281-00709	CLAMP	2	SN: 80070-UP
21	6136-81-4111	PLATE	1	SN: 80070-UP
22	600-815-2170	SWITCH	1	SN: 80070-UP
23	01010-30620	BOLT	2	SN: 80070-UP
24	01580-00605	NUT	2	SN: 80070-UP
25	01602-00619	WASHER,SPRING	2	SN: 80070-UP
26	01641-00608	WASHER	4	SN: 80070-UP
27	6678-81-4330	WIRE, 350MM	1	SN: 80070-UP

Reference: 0131



PJ35626

Reference: 0142

030050 AIR CLEANER AND MOUNTING

Item	Part No.	Part Name	Qty	Options
1	6131-82-7103	AIR CLEANER ASS'Y	1	SN: 80070-UP
	6131-82-7112	• BODY	1	SN: 80070-UP
	6131-82-7011	• ELEMENT ASS'Y	1	SN: 80070-UP
2		• ☆ ELEMENT, INNER	1	SN: 80070-UP
3	600-181-9631	• NUT	1	SN: 80070-UP
4	600-181-7511	• WASHER, SEAL (K1)	1	SN: 80070-UP
	600-181-8300	• ELEMENT ASS'Y, OUTER	1	SN: 80070-UP
5		• ☆ ELEMENT	1	SN: 80070-UP
6	600-181-8640	• NUT, WING	1	SN: 80070-UP
7	600-181-7511	• WASHER, SEAL (K1)	1	SN: 80070-UP
8	04064-01510	• RING, SNAP	1	SN: 80070-UP
9	600-181-8590	• PAN, DUST	1	SN: 80070-UP
10	600-181-2480	• VALVE	1	SN: 80070-UP
11	600-181-8490	• O-RING (K1)	1	SN: 80070-UP
12	600-181-8580	• CLAMP	1	SN: 80070-UP
13	6137-81-8720	BRACKET	1	SN: 80070-UP
14	01010-31225	BOLT	4	SN: 80070-UP
15	01602-01236	WASHER, SPRING	4	SN: 80070-UP
16	01641-21223	WASHER	4	SN: 80070-UP
17	6131-11-4520	BAND ASS'Y	2	SN: 80070-UP
17		• ☆ PIN	1	SN: 80070-UP
17		• ☆ PIN, WITH THREAD	1	SN: 80070-UP
18	6643-11-4641	BOLT	2	SN: 80070-UP
19	6131-12-4240	CONNECTOR	1	SN: 80070-UP
20	6110-11-4430	GASKET (K1)	1	SN: 80070-UP
21	01580-00806	NUT	6	SN: 80070-UP
22	01602-00825	WASHER, SPRING	6	SN: 80070-UP
23	01641-00812	WASHER	6	SN: 80070-UP
24	6137-81-8730	HOSE	1	SN: 80070-UP
25	07281-00909	CLAMP	2	SN: 80070-UP
26	600-181-3870	SCREEN	1	SN: 80070-UP
27	08670-50635	INDICATOR, DUST (FOR JAPAN)	1	SN: 80070-UP
28	09637-00161	PLATE, INSTRUCTION, (JAPANESE-ENGLISH)	1	SN: 80070-UP

Catalog signs: ☆ not supplied separately: assembly only


P J 3 1 2 7 1

Reference: 0151

030060 EXHAUST MANIFOLD AND TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
1	6137-11-5110	MANIFOLD,EXHAUST	1	SN: 80070-UP
2	07042-20108	PLUG	2	SN: 80070-UP
3	6136-11-5810	GASKET (K1)	3	SN: 80070-UP
4	01011-31000	BOLT	9	SN: 80070-UP
5	6136-11-5120	SPACER	9	SN: 80070-UP
6	01643-31032	WASHER	1	SN: 80070-UP
7	01011-31015	BOLT	2	SN: 80070-UP
8	6137-11-5120	SPACER	2	SN: 80070-UP
9	01010-31060	BOLT	1	SN: 80070-UP
10	6112-21-6960	SPACER	1	SN: 80070-UP
11	6137-82-8200	TURBOCHARGER ASS'Y,(T04B-59)	1	SN: 80070-UP
12	6131-11-5170	GASKET (K1)	1	SN: 80070-UP
13	02030-40638	BOLT	4	SN: 80070-UP
14	6131-11-1290	NUT	4	SN: 80070-UP

Reference: 0151




P G 3 T 0 0 0

Reference: 0155

030070 TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
	6137-82-8200	TURBOCHARGER ASS'Y,(T04B-59)	1	SN: 80070-UP
1	GA408274-0034	• HOUSING,BLOWER	1	SN: 80070-UP
2	GA467114-0004	• ROTOR ASS'Y	1	SN: 80070-UP
3	GA407875-0000	• CLAMP	3	SN: 80070-UP
4	GA407876-0000	• PLATE,LOCK	3	SN: 80070-UP
5	GA400572-0301	• BOLT	6	SN: 80070-UP
6	GA406908-0002	• CLAMP	3	SN: 80070-UP
7	GA406909-0000	• PLATE,LOCK	3	SN: 80070-UP
8	GA400450-0001	• BOLT	6	SN: 80070-UP
9	GA410401-0036	• HOUSING,TURBINE	1	SN: 80070-UP
10	GA467057-0001	OVERHAUL KIT,(NOT SHOWN)	1	SN: 80070-UP

Reference: 0155



PJ81273

Reference: 0161

030080 MUFFLER AND MOUNTING

Item	Part No.	Part Name	Qty	Options
1	6137-11-5531	MUFFLER	1	SN: 80070-UP
2	6137-11-5560	BRACKET	1	SN: 80070-UP
3	01010-30825	BOLT	1	SN: 80070-UP
4	01642-00810	WASHER	1	SN: 80070-UP
5	01010-31025	BOLT	4	SN: 80070-UP
6	01642-01016	WASHER	4	SN: 80070-UP
7	01010-31040	BOLT	5	SN: 80070-UP
8	6631-11-5630	SPACER	5	SN: 80070-UP
9	6131-11-5230	JOINT	1	SN: 80070-UP
10	6131-11-5360	BOLT	2	SN: 80070-UP
11	6114-11-5280	RING,SEAL	1	SN: 80070-UP
12	6137-11-5580	PIPE,DRAIN	1	SN: 80070-UP
13	07260-20971	HOSE	1	SN: 80070-UP
14	6136-11-5680	CLIP	1	SN: 80070-UP
15	6993-11-5370	PIPE,EXHAUST	1	SN: 80070-UP
16	6620-11-5742	CLAMP	1	SN: 80070-UP
17	01051-31215	BOLT	1	SN: 80070-UP
18	01582-21210	NUT	2	SN: 80070-UP
19	01643-31232	WASHER	2	SN: 80070-UP

Reference: 0161

Get the complete PDF catalogue

Komatsu S6D105-1MM-B S/N 80070-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.