




Reference: 0101


030010 CYLINDER HEAD(#35323-48087)

Item	Part No.	Part Name	Qty	Options
1	6151-13-1101	CYLINDER HEAD ASS'Y,VALVE LESS	6	SN: 35323-48087
		• ☆ HEAD,CYLINDER	1	SN: 35323-48087
2	6150-11-1331	• INSERT,INTAKE VALVE (STD)	2	SN: 35323-@
	6150-19-1331	• INSERT ? 0.25MM,INTAKE VALVE (OS)	2	SN: 35323-@
	6150-18-1331	• INSERT ? 0.50MM,INTAKE VALVE (OS)	2	SN: 35323-@
	6150-17-1331	• INSERT ? 0.75MM,INTAKE VALVE (OS)	2	SN: 35323-@
	6150-16-1331	• INSERT ? 1.00MM,INTAKE VALVE (OS)	2	SN: 35323-@
3	6150-11-1320	• INSERT,EXHAUST VALVE (STD)	2	SN: 35323-@
	6150-19-1320	• INSERT ? 0.25MM,EXHAUST VALVE (OS)	2	SN: 35323-@
	6150-18-1320	• INSERT ? 0.50MM,EXHAUST VALVE (OS)	2	SN: 35323-@
	6150-17-1320	• INSERT ? 0.75MM,EXHAUST VALVE (OS)	2	SN: 35323-@
	6150-16-1320	• INSERT ? 1.00MM,EXHAUST VALVE (OS)	2	SN: 35323-@
4	6150-12-1341	• GUIDE,INTAKE VALVE	2	SN: 35323-@
5	6150-12-1351	• GUIDE,EXHAUST VALVE	2	SN: 35323-@
6	6150-11-1140	• GUIDE	2	SN: 35323-@
7	04260-00793	• BALL	2	SN: 35323-48087
8	07046-41810	• PLUG	1	SN: 35323-48087
9	07043-70108	• PLUG	2	SN: 35323-48087
10	6162-13-1150	• PLUG	9	SN: 35323-48087
11	04020-00820	• PIN,DOWEL	2	SN: 35323-@
12	6150-41-4111	VALVE,INTAKE	12	SN: 35323-@
13	6150-41-4210	VALVE,EXHAUST	12	SN: 35323-@
14	6150-41-4540	ROTATOR,INTAKE VALVE	12	SN: 35323-@
15	6140-41-4540	SEAL,EXHAUST VALVE (K1)	12	SN: 35323-@
16	6150-41-4430	SEAT,LOWER	12	SN: 35323-@
17	6150-41-4510	SEAT,UPPER	24	SN: 35323-@
18	6136-42-4520	COTTER	48	SN: 35323-@
19	6150-41-4420	SPRING,INTAKE	12	SN: 35323-@
20	6150-41-4411	SPRING,EXHAUST	12	SN: 35323-@
21	6150-41-5611	CROSSHEAD	12	SN: 35323-@
22	6150-41-5620	SCREW	12	SN: 35323-@
23	6150-41-5630	NUT	12	SN: 35323-@
24	6150-17-1812	GASKET,HEAD (K1)	6	SN: 35323-@
25	6150-11-1920	• GROMMET,OIL	1	SN: 35323-@

Item	Part No.	Part Name	Qty	Options
26	6150-11-1930	• GROMMET,OIL	1	SN: 35323-@
27	6150-11-1940	• GROMMET,WATER	4	SN: 35323-@
28	6150-11-1610	BOLT	36	SN: 35323-@
29	6150-81-9160	BOLT	6	SN: 35323-@

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0101



Reference: 0101A


030020 CYLINDER HEAD(#48088-)

Item	Part No.	Part Name	Qty	Options
	6151-11-1100	CYLINDER HEAD ASS'Y,VALVE LESS	6	SN: 48088-UP
1		• ☆ HEAD,CYLINDER	1	SN: 48088-UP
2	6136-11-1130	• SLEEVE	1	SN: 48088-UP
3	6150-11-1331	• INSERT,INTAKE VALVE (STD)	2	SN: 35323-UP
	6150-19-1331	• INSERT ? 0.25MM,INTAKE VALVE (OS)	2	SN: 35323-UP
	6150-18-1331	• INSERT ? 0.50MM,INTAKE VALVE (OS)	2	SN: 35323-UP
	6150-17-1331	• INSERT ? 0.75MM,INTAKE VALVE (OS)	2	SN: 35323-UP
	6150-16-1331	• INSERT ? 1.00MM,INTAKE VALVE (OS)	2	SN: 35323-UP
4	6150-11-1320	• INSERT,EXHAUST VALVE (STD)	2	SN: 35323-UP
	6150-19-1320	• INSERT ? 0.25MM,EXHAUST VALVE (OS)	2	SN: 35323-UP
	6150-18-1320	• INSERT ? 0.50MM,EXHAUST VALVE (OS)	2	SN: 35323-UP
	6150-17-1320	• INSERT ? 0.75MM,EXHAUST VALVE (OS)	2	SN: 35323-UP
	6150-16-1320	• INSERT ? 1.00MM,EXHAUST VALVE (OS)	2	SN: 35323-UP
5	6150-12-1341	• GUIDE,INTAKE VALVE	2	SN: 35323-UP
6	6150-12-1351	• GUIDE,EXHAUST VALVE	2	SN: 35323-UP
7	6150-11-1140	• GUIDE	2	SN: 35323-UP
8	6162-13-1150	• PLUG	8	SN: 48088-UP
9	04020-00820	• PIN,DOWEL	2	SN: 35323-UP
10	6150-41-4111	VALVE,INTAKE	12	SN: 35323-UP
11	6150-41-4210	VALVE,EXHAUST	12	SN: 35323-UP
12	6150-41-4540	ROTATOR,INTAKE VALVE	12	SN: 35323-UP
13	6140-41-4540	SEAL,EXHAUST VALVE (K1)	12	SN: 35323-UP
14	6150-41-4430	SEAT,LOWER	12	SN: 35323-UP
15	6150-41-4510	SEAT,UPPER	24	SN: 35323-UP
16	6136-42-4520	COTTER	48	SN: 35323-UP
17	6150-41-4420	SPRING,INTAKE	12	SN: 35323-UP
18	6150-41-4411	SPRING,EXHAUST	12	SN: 35323-UP
19	6150-41-5611	CROSSHEAD	12	SN: 35323-UP
20	6150-41-5620	SCREW	12	SN: 35323-UP
21	6150-41-5630	NUT	12	SN: 35323-UP
22	6150-17-1812	GASKET,HEAD (K1)	6	SN: 35323-UP
23	6150-11-1920	• GROMMET,OIL	1	SN: 35323-UP
24	6150-11-1930	• GROMMET,OIL	1	SN: 35323-UP
25	6150-11-1940	• GROMMET,WATER	4	SN: 35323-UP

Item	Part No.	Part Name	Qty	Options
26	6150-11-1610	BOLT	36	SN: 35323-UP
27	6150-81-9160	BOLT	6	SN: 35323-UP

Catalog signs: ☆ not supplied separately; assembly only

Reference: 0101A




Reference: 0111

030030 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
1	6150-11-7110	HOUSING,ROCKER ARM	6	SN: 35323-UP
2	6150-11-7810	GASKET (K1)	6	SN: 35323-UP
3	6150-81-9140	BOLT	42	SN: 35323-UP
4	01643-31032	WASHER	42	SN: 35323-UP
	6150-41-5400	ARM ASS'Y,INTAKE	6	SN: 35323-UP
5		• ☆ ARM,ROCKER	1	SN: 35323-UP
6	6150-41-5420	• BUSHING	1	SN: 35323-UP
7	6150-41-5540	SCREW	6	SN: 35323-UP
8	01582-01008	NUT	6	SN: 35323-UP
	6150-41-5500	ARM ASS'Y,EXHAUST	6	SN: 35323-UP
9		• ☆ ARM,ROCKER	1	SN: 35323-UP
10	6150-41-5420	• BUSHING	1	SN: 35323-UP
11	6162-43-5340	• RIVET	1	SN: 35323-UP
12	6150-41-5540	SCREW	6	SN: 35323-UP
13	01582-01008	NUT	6	SN: 35323-UP
	6150-41-5300	ROCKER ARM SHAFT A.	6	SN: 35323-UP
14		• ☆ SHAFT	1	SN: 35323-UP
15	6150-81-8420	• BALL	1	SN: 35323-UP
16	6150-41-5320	SPRING	6	SN: 35323-UP
17	6150-81-9370	BOLT	12	SN: 35323-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0111




Reference: 0115

030040 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6150-11-8111	COVER,HEAD ? NO.1 ?2 ?3 ?4 ?5	5	SN: 35323-UP
2	6150-11-8810	GASKET (K1)	6	SN: 35323-UP
3	6150-81-9370	BOLT	24	SN: 35323-UP
4	01640-21016	WASHER	24	SN: 35323-UP
5	6150-11-8820	RUBBER (K1)	24	SN: 35323-UP
	6151-11-8820	RUBBER,(B)	24	SN: 47234-UP
6	6150-11-8151	COVER,HEAD ? NO.6	1	SN: 35323-UP
7	6150-21-6520	TUBE	1	SN: 35323-UP
8	07025-00050	CAP	1	SN: 35323-UP
	07025-10050	CAP,(B)	1	SN: 47234-UP

Reference: 0115



PG36341

Reference: 0131


030050 AIR INTAKE MANIFOLD AND CONNECTION

Item	Part No.	Part Name	Qty	Options
	6151-11-4910	INTAKE MANIFOLD A.	1	SN: 35323-UP
1		• ☆ MANIFOLD	1	SN: 35323-UP
2	07042-00415	• PLUG	1	SN: 35323-UP
3	07042-00108	• PLUG	2	SN: 35323-UP
4	6150-13-4810	GASKET (K1)	6	SN: 35323-UP
5	01010-51030	BOLT	11	SN: 35323-UP
6	01010-51045	BOLT	3	SN: 35323-UP
7	01010-51060	BOLT	1	SN: 35323-UP
8	01011-51045	BOLT	1	SN: 35323-UP
9	01011-51010	BOLT	8	SN: 35323-UP
10	01640-21016	WASHER	24	SN: 35323-UP
11	6631-11-6390	SPACER	3	SN: 35323-UP
12	6206-81-9870	SPACER	1	SN: 35323-UP
13	6151-11-4362	CONNECTOR	1	SN: 48088-UP
	6151-13-4361	CONNECTOR	1	SN: 42272-48087
	6151-13-4360	□ CONNECTOR	1	SN: 35323-42271
14	07042-00108	PLUG	1	SN: 35323-UP
15	600-815-3810	HEATER,RIBBON	1	SN: 35323-UP
16	6150-11-4820	GASKET (K1)	2	SN: 35323-UP
17	01010-51055	BOLT	4	SN: 35323-UP
18	01011-51075	BOLT	2	SN: 35323-UP
19	01640-21016	WASHER	7	SN: 35323-UP
20	6151-11-4410	HOSE	1	SN: 48088-UP
	6151-13-4410	HOSE	1	SN: 35323-48087
21	07281-00909	CLAMP	2	SN: 48088-UP
	07281-00809	CLAMP	2	SN: 35323-48087
22	6151-81-4510	BRACKET	1	SN: 35323-UP
23	01010-51020	BOLT	2	SN: 35323-UP
24	600-815-2170	SWITCH,HEATER	1	SN: 35323-UP
25	01010-50610	BOLT	2	SN: 35323-UP
26	01640-20610	WASHER	2	SN: 35323-UP
27	6151-81-4590	PLATE	1	SN: 35323-UP
28	6151-81-4490	WIRE ? 160MM	1	SN: 35323-UP
29	08038-00519	CAP	2	SN: 35323-UP

Item	Part No.	Part Name	Qty	Options
	08038-10519	CAP,(B)	2	SN: 47234-UP
30	600-050-2420	CLIP,(SEE FIG.ENGINE WIRING)	1	SN: 35323-UP

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: 0131



PJ31180

Reference: 0132

030060 AIR INTAKE MANIFOLD AND CONNECTION (WITH WATER SEPARATOR)

Item	Part No.	Part Name	Qty	Options
	6151-11-4910	INTAKE MANIFOLD A.	1	SN: 35323-UP
1		• ☆ MANIFOLD	1	SN: 35323-UP
2	07042-00415	• PLUG	1	SN: 35323-UP
3	07042-00108	• PLUG	2	SN: 35323-UP
4	6150-13-4810	GASKET (K1)	6	SN: 35323-UP
5	01010-51030	BOLT	11	SN: 35323-UP
6	01010-51045	BOLT	3	SN: 35323-UP
7	01010-51060	BOLT	1	SN: 35323-UP
8	01011-51045	BOLT	1	SN: 35323-UP
9	01011-51010	BOLT	8	SN: 35323-UP
10	01640-21016	WASHER	24	SN: 35323-UP
11	6631-11-6390	SPACER	3	SN: 35323-UP
12	6206-81-9870	SPACER	1	SN: 35323-UP
13	6151-11-4362	CONNECTOR	1	SN: 48088-UP
	6151-13-4361	CONNECTOR	1	SN: 42272-48087
	6151-13-4360	□ CONNECTOR	1	SN: 35323-42271
14	07042-00108	PLUG	1	SN: 35323-UP
15	600-815-3810	HEATER,RIBBON	1	SN: 35323-UP
16	6150-11-4820	GASKET (K1)	2	SN: 35323-UP
17	01010-51055	BOLT	4	SN: 35323-UP
18	01011-51075	BOLT	2	SN: 35323-UP
19	01640-21016	WASHER	7	SN: 35323-UP
20	6151-11-4410	HOSE	1	SN: 48088-UP
	6151-13-4410	HOSE	1	SN: 35323-48087
21	07281-00909	CLAMP	2	SN: 48088-UP
	07281-00809	CLAMP	2	SN: 35323-48087
22	6151-81-4510	BRACKET	1	SN: 35323-UP
23	01010-51030	BOLT	1	SN: 35323-UP
24	01010-51035	BOLT,(SEE FIG.0415)	1	SN: 35323-UP
25	600-815-2170	SWITCH,HEATER	1	SN: 35323-UP
26	01010-50610	BOLT	2	SN: 35323-UP
27	01640-20610	WASHER	2	SN: 35323-UP
28	6151-81-4590	PLATE	1	SN: 35323-UP

Item	Part No.	Part Name	Qty	Options
29	6151-81-4490	WIRE ? 160MM	1	SN: 35323-UP
30	08038-00519	CAP	2	SN: 35323-UP
31	600-050-2420	CLIP,(SEE FIG.ENGINE WIRING)	1	SN: 35323-UP

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: 0132

Get the complete PDF catalogue

Komatsu S6D125-1VV S/N 35323-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.