




Reference: 0101


030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6128-11-1012	CYLINDER HEAD ASS'Y	3	SN: 52707-UP
	6128-11-1022	• CYLINDER HEAD ASS'Y	1	SN: 52707-UP
1		• • ☆ HEAD,CYLINDER	1	SN: 52707-UP
2	6128-11-1130	• • SLEEVE	2	SN: 52707-UP
3	6127-11-1141	• • GUIDE,CROSSHEAD	4	SN: 52707-UP
4	6127-11-1341	• • GUIDE,VALVE	8	SN: 52707-UP
5	6127-11-1335	• • SEAT,INTAKE VALVE (STD)	4	SN: 52707-UP
	6127-19-1335	• • SEAT□ 0.25MM,INTAKE VALVE (OS)	4	SN: 52707-UP
	6127-18-1335	• • SEAT□ 0.50MM,INTAKE VALVE (OS)	4	SN: 52707-UP
	6127-17-1335	• • SEAT□ 0.75MM,INTAKE VALVE (OS)	4	SN: 52707-UP
	6127-16-1335	• • SEAT□ 1.00MM,INTAKE VALVE (OS)	4	SN: 52707-UP
6	6127-11-1325	• • SEAT,EXHAUST VALVE (STD)	4	SN: 52707-UP
	6127-19-1325	• • SEAT□ 0.25MM,EXHAUST VALVE (OS)	4	SN: 52707-UP
	6127-18-1325	• • SEAT□ 0.50MM,EXHAUST VALVE (OS)	4	SN: 52707-UP
	6127-17-1325	• • SEAT□ 0.75MM,EXHAUST VALVE (OS)	4	SN: 52707-UP
	6127-16-1325	• • SEAT□ 1.00MM,EXHAUST VALVE (OS)	4	SN: 52707-UP
7	07046-43016	• • PLUG	13	SN: 52707-UP
8	07046-42516	• • PLUG	2	SN: 52707-UP
9	6127-41-4113	• VALVE,INTAKE	4	SN: 52707-UP
10	6127-41-4214	• VALVE,EXHAUST	4	SN: 52707-UP
11	6127-41-4410	• SPRING,VALVE	8	SN: 52707-UP
12	6127-41-4530	• SEAT,SPRING□ EXHAUST	4	SN: 52707-UP
13	6127-41-4541	• SEAL,VALVE STEM (K1)	4	SN: 52707-UP
	6127-40-4501	• VALVE COTTER ASS'Y	8	SN: 52707-UP
14	6127-41-4510	• • SEAT,SPRING	1	SN: 52707-UP
15	6127-41-4522	• • COTTER	2	SN: 52707-UP
16	6127-11-1410	COVER	3	SN: 52707-UP
17	6110-61-6831	GASKET (K1)	3	SN: 52707-UP
18	01010-31030	BOLT	6	SN: 52707-UP
19	01602-01030	WASHER,SPRING	6	SN: 52707-UP
20	6127-41-5614	CROSSHEAD	12	SN: 52707-UP
21	6127-41-5641	SCREW,ADJUST	12	SN: 52707-UP
22	6127-41-5630	NUT	12	SN: 52707-UP
	6127-11-1087	GASKET ASS'Y,HEAD (K1)	3	SN: 52707-UP

Item	Part No.	Part Name	Qty	Options
23		• ☆ GASKET,HEAD	1	SN: 52707-UP
24	6127-11-1827	•• SEAL	2	SN: 52707-UP
25	6127-11-1830	•• GROMMET	1	SN: 52707-UP
26	6127-11-1851	• RETAINER	8	SN: 52707-UP
27	6127-11-1841	• GROMMET	8	SN: 52707-UP
28	6127-11-1612	BOLT	30	SN: 52707-UP
29	6127-11-1620	WASHER	30	SN: 52707-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0101



PJ36018

Reference: 0111


030020 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
	6127-11-7030	HOUSING ASS'Y	3	SN: 52707-UP
	6127-11-7040	• HOUSING ASS'Y	1	SN: 52707-UP
1		• • ☆ HOUSING,ROCKER ARM	1	SN: 52707-UP
2	6127-11-7131	• • CONNECTOR	2	SN: 52707-UP
3	6127-11-7140	• • CONNECTOR	2	SN: 52707-UP
4	07000-02016	• • O-RING (K1)	4	SN: 52707-UP
5	01010-30812	• • BOLT	1	SN: 52707-UP
6	07005-00812	• • GASKET (K1)	1	SN: 52707-UP
7	07046-22816	• • PLUG	2	SN: 52707-UP
8	6127-11-7150	• PLUG	2	SN: 52707-UP
9	6127-11-7412	• STOPPER	1	SN: 52707-UP
10	01602-00825	• WASHER,SPRING	1	SN: 52707-UP
11	01642-20810	• WASHER	1	SN: 52707-UP
	6128-41-5040	• ARM ASS'Y,INTAKE VALVE	2	SN: 52707-UP
	6128-41-5400	• • ARM ASS'Y,INTAKE VALVE	1	SN: 52707-UP
12	6128-41-5412	• • • LEVER,INTAKE VALVE	1	SN: 52707-UP
13	6127-41-5420	• • • BUSHING	1	SN: 52707-UP
14	6162-43-5340	• • • RIVET	2	SN: 52707-UP
15	6127-41-5445	• • SCREW,ADJUST	1	SN: 52707-UP
16	6127-41-5431	• • NUT,LOCK	1	SN: 52707-UP
	6127-41-5050	• ARM ASS'Y,EXHAUST VALVE	2	SN: 52707-UP
	6127-41-5500	• • ARM ASS'Y,EXHAUST VALVE	1	SN: 52707-UP
17	6127-41-5512	• • • LEVER,EXHAUST VALVE	1	SN: 52707-UP
18	6127-41-5420	• • • BUSHING	1	SN: 52707-UP
19	6162-43-5340	• • • RIVET	2	SN: 52707-UP
20	6127-41-5445	• • SCREW,ADJUST	1	SN: 52707-UP
21	6127-41-5431	• • NUT,LOCK	1	SN: 52707-UP
	6127-41-5021	• ROCKER ARM SHAFT A.	1	SN: 52707-UP
22	6127-41-5212	• • SHAFT	1	SN: 52707-UP
23	07043-00312	• • PLUG	1	SN: 52707-UP
24	6127-41-5540	• COLLAR	2	SN: 52707-UP
25	6127-41-5320	• SPRING	2	SN: 52707-UP
26	6127-11-7811	GASKET (K1)	3	SN: 52707-UP
27	01011-31205	BOLT	22	SN: 52707-UP

Item	Part No.	Part Name	Qty	Options
28	01011-31210	BOLT	2	SN: 52707-UP
29	01602-01236	WASHER,SPRING	24	SN: 52707-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0111




PJ38019

Reference: 0115

030030 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6127-11-8112	COVER,ROCKER ARM HOUSING	2	SN: 52707-UP
2	6127-11-8122	COVER,ROCKER ARM HOUSING	1	SN: 52707-UP
3	6127-11-8812	GASKET (K1)	3	SN: 52707-UP
4	01010-31080	BOLT	16	SN: 52707-UP
5	01010-31085	BOLT	2	SN: 52707-UP
6	01602-01030	WASHER,SPRING	18	SN: 52707-UP
7	01640-21016	WASHER	14	SN: 52707-UP
8	6127-11-8211	BREATHER ASS'Y	1	SN: 52707-UP
9	07000-62070	O-RING (K1)	1	SN: 52707-UP
10	01010-30822	BOLT	3	SN: 52707-UP
11	01602-00825	WASHER,SPRING	3	SN: 52707-UP
12	6128-11-8262	PIPE	1	SN: 52707-UP
13	6127-11-8290	HOSE	1	SN: 52707-UP
14	07281-00549	CLAMP	2	SN: 52707-UP
15	6124-61-6430	CLAMP	1	SN: 52707-UP
16	6127-11-8380	CLAMP	1	SN: 52707-UP
17	6127-61-6440	CLAMP	2	SN: 52707-UP
18	01010-30840	BOLT	2	SN: 52707-UP
19	01602-00825	WASHER,SPRING	2	SN: 52707-UP
20	6128-11-8360	BRACKET	1	SN: 52707-UP
21	01010-31025	BOLT	2	SN: 52707-UP
22	01602-01030	WASHER,SPRING	2	SN: 52707-UP
23	01580-01008	NUT	1	SN: 52707-UP
24	6127-11-8250	HOSE	1	SN: 52707-UP
25	6127-11-8490	COVER,(FOR SLAG HANDLING)	1	SN: 52707-UP

Reference: 0115




PJ38020

Reference: 0131

030040 AIR INTAKE MANIFOLD AND CONNECTION

Item	Part No.	Part Name	Qty	Options
1	6128-11-4112	MANIFOLD,AIR INTAKE	1	SN: 52707-UP
2	6685-11-4850	COVER	2	SN: 52707-UP
3	6127-11-4640	GASKET (K1)	2	SN: 52707-UP
4	01010-31025	BOLT	8	SN: 52707-UP
5	01602-01030	WASHER,SPRING	8	SN: 52707-UP
6	6127-11-4820	GASKET (K1)	3	SN: 52707-UP
7	01010-31285	BOLT	11	SN: 52707-UP
8	01010-31290	BOLT	1	SN: 52707-UP
9	01602-01236	WASHER,SPRING	12	SN: 52707-UP
10	01640-21223	WASHER	12	SN: 52707-UP
11	6127-11-4331	PIPE	1	SN: 52707-UP
12	6162-83-4810	PLUG	1	SN: 52707-UP
13	6127-11-4620	GASKET (K1)	1	SN: 52707-UP
14	01010-31445	BOLT	4	SN: 52707-UP
15	01602-01442	WASHER,SPRING	4	SN: 52707-UP
16	01641-21423	WASHER	4	SN: 52707-UP
17	6127-11-4320	JOINT	1	SN: 52707-UP
18	02895-67091	O-RING (K1)	4	SN: 52707-UP

Reference: 0131




Reference: 0132

030050 AIR INTAKE MANIFOLD AND AFTER COOLER (WITH AFTER COOLER)

Item	Part No.	Part Name	Qty	Options
	6128-61-6100	AFTER COOLER ASS'Y	1	SN: 52707-UP
1	6128-11-4420	• MANIFOLD,AIR INTAKE	1	SN: 52707-UP
2	07042-00108	• PLUG	1	SN: 52707-UP
3	6128-61-6120	• CORE ASS'Y	1	SN: 52707-UP
4	6710-61-6340	• O-RING	4	SN: 52707-UP
5	6128-11-4650	• COVER	1	SN: 52707-UP
6	6128-61-6390	• PLATE	1	SN: 52707-UP
7	6128-61-6840	• GASKET	1	SN: 52707-UP
8	6128-11-4820	• BOLT	4	SN: 52707-UP
9	01602-00825	• WASHER,SPRING	4	SN: 52707-UP
10	6128-61-6380	• PLATE	1	SN: 52707-UP
11	6128-61-6830	• GASKET	1	SN: 52707-UP
12	01010-30825	• BOLT	4	SN: 52707-UP
13	01602-00825	• WASHER,SPRING	4	SN: 52707-UP
14	6128-11-4720	• GASKET	2	SN: 52707-UP
15	01010-30895	• BOLT	20	SN: 52707-UP
16	01602-00825	• WASHER,SPRING	20	SN: 52707-UP
17	01640-20816	• WASHER	20	SN: 52707-UP
18	6127-11-4820	GASKET	3	SN: 52707-UP
19	01011-31280	BOLT	12	SN: 52707-UP
20	01602-01236	WASHER,SPRING	12	SN: 52707-UP
21	01640-21223	WASHER	12	SN: 52707-UP
22	6128-81-4930	COVER	2	SN: 52707-UP
23	6675-11-4960	GASKET	2	SN: 52707-UP
24	01010-30825	BOLT	8	SN: 52707-UP
25	01602-00825	WASHER,SPRING	8	SN: 52707-UP
26	6128-11-4330	CONNECTOR	1	SN: 52707-UP
27	6610-21-2720	PLUG	1	SN: 52707-UP
28	07042-00108	PLUG	1	SN: 52707-UP
29	6128-11-4730	GASKET	1	SN: 52707-UP
30	01010-30835	BOLT	2	SN: 52707-UP
31	01010-30840	BOLT	2	SN: 52707-UP
32	01602-00825	WASHER,SPRING	4	SN: 52707-UP

Item	Part No.	Part Name	Qty	Options
33	01641-20812	WASHER	4	SN: 52707-UP
34	6128-11-4320	CONNECTOR	1	SN: 52707-UP
35	02895-67091	O-RING	4	SN: 52707-UP
36	04435-01208	CLIP	1	SN: 52707-UP
37	6124-81-4480	CLAMP	1	SN: 52707-UP

Reference: 0132



Reference: 0141

030060 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
	6127-82-7106	AIR CLEANER ASS'Y	1	SN: 52707-UP
1	6127-82-7115	• BODY	1	SN: 52707-UP
	6128-81-7042	• ELEMENT ASS'Y	1	SN: 52707-UP
2		• ☆ ELEMENT, INNER	1	SN: 52707-UP
3	600-181-7511	• • WASHER, SEAL	1	SN: 52707-UP
4	600-181-4370	• • NUT	1	SN: 52707-UP
	600-181-4400	• • ELEMENT ASS'Y, OUTER	1	SN: 52707-UP
5		• • • ☆ ELEMENT, OUTER	1	SN: 52707-UP
6	600-181-4420	• • • NUT, WING	1	SN: 52707-UP
7	600-181-4440	• • • GASKET	1	SN: 52707-UP
8	600-181-4430	• • • CLIP	1	SN: 52707-UP
9	6127-81-4821	GASKET (K1)	1	SN: 52707-UP
10	6127-11-4310	CONNECTOR	1	SN: 52707-UP
11	01640-21016	WASHER	3	SN: 52707-UP
12	01580-01008	NUT	8	SN: 52707-UP
13	01602-01030	WASHER, SPRING	8	SN: 52707-UP
14	01640-21016	WASHER	8	SN: 52707-UP
15	02895-67116	O-RING (K1)	2	SN: 52707-UP
16	6127-11-4560	BRACKET	1	SN: 52707-UP
17	01010-31085	BOLT	2	SN: 52707-UP
18	01602-01030	WASHER, SPRING	2	SN: 52707-UP
19	6127-11-4340	BRACKET	1	SN: 52707-UP
	6127-11-4520	BRACKET, (NOISE SUPPRESSION SPEC.)	1	SN: 52707-UP
20	01010-31435	BOLT	4	SN: 52707-UP
21	01602-01442	WASHER, SPRING	4	SN: 52707-UP
22	6127-11-4360	BAND ASS'Y	1	SN: 52707-UP
	6691-21-6550	• PIN	1	SN: 52707-UP
	6691-21-6560	• PIN ^a WITH THREAD	1	SN: 52707-UP
23	6643-11-4641	BOLT	1	SN: 52707-UP
24	600-181-5710	PRE-CLEANER ASS'Y	1	SN: 52707-UP
25	01016-31045	• BOLT	1	SN: 52707-UP
26	01580-01008	• NUT	1	SN: 52707-UP
27	6127-11-4580	HOOD	1	SN: 52707-UP
28	6127-11-5881	PIPE	1	SN: 52707-UP

Item	Part No.	Part Name	Qty	Options
29	6127-11-5960	HOSE	1	SN: 52707-UP
30	07281-00609	CLAMP	2	SN: 52707-UP
	6128-11-5303	CHECK VALVE ASS'Y	1	SN: 52707-UP
31		• ☆ BODY	1	SN: 52707-UP
32		• ☆ VALVE,CHECK	1	SN: 52707-UP
33		• ☆ COVER	1	SN: 52707-UP
34	6128-11-5610	GASKET (K1)	2	SN: 52707-UP
35	01020-01030	BOLT	4	SN: 52707-UP
36	08670-02001	INDICATOR,DUST	1	SN: 52707-UP
37	09637-00161	PLATE▯ INSTRUCTION	1	SN: 52707-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0141

Get the complete PDF catalogue

Komatsu S6D155-4S S/N 52707-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.