




PG30439

Reference: 0101


030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6211-11-1100	CYLINDER HEAD ASS'Y,VALVE LESS	6	SN: 12599-UP
1		• ☆ HEAD,CYLINDER	1	SN: 12599-UP
2	6210-16-1340	• GUIDE,VALVE	4	SN: 12599-UP
3	6210-11-1140	• GUIDE,CROSSHEAD	2	SN: 12599-UP
4	04020-00820	• PIN,DOWEL	2	SN: 12599-UP
5	07046-41810	• PLUG	1	SN: 12599-UP
6	6162-13-1150	• PLUG,EXPANSION	12	SN: 12599-UP
7	6210-11-1330	• INSERT,INTAKE VALVE (STD)	2	SN: 12599-UP
7	6210-19-1330	• INSERT, 0.25MM,INTAKE VALVE (OS)	2	SN: 12599-UP
7	6210-18-1330	• INSERT, 0.50MM,INTAKE VALVE (OS)	2	SN: 12599-UP
7	6210-17-1330	• INSERT, 0.75MM,INTAKE VALVE (OS)	2	SN: 12599-UP
7	6210-16-1330	• INSERT, 1.00MM,INTAKE VALVE (OS)	2	SN: 12599-UP
8	6210-11-1320	• INSERT,EXHAUST VALVE (STD)	2	SN: 12599-UP
8	6210-19-1320	• INSERT, 0.25MM,EXHAUST VALVE (OS)	2	SN: 12599-UP
8	6210-18-1320	• INSERT, 0.50MM,EXHAUST VALVE (OS)	2	SN: 12599-UP
8	6210-17-1320	• INSERT, 0.75MM,EXHAUST VALVE (OS)	2	SN: 12599-UP
8	6210-16-1320	• INSERT, 1.00MM,EXHAUST VALVE (OS)	2	SN: 12599-UP
9	6210-11-1150	• PIPE	1	SN: 12599-UP
10	07000-63025	• O-RING (K1)	1	SN: 12599-UP
11	07043-50108	• PLUG	1	SN: 12599-UP
12	6210-41-4110	VALVE,INTAKE	12	SN: 12599-UP
13	6210-41-4210	VALVE,EXHAUST	12	SN: 12599-UP
14	6210-41-4410	SPRING,INNER	24	SN: 12599-UP
15	6210-41-4420	SPRING,OUTER	24	SN: 12599-UP
16	6210-41-4530	SEAT,LOWER	24	SN: 12599-UP
17	6210-41-4510	SEAT,UPPER	24	SN: 12599-UP
18	6136-41-4520	COTTER	48	SN: 12599-UP
19	6210-41-5610	CROSSHEAD	12	SN: 12599-UP
20	6210-41-5640	SCREW	12	SN: 12599-UP
21	6127-41-5630	NUT	12	SN: 12599-UP
22	6210-17-1811	GASKET,HEAD (K1)	6	SN: 12599-UP
23	6210-11-1820	• GROMMET,OIL	1	SN: 12599-UP
24	6210-11-1830	• GROMMET,OIL	1	SN: 12599-UP
25	6210-11-1840	• GROMMET,OIL	1	SN: 12599-UP

Item	Part No.	Part Name	Qty	Options
26	6210-11-1850	• GROMMET,WATER	1	SN: 12599-UP
27	6210-11-1860	• GROMMET,WATER	4	SN: 12599-UP
28	6210-11-1610	BOLT,HEAD	36	SN: 12599-UP
29	6150-81-9160	BOLT,HEAD	6	SN: 12599-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0101




Reference: 0111

030020 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
1	6210-11-7120	HOUSING,ROCKER ARM	6	SN: 12599-UP
2	07046-41008	PLUG	18	SN: 12599-UP
3	6210-11-7130	O-RING (K1)	6	SN: 12599-UP
4	6210-11-7810	GASKET (K1)	6	SN: 12599-UP
5	6210-81-8140	BOLT	17	SN: 12599-UP
6	01643-51032	WASHER	18	SN: 12599-UP
7	6150-81-9250	BOLT	1	SN: 12599-UP
8	6210-81-8330	BOLT	6	SN: 12599-UP
9	01643-51232	WASHER	6	SN: 12599-UP
	6210-41-5400	ARM ASS'Y,INTAKE	6	SN: 12599-UP
10		• ☆ ARM,ROCKER	1	SN: 12599-UP
11	6210-41-5420	• BUSHING	1	SN: 12599-UP
	6210-41-5500	ARM ASS'Y,EXHAUST	6	SN: 12599-UP
12		• ☆ ARM,ROCKER	1	SN: 12599-UP
13	6162-43-5340	• RIVET	1	SN: 12599-UP
14	6210-41-5420	• BUSHING	1	SN: 12599-UP
15	6150-41-5540	SCREW	12	SN: 12599-UP
16	01582-01008	NUT	12	SN: 12599-UP
	6210-41-5300	ROCKER ARM SHAFT A.	6	SN: 12599-UP
17		• ☆ SHAFT	1	SN: 12599-UP
18	6150-81-8420	• BALL	1	SN: 12599-UP
19	6210-81-8310	BOLT	12	SN: 12599-UP
20	6210-11-6540	TUBE,AIR	1	SN: 12599-UP
21	07206-30710	BOLT,JOINT	6	SN: 12599-UP
22	07005-01012	GASKET (K1)	12	SN: 12599-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0111




PG30402

Reference: 0115

030030 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6210-11-8110	COVER,ROCKER ARM HOUSING	6	SN: 12599-UP
2	6210-11-8810	GASKET (K1)	6	SN: 12599-UP
3	01010-50865	BOLT	18	SN: 12599-UP
4	6210-11-8120	WASHER	18	SN: 12599-UP
5	6210-11-8140	RUBBER (K1)	18	SN: 12599-UP

Reference: 0115




Reference: 0131

030040 AIR INTAKE MANIFOLD AND AFTER COOLER

Item	Part No.	Part Name	Qty	Options
1	6212-11-4110	MANIFOLD,INTAKE	1	SN: 12599-UP
2	07043-50108	PLUG	2	SN: 12599-UP
3	6212-61-6120	CORE	1	SN: 12599-UP
4	6212-61-6430	O-RING (K1)	4	SN: 12599-UP
5	6212-11-4210	COVER	1	SN: 12599-UP
6	6212-11-4710	GASKET (K1)	2	SN: 12599-UP
7	01435-00890	BOLT	22	SN: 12599-UP
8	01436-01000	BOLT	4	SN: 12599-UP
9	6132-11-4690	BOLT	4	SN: 12599-UP
10	01640-20816	WASHER	4	SN: 12599-UP
11	07043-50108	PLUG	1	SN: 12599-UP
12	600-815-4290	HEATER,RIBBON	6	SN: 12599-UP
13	6210-11-4810	GASKET (K1)	12	SN: 12599-UP
14	01011-51055	BOLT	12	SN: 12599-UP
15	01011-51000	BOLT	12	SN: 12599-UP
16	01640-21016	WASHER	24	SN: 12599-UP
17	6212-11-4320	CONNECTOR	1	SN: 12599-UP
18	07042-00108	PLUG	1	SN: 12599-UP
19	6212-11-4720	GASKET (K1)	1	SN: 12599-UP
20	6150-81-9130	BOLT	5	SN: 12599-UP
21	6150-81-9140	BOLT	1	SN: 12599-UP
22	01641-21016	WASHER	5	SN: 12599-UP
23	6211-11-4410	CONNECTOR	1	SN: 12599-UP
24	02895-67075	O-RING (K1)	4	SN: 12599-UP
25	6212-81-4110	PLATE	1	SN: 12599-UP
26	01010-31025	BOLT	2	SN: 12599-UP
27	600-815-2690	SWITCH,HEATER	1	SN: 12599-UP
28	01010-50812	BOLT	2	SN: 12599-UP
29	01640-20816	WASHER	2	SN: 12599-UP
30	6212-81-4210	WIRE	3	SN: 12599-UP
31	6212-81-4220	WIRE	3	SN: 12599-UP
32	6212-81-4260	WIRE	1	SN: 12599-UP
33	6212-81-4270	WIRE	1	SN: 12599-UP
34	08038-06031	CAP	1	SN: 12599-UP

Item	Part No.	Part Name	Qty	Options
35	08036-31210	CLIP	2	SN: 12599-UP

Reference: 0131



Reference: 0144


030050 AIR CLEANER (EG400BS EXCEPT JAPAN)

Item	Part No.	Part Name	Qty	Options
1	6128-81-7401	AIR CLEANER ASS'Y	1	SN: 12599-UP
	6128-81-7410	• BODY	1	SN: 12599-UP
	6128-81-7051	• ELEMENT ASS'Y	1	SN: 12599-UP
2		• ☆ ELEMENT, INNER	1	SN: 12599-UP
3	600-181-9671	• • NUT	1	SN: 12599-UP
4	600-181-7511	• • WASHER, SEAL	1	SN: 12599-UP
	600-181-4200	• • ELEMENT ASS'Y, OUTER	1	SN: 12599-UP
5		• • • ☆ ELEMENT, OUTER	1	SN: 12599-UP
6	600-181-1990	• • • NUT, WING	1	SN: 12599-UP
7	600-181-4591	• • • WASHER, SEAL	1	SN: 12599-UP
8	04064-01510	• • • RING, SNAP	1	SN: 12599-UP
9	6127-82-7520	• COVER	1	SN: 12599-UP
10	6112-81-7810	• VALVE	1	SN: 12599-UP
11	6112-81-7820	• CLAMP	1	SN: 12599-UP
12	6127-82-7530	• BAFFLE	1	SN: 12599-UP
13	6127-82-7550	• O-RING	1	SN: 12599-UP
14	6127-82-7540	• CLAMP	1	SN: 12599-UP
15	6212-11-4510	CONNECTOR, AIR	1	SN: 12599-UP
16	6127-81-4821	GASKET (K1)	1	SN: 12599-UP
17	01580-11008	NUT	8	SN: 12599-UP
18	01640-21016	WASHER	8	SN: 12599-UP
19	02895-67081	O-RING (K1)	2	SN: 12599-UP
20	6212-11-4520	BRACKET	1	SN: 12599-UP
21	01010-31225	BOLT	4	SN: 12599-UP
22	6211-11-4710	BRACKET	1	SN: 12599-UP
23	01010-31040	BOLT	2	SN: 12599-UP
24	6631-11-5630	SPACER	2	SN: 12599-UP
25	01010-31030	BOLT	2	SN: 12599-UP
26	01642-01016	WASHER	2	SN: 12599-UP
27	6128-11-4380	BAND ASS'Y	1	SN: 12599-UP
27	6691-21-6550	• PIN	1	SN: 12599-UP
27	6691-21-6560	• PIN, WITH THREAD	1	SN: 12599-UP
28	6643-11-4641	BOLT	1	SN: 12599-UP
29	6128-81-7420	SCREEN	1	SN: 12599-UP

Item	Part No.	Part Name	Qty	Options
30	08670-01001	INDICATOR,DUST	1	SN: 12599-UP
31	600-181-0320	ADAPTER	1	SN: 12599-UP
32	09637-00161	PLATE, INSTRUCTION,(ENGLISH-JAPANESE)	1	SN: 12599-UP
32	09637-30161	PLATE, INSTRUCTION,(ENGLISH)	1	SN: 12599-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0144




Reference: 0151

030060 EXHAUST MANIFOLD AND TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
1	6211-11-5140	MANIFOLD,EXHAUST, FRONT	1	SN: 12599-UP
2	6211-11-5150	MANIFOLD,EXHAUST, CENTER	1	SN: 12599-UP
3	07042-20108	PLUG	1	SN: 12599-UP
4	6211-11-5160	MANIFOLD,EXHAUST, REAR	1	SN: 12599-UP
5	6210-11-5810	GASKET (K1)	6	SN: 12599-UP
6	01011-61000	BOLT	22	SN: 12599-UP
7	6136-11-5120	SPACER	22	SN: 12599-UP
8	01010-61055	BOLT	2	SN: 12599-UP
9	6210-11-5820	SPACER	2	SN: 12599-UP
10	6211-11-5191	SEAL	2	SN: 12599-UP
11	07281-10909	CLAMP	2	SN: 12599-UP
12	6505-11-6426	TURBOCHARGER ASS'Y	1	SN: 12599-UP
13	6151-11-5710	GASKET (K1)	1	SN: 12599-UP
14	6151-11-5330	STUD	2	SN: 12599-UP
15	01050-61045	BOLT	2	SN: 12599-UP
16	6114-11-5590	NUT	4	SN: 12599-UP
17	6211-11-5870	ELBOW,EXHAUST	1	SN: 12599-UP
18	6631-11-5630	SPACER	4	SN: 12599-UP
19	01010-31045	BOLT	4	SN: 12599-UP
20	6211-11-5380	CONNECTOR	1	SN: 12599-UP
21	6211-11-5281	SEAL	1	SN: 12599-UP
22	07281-11589	CLAMP	1	SN: 12599-UP
23	6211-11-5390	SEAL	1	SN: 12599-UP
24	07281-11589	CLAMP	1	SN: 12599-UP
25	6211-11-5890	GASKET (K1)	1	SN: 12599-UP

Reference: 0151



PG3T009

Reference: 0155

030070 TURBOCHARGER (EXCEPT JAPAN)

Item	Part No.	Part Name	Qty	Options
	6505-11-6426	TURBOCHARGER ASS'Y,(KTR110A-1C)	1	SN: 12599-UP
1	6505-11-4220	• HOUSING,TURBINE	1	SN: 12599-UP
2	6505-11-0012	• HOUSING,CENTER	1	SN: 12599-UP
3	6505-11-0111	• BEARING,JOURNAL	1	SN: 12599-UP
	6505-11-8910	• ROTOR ASS'Y	1	SN: 12599-UP
4		• ☆ ROTOR,TURBINE	1	SN: 12599-UP
5		• ☆ COLLAR,THRUST	1	SN: 12599-UP
6		• ☆ FLINGER	1	SN: 12599-UP
7		• ☆ IMPELLER,BLOWER	1	SN: 12599-UP
8		• ☆ NUT,LOCK	1	SN: 12599-UP
9	6505-11-0310	• RING,SEAL	2	SN: 12599-UP
10	6505-11-0710	• SHIELD,HEAT	1	SN: 12599-UP
11	6505-11-0510	• LOCK	4	SN: 12599-UP
12	6505-11-0550	• LOCK	4	SN: 12599-UP
13	01020-11016	• BOLT	8	SN: 12599-UP
14	6505-11-0150	• BEARING,THRUST	1	SN: 12599-UP
15	04022-04008	• PIN,DOWEL	1	SN: 12599-UP
16	6505-11-0810	• PLATE,DIFFUSER	1	SN: 12599-UP
17	07000-62055	• O-RING	1	SN: 12599-UP
18	6505-11-0350	• RING,SEAL	1	SN: 12599-UP
19	01010-30816	• BOLT	4	SN: 12599-UP
20	6505-11-0610	• LOCK	2	SN: 12599-UP
21	6505-11-2051	• HOUSING,BLOWER	1	SN: 12599-UP
22	6505-11-0450	• V-BAND	1	SN: 12599-UP
23	6505-11-9035	• PLATE, NAME	1	SN: 12599-UP
24	04418-02550	• SCREW	2	SN: 12599-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0155

Get the complete PDF catalogue

Komatsu SA6D140-A-1T S/N 12599-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.