




Reference: 0101


030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6128-11-1012	CYLINDER HEAD ASS'Y	3	SN: 50816-UP
	6128-11-1022	• CYLINDER HEAD ASS'Y	1	SN: 50816-UP
1		• ☆ HEAD,CYLINDER	1	SN: 50816-UP
2	6128-11-1130	• SLEEVE	2	SN: 50816-UP
3	6127-11-1141	• GUIDE	4	SN: 50816-UP
4	6127-11-1341	• Δ GUIDE,VALVE	8	SN: 50816-UP
5	6127-11-1335	• SEAT,INTAKE VALVE (STD)	4	SN: 50816-UP
	6127-19-1335	• SEAT ? 0.25MM,INTAKE VALVE (OS)	4	SN: 50816-UP
	6127-18-1335	• SEAT ? 0.50MM,INTAKE VALVE (OS)	4	SN: 50816-UP
	6127-17-1335	• SEAT ? 0.75MM,INTAKE VALVE (OS)	4	SN: 50816-UP
	6127-16-1335	• SEAT ? 1.00MM,INTAKE VALVE (OS)	4	SN: 50816-UP
6	6127-11-1325	• SEAT,EXHAUST VALVE (STD)	4	SN: 50816-UP
	6127-19-1325	• SEAT ? 0.25MM,EXHAUST VALVE (OS)	4	SN: 50816-UP
	6127-18-1325	• SEAT ? 0.50MM,EXHAUST VALVE (OS)	4	SN: 50816-UP
	6127-17-1325	• SEAT ? 0.75MM,EXHAUST VALVE (OS)	4	SN: 50816-UP
	6127-16-1325	• SEAT ? 1.00MM,EXHAUST VALVE (OS)	4	SN: 50816-UP
7	07046-43016	• PLUG	13	SN: 50816-UP
8	07046-42516	• PLUG	2	SN: 50816-UP
9	6127-41-4113	• VALVE,INTAKE	4	SN: 50816-UP
10	6127-41-4214	• VALVE,EXHAUST	4	SN: 50816-UP
11	6127-41-4410	• SPRING,VALVE	8	SN: 50816-UP
12	6127-41-4530	• SEAT,SPRING	4	SN: 50816-UP
13	6127-41-4541	• SEAL,VALVE STEM (K1)	4	SN: 50816-UP
	6127-40-4501	• VALVE COTTER ASS'Y	8	SN: 50816-UP
14	6127-41-4510	• SEAT,SPRING	1	SN: 50816-UP
15	6127-41-4522	• COTTER	2	SN: 50816-UP
16	6127-11-1410	COVER	3	SN: 50816-UP
17	6110-61-6831	GASKET (K1)	3	SN: 50816-UP
18	01010-31030	BOLT	6	SN: 50816-UP
19	01602-01030	WASHER,SPRING	6	SN: 50816-UP
20	6127-41-5614	CROSSHEAD	12	SN: 50816-UP
21	6127-41-5641	SCREW,ADJUSTING	12	SN: 50816-UP
22	6127-41-5630	NUT	12	SN: 50816-UP
	6127-11-1087	GASKET ASS'Y,CYLINDER HEAD (K1)	3	SN: 50816-UP

Item	Part No.	Part Name	Qty	Options
23		• ☆ GASKET,CYLINDER HEAD (K1)	1	SN: 50816-UP
24	6127-11-1827	•• SEAL (K1)	2	SN: 50816-UP
25	6127-11-1830	•• GROMMET (K1)	1	SN: 50816-UP
26	6127-11-1851	• RETAINER (K1)	8	SN: 50816-UP
27	6127-11-1841	• GROMMET (K1)	8	SN: 50816-UP
28	6127-11-1612	BOLT	30	SN: 50816-UP
29	6127-11-1620	WASHER	30	SN: 50816-UP

Catalog signs: ☆ not supplied separately: assembly only Δ semi-finished: additional work required

Reference: 0101




Reference: 0111

030020 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
	6127-11-7013	HOUSING ASS'Y,ROCKER ARM	3	SN: 50816-UP
	6127-11-7022	• HOUSING ASS'Y,ROCKER ARM	1	SN: 50816-UP
1		• ☆ HOUSING	1	SN: 50816-UP
2	6127-11-7131	• • CONNECTOR	2	SN: 50816-UP
3	6127-11-7140	• • CONNECTOR	2	SN: 50816-UP
4	07000-02016	• • O-RING (K1)	4	SN: 50816-UP
5	6127-11-7150	• • PLUG	2	SN: 50816-UP
6	6127-11-7412	• STOPPER	1	SN: 50816-UP
7	01602-00825	• WASHER,SPRING	1	SN: 50816-UP
8	01642-20810	• WASHER	1	SN: 50816-UP
	6127-41-5021	• ROCKER ARM SHAFT A.	1	SN: 50816-UP
9	6127-41-5212	• • SHAFT	1	SN: 50816-UP
10	07043-00312	• • PLUG	1	SN: 50816-UP
	6128-41-5040	• ARM ASS'Y,INTAKE VALVE	2	SN: 50816-UP
	6127-41-5050	• ARM ASS'Y,EXHAUST VALVE	2	SN: 50816-UP
	6128-41-5400	• • ARM ASS'Y,INTAKE VALVE	1	SN: 50816-UP
	6127-41-5500	• • ARM ASS'Y,EXHAUST VALVE	1	SN: 50816-UP
11	6128-41-5412	• • • LEVER,INTAKE VALVE	1	SN: 50816-UP
12	6127-41-5512	• • • LEVER,EXHAUST VALVE	1	SN: 50816-UP
13	6127-41-5420	• • • BUSHING	1	SN: 50816-UP
14	6610-41-5340	• • • PIN	2	SN: 50816-UP
15	6127-41-5444	• • SCREW,ADJUSTING	1	SN: 50816-UP
16	6127-41-5431	• • NUT,LOCK	1	SN: 50816-UP
17	6127-41-5540	• COLLAR	2	SN: 50816-UP
18	6127-41-5320	• SPRING	2	SN: 50816-UP
19	04020-01024	PIN,DOWEL	2	SN: 50816-UP
20	6127-11-7811	GASKET (K1)	3	SN: 50816-UP
21	01011-31205	BOLT	21	SN: 50816-UP
22	01011-31210	BOLT	3	SN: 50816-UP
23	01602-01236	WASHER,SPRING	24	SN: 50816-UP
24	01643-31232	WASHER	1	SN: 50816-UP

Catalog signs: ☆ not supplied separately: assembly only




Reference: 0115

030030 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6127-11-8112	COVER,ROCKER ARM HOUSING	2	SN: 50816-UP
2	6127-11-8122	COVER,ROCKER ARM HOUSING	1	SN: 50816-UP
3	6127-11-8812	GASKET (K1)	3	SN: 50816-UP
4	01010-31080	BOLT	18	SN: 50816-UP
5	01602-01030	WASHER,SPRING	18	SN: 50816-UP
6	01640-21016	WASHER	16	SN: 50816-UP
7	6127-11-8211	BREATHER ASS'Y	1	SN: 50816-UP
8	07000-62070	O-RING (K1)	1	SN: 50816-UP
9	01010-30822	BOLT	3	SN: 50816-UP
10	01602-00825	WASHER,SPRING	3	SN: 50816-UP
11	6128-11-8262	PIPE,BREATHER	1	SN: 50816-UP
12	6127-11-8290	HOSE	1	SN: 50816-UP
13	07281-00489	CLAMP	2	SN: 50816-UP
14	6124-61-6430	CLAMP	1	SN: 50816-UP
15	6127-11-8380	CLAMP	1	SN: 50816-UP
16	6127-61-6440	CLAMP	2	SN: 50816-UP
17	01010-30840	BOLT	2	SN: 50816-UP
18	01602-00825	WASHER,SPRING	2	SN: 50816-UP
19	6128-11-8360	BRACKET	1	SN: 50816-UP
20	01010-31025	BOLT	2	SN: 50816-UP
21	01602-01030	WASHER,SPRING	2	SN: 50816-UP
22	01580-01008	NUT	1	SN: 50816-UP

Reference: 0115




Reference: 0121

030040 COMPRESSION RELEASE

Item	Part No.	Part Name	Qty	Options
1	6127-41-8111	SHAFT	1	SN: 50816-UP
2	6127-41-8121	SHAFT	1	SN: 50816-UP
3	6127-41-8141	SHAFT	1	SN: 50816-UP
4	6120-41-8130	JOINT	2	SN: 50816-UP
5	07000-03022	O-RING (K1)	6	SN: 50816-UP
6	6127-41-4291	LEVER	1	SN: 50816-UP
7	6127-11-7412	STOPPER	3	SN: 50816-UP
8	07005-00812	GASKET	3	SN: 50816-UP
9	04000-00720	KEY	1	SN: 50816-UP
10	01010-30835	BOLT	1	SN: 50816-UP
11	01602-00825	WASHER,SPRING	1	SN: 50816-UP

Reference: 0121




Reference: 0131

030050 AIR INTAKE MANIFOLD AND AFTER COOLER

Item	Part No.	Part Name	Qty	Options
	6128-61-6100	AFTER COOLER ASS'Y	1	SN: 50816-UP
1	6128-11-4420	• MANIFOLD,INTAKE	1	SN: 50816-UP
2	07042-00108	• PLUG	1	SN: 50816-UP
3	6128-61-6120	• CORE ASS'Y	1	SN: 50816-UP
4	6710-61-6340	• O-RING (K1)	4	SN: 50816-UP
5	6128-11-4650	• COVER	1	SN: 50816-UP
6	6128-61-6390	• PLATE	1	SN: 50816-UP
7	6128-61-6840	• GASKET (K1)	1	SN: 50816-UP
8	6128-11-4820	• BOLT	4	SN: 50816-UP
9	01602-00825	• WASHER,SPRING	4	SN: 50816-UP
10	6128-61-6380	• PLATE	1	SN: 50816-UP
11	6128-61-6830	• GASKET (K1)	1	SN: 50816-UP
12	01010-30825	• BOLT	4	SN: 50816-UP
13	01602-00825	• WASHER,SPRING	4	SN: 50816-UP
14	6128-11-4720	• GASKET (K1)	2	SN: 50816-UP
15	01010-30895	• BOLT	20	SN: 50816-UP
16	01602-00825	• WASHER,SPRING	20	SN: 50816-UP
17	01640-20816	• WASHER	20	SN: 50816-UP
18	6127-11-4820	GASKET (K1)	3	SN: 50816-UP
19	01011-31280	BOLT	12	SN: 50816-UP
20	01602-01236	WASHER,SPRING	12	SN: 50816-UP
21	01640-21223	WASHER	12	SN: 50816-UP
22	6128-11-4332	CONNECTOR	1	SN: 50816-UP
23	07042-00108	PLUG	1	SN: 50816-UP
24	6610-21-2720	PLUG	1	SN: 50816-UP
25	07217-50610	ELBOW	1	SN: 50816-UP
26	6128-11-4730	GASKET (K1)	1	SN: 50816-UP
27	01010-30835	BOLT	2	SN: 50816-UP
28	01010-30840	BOLT	2	SN: 50816-UP
29	01602-00825	WASHER,SPRING	4	SN: 50816-UP
30	01641-20812	WASHER	4	SN: 50816-UP
31	6130-51-6530	BRACKET	1	SN: 50816-UP
32	6128-11-4320	CONNECTOR	1	SN: 50816-UP
33	02895-67091	O-RING (K1)	4	SN: 50816-UP

Item	Part No.	Part Name	Qty	Options
34	6128-11-4310	CONNECTOR	1	SN: 50816-UP
35	02895-67116	O-RING (K1)	2	SN: 50816-UP
36	08670-01635	INDICATOR,DUST	1	SN: 50816-UP
37	6128-11-8620	BRACKET	1	SN: 50816-UP
38	01580-01008	NUT	8	SN: 50816-UP
39	01602-01030	WASHER,SPRING	8	SN: 50816-UP
40	01640-21016	WASHER	8	SN: 50816-UP
41	6128-11-4221	BRACKET	1	SN: 50816-UP
42	01010-31025	BOLT	5	SN: 50816-UP
43	01602-01030	WASHER,SPRING	5	SN: 50816-UP
44	01641-21016	WASHER	5	SN: 50816-UP

Reference: 0131




Reference: 0141

030060 AIR CLEANER AND PRE-CLEANER

Item	Part No.	Part Name	Qty	Options
	6128-81-7105	AIR CLEANER ASS'Y	1	SN: 50816-UP
1	6128-81-7113	• BODY	1	SN: 50816-UP
	6128-81-7042	• ELEMENT ASS'Y	1	SN: 50816-UP
2		• ☆ ELEMENT, INNER	1	SN: 50816-UP
3	600-181-7511	• • WASHER, SEAL	1	SN: 50816-UP
4	600-181-4370	• • NUT	1	SN: 50816-UP
	600-181-4400	• • ELEMENT ASS'Y, OUTER	1	SN: 50816-UP
5		• • • ☆ ELEMENT, OUTER	1	SN: 50816-UP
6	600-181-4420	• • • NUT, WING	1	SN: 50816-UP
7	600-181-4440	• • • GASKET	1	SN: 50816-UP
8	600-181-4430	• • • CLIP	1	SN: 50816-UP
9	6127-11-4360	BAND ASS'Y	1	SN: 50816-UP
10	6643-11-4641	BOLT	1	SN: 50816-UP
11	6127-81-4821	GASKET (K1)	1	SN: 50816-UP
12	09637-00161	PLATE ? INSTRUCTION	1	SN: 50816-UP
13	600-181-4870	PRE-CLEANER	1	SN: 50816-UP
14	6127-11-5960	HOSE	1	SN: 50816-UP
15	07281-00609	CLAMP	2	SN: 50816-UP
16	6128-11-5590	PIPE, EJECTOR	1	SN: 50816-UP
17	6128-11-5303	CHECK VALVE ASS'Y	1	SN: 50816-UP
18	6128-11-5610	GASKET (K1)	2	SN: 50816-UP
19	01020-01030	BOLT	4	SN: 50816-UP
20	6128-11-5180	HOOD ASS'Y	1	SN: 50816-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0141



Reference: 0151

030070 EXHAUST MANIFOLD AND TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
1	6128-11-5112	MANIFOLD,EXHAUST ? FRONT	1	SN: 50816-UP
2	6128-11-5141	MANIFOLD,EXHAUST ? CENTER	1	SN: 50816-UP
3	07042-00108	PLUG	2	SN: 50816-UP
4	6128-11-5133	MANIFOLD,EXHAUST ? REAR	1	SN: 50816-UP
5	6127-11-5810	GASKET (K1)	6	SN: 50816-UP
6	01011-61210	BOLT	12	SN: 50816-UP
7	01011-61225	BOLT	6	SN: 50816-UP
8	6127-11-5190	LOCK (K1)	6	SN: 50816-UP
9	6127-11-5180	SPACER	12	SN: 50816-UP
10	6128-21-6730	SPACER	6	SN: 50816-UP
11	6127-11-5150	RING,SEAL	2	SN: 50816-UP
12	6502-12-9004	TURBOCHARGER ASS'Y,(SEE FIG.0155)	1	SN: 50816-UP
13	6127-81-2810	GASKET (K1)	1	SN: 50816-UP
14	6128-11-5240	STUD	4	SN: 50816-UP
15	6710-81-2920	NUT	4	SN: 50816-UP

Reference: 0151

Get the complete PDF catalogue

Komatsu SA6D155-4A S/N 50816-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.