




PJ35088A


Reference: 0101

## 030010 CYLINDER HEAD

| Item | Part No.     | Part Name                                             | Qty | Options           |
|------|--------------|-------------------------------------------------------|-----|-------------------|
|      | 6209-11-1100 | CYLINDER HEAD ASS'Y, VALVE LESS                       | 1   | SN: 35398-UP      |
| 1    |              | • ☆ HEAD, CYLINDER                                    | 1   | SN: 35398-UP      |
| 2    | 6204-19-1310 | • GUIDE, VALVE                                        | 12  | SN: 35398-UP      |
| 3    | 6209-11-1430 | • SEAT, INTAKE VALVE (STD)                            | 6   | SN: 35398-UP      |
| 3    | 6209-19-1430 | • SEAT, 0.25MM, INTAKE VALVE (OS)                     | 6   | SN: 35398-UP      |
| 3    | 6209-18-1430 | • SEAT, 0.50MM, INTAKE VALVE (OS)                     | 6   | SN: 35398-UP      |
| 4    | 6207-11-1440 | • SEAT, EXHAUST VALVE (STD)                           | 6   | SN: 35398-UP      |
| 4    | 6207-19-1440 | • SEAT, 0.25MM, EXHAUST VALVE (OS)                    | 6   | SN: 35398-UP      |
| 4    | 6207-18-1440 | • SEAT, 0.50MM, EXHAUST VALVE (OS)                    | 6   | SN: 35398-UP      |
| 5    | 07046-41008  | • PLUG                                                | 6   | SN: 35398-UP      |
| 6    | 07046-41810  | • PLUG                                                | 13  | SN: 35398-UP      |
| 7    | 07046-42216  | • PLUG                                                | 5   | SN: 35398-UP      |
| 8    | 07046-42516  | • PLUG                                                | 15  | SN: 35398-UP      |
| 9    | 02720-40104  | • PLUG                                                | 1   | SN: 35398-UP      |
| 10   | 6209-41-4110 | VALVE, INTAKE                                         | 6   | SN: 35398-UP      |
| 11   | 6209-41-4210 | VALVE, EXHAUST                                        | 6   | SN: 35398-UP      |
| 12   | 6204-41-4510 | SEAT, SPRING                                          | 12  | SN: 35398-UP      |
| 13   | 6204-41-4520 | COTTER                                                | 24  | SN: 35398-UP      |
| 14   | 6204-41-4550 | CAP, VALVE                                            | 12  | SN: 35398-UP      |
| 15   | 6204-41-4431 | SPRING, VALVE                                         | 12  | SN: 35398-UP      |
| 16   | 6204-41-4540 | SEAL, VALVE (K1)                                      | 6   | SN: 35398-UP      |
| 17   | 6206-11-1930 | HANGER, FRONT                                         | 1   | SN: 35398-UP      |
| 17   | 6207-11-1910 | HANGER, FRONT (WITH ALTERNATOR COVER)                 | 1   | SN: 57205-UP      |
| 17   | 6207-61-8110 | HANGER, FRONT (WITH CORROSION RESISTOR)               | 1   | SN: 55690-UP      |
| 18   | 6206-11-1910 | HANGER, REAR                                          | 1   | SN: 35398-UP      |
| 19   | 01435-01020  | BOLT                                                  | 4   | SN: 35398-UP      |
| 20   | 6207-11-1822 | GASKET, HEAD (K1)                                     | 1   | SN: 35398-UP      |
| 20   | 6207-11-1821 | <input checked="" type="checkbox"/> GASKET, HEAD (K1) | 1   | SN: (35398-77240) |
| 21   | 6204-13-1610 | BOLT                                                  | 25  | SN: 35398-UP      |
| 22   | 01643-51232  | WASHER                                                | 25  | SN: 81676-UP      |
| 22   | 01643-31232  | <input type="checkbox"/> WASHER                       | 25  | SN: 35398-81675   |

Catalog signs: ☆ not supplied separately: assembly only ☒ discontinued: use part above ☐ part above may be used instead





PE80001


Reference: 0111

## 030020 ROCKER ARM

| Item | Part No.     | Part Name    | Qty | Options      |
|------|--------------|--------------|-----|--------------|
| 1    | 6204-41-5110 | BRACKET      | 1   | SN: 35398-UP |
| 2    | 6204-41-5120 | BRACKET      | 5   | SN: 35398-UP |
|      | 6206-41-5201 | SHAFT ASS'Y  | 1   | SN: 35398-UP |
| 3    |              | • ☆ SHAFT    | 1   | SN: 35398-UP |
| 4    | 6221-41-5540 | • PLUG       | 2   | SN: 35398-UP |
| 5    | 6221-41-5310 | BOLT         | 1   | SN: 35398-UP |
| 6    | 6202-43-5410 | ARM,ROCKER   | 12  | SN: 35398-UP |
| 7    | 6221-41-5410 | SCREW,ADJUST | 12  | SN: 35398-UP |
| 8    | 6221-41-5420 | NUT          | 12  | SN: 35398-UP |
| 9    | 6202-43-5320 | SPRING       | 5   | SN: 35398-UP |
| 10   | 6221-41-5520 | SPRING       | 2   | SN: 35398-UP |
| 11   | 6136-41-5330 | CLIP         | 2   | SN: 35398-UP |
| 12   | 01435-00865  | BOLT         | 8   | SN: 35398-UP |
| 13   | 6204-41-5710 | BOLT         | 4   | SN: 35398-UP |

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0111




PJ85030

Reference: 0115

## 030030 CYLINDER HEAD COVER

| Item | Part No.     | Part Name                              | Qty | Options      |
|------|--------------|----------------------------------------|-----|--------------|
|      | 6207-11-8100 | HEAD COVER ASS'Y                       | 1   | SN: 35398-UP |
| 1    | 6207-11-8110 | • COVER,HEAD                           | 1   | SN: 35398-UP |
| 2    | 6207-11-8170 | • TUBE                                 | 1   | SN: 35398-UP |
| 3    | 6207-11-8140 | • PLATE                                | 1   | SN: 35398-UP |
| 4    | 04418-02550  | • SCREW                                | 4   | SN: 35398-UP |
| 5    | 6206-11-8810 | O-RING (K1)                            | 1   | SN: 35398-UP |
| 6    | 6136-11-8120 | NUT                                    | 4   | SN: 35398-UP |
| 7    | 6136-11-8130 | WASHER                                 | 4   | SN: 35398-UP |
| 8    | 6136-11-8142 | PACKING (K1)                           | 4   | SN: 35398-UP |
| 9    | 6130-12-8610 | CAP                                    | 1   | SN: 35398-UP |
| 10   | 6207-11-8920 | TUBE,BREATHER                          | 1   | SN: 35398-UP |
| 11   | 07285-00180  | CLIP                                   | 1   | SN: 35398-UP |
| 12   | 424-06-12760 | CLIP                                   | 1   | SN: 35398-UP |
| 13   | 01435-21016  | BOLT                                   | 1   | SN: 35398-UP |
| 14   | 6204-81-2210 | PLATE, NAME,(LIMITED SUPPLY) (ENGLISH) | 1   | SN: 35398-UP |
| 14   | 6204-81-2260 | PLATE, NAME,(LIMITED SUPPLY) (GERMAN)  | 1   | SN: 55690-UP |
| 14   | 6204-81-2290 | PLATE, NAME,(LIMITED SUPPLY) (FRENCH)  | 1   | SN: 55690-UP |
| 14   | 6204-81-2240 | PLATE, NAME,(LIMITED SUPPLY) (SPANISH) | 1   | SN: 55690-UP |
| 14   | 6204-81-2310 | PLATE, NAME,(LIMITED SUPPLY) (ITALIAN) | 1   | SN: 55690-UP |
| 14   | 6204-81-2280 | PLATE, NAME,(LIMITED SUPPLY) (RUSSIAN) | 1   | SN: 55690-UP |

Reference: 0115



PJ35118


Reference: 0131

## 030040 AIR INTAKE MANIFOLD AND CONNECTION

| Item | Part No.     | Part Name                 | Qty | Options         |
|------|--------------|---------------------------|-----|-----------------|
| 1    | 6206-11-4120 | MANIFOLD,AIR INTAKE       | 1   | SN: 35398-UP    |
| 2    | 01435-21025  | BOLT                      | 11  | SN: 35398-UP    |
| 3    | 01435-21075  | BOLT                      | 1   | SN: 35398-UP    |
| 4    | 600-815-2341 | HEATER,RIBBON             | 1   | SN: 35398-UP    |
| 5    | 6206-11-4220 | CONNECTOR,AIR             | 1   | SN: 35398-UP    |
| 6    | 02720-20204  | PLUG                      | 1   | SN: 35398-UP    |
| 7    | 6136-11-4820 | GASKET (K1)               | 2   | SN: 35398-UP    |
| 8    | 01436-01005  | BOLT                      | 2   | SN: 48447-UP    |
| 8    | 01436-21005  | □ BOLT                    | 2   | SN: 35398-48446 |
| 9    | 6209-11-4630 | BRACKET                   | 1   | SN: 35398-UP    |
| 10   | 6132-21-4630 | SPACER                    | 2   | SN: 35398-UP    |
| 11   | 01435-21085  | BOLT                      | 2   | SN: 35398-UP    |
| 12   | 6151-81-4520 | WIRE, 265MM               | 1   | SN: 35398-UP    |
| 13   | 08038-00519  | CAP                       | 3   | SN: 35398-UP    |
| 14   | 600-815-2170 | SWITCH                    | 1   | SN: 35398-UP    |
| 15   | 01435-20612  | BOLT                      | 2   | SN: 35398-UP    |
| 16   | 09920-00150  | LIQUID GASKET, LG-7, 150G | -2  | SN: 35398-UP    |

Catalog signs: □ part above may be used instead

Reference: 0131




PJ35118

Reference: 0135

## 030050 AFTER COOLER AND PIPING

| Item | Part No.     | Part Name          | Qty | Options      |
|------|--------------|--------------------|-----|--------------|
| 1    | 6209-61-4100 | AFTER COOLER ASS'Y | 1   | SN: 35398-UP |
| 2    | 6209-11-4610 | TUBE               | 1   | SN: 35398-UP |
| 3    | 6209-11-4620 | TUBE               | 1   | SN: 35398-UP |
| 4    | 6209-11-4691 | HOSE               | 1   | SN: 35398-UP |
| 5    | 6209-11-4681 | HOSE               | 1   | SN: 35398-UP |
| 6    | 208-09-11120 | CLAMP              | 8   | SN: 35398-UP |
| 7    | 6207-11-4390 | HOSE               | 1   | SN: 35398-UP |
| 8    | 07281-00709  | CLAMP              | 2   | SN: 35398-UP |
| 9    | 6209-11-4380 | HOSE               | 1   | SN: 35398-UP |
| 10   | 07281-00809  | CLAMP              | 4   | SN: 35398-UP |
| 11   | 6209-11-4640 | CLAMP              | 1   | SN: 35398-UP |
| 12   | 6209-11-4650 | CLAMP              | 1   | SN: 35398-UP |
| 13   | 01435-21025  | BOLT               | 2   | SN: 35398-UP |
| 14   | 6209-11-4660 | BRACKET            | 1   | SN: 35398-UP |
| 15   | 6134-11-5120 | SPACER             | 2   | SN: 35398-UP |
| 16   | 01435-21070  | BOLT               | 2   | SN: 35398-UP |
| 17   | 07283-27060  | CLIP               | 1   | SN: 35398-UP |
| 18   | 01599-01011  | NUT                | 2   | SN: 35398-UP |
| 19   | 01643-31032  | WASHER             | 2   | SN: 35398-UP |
| 20   | 6110-23-6490 | SPACER             | 4   | SN: 48447-UP |

Reference: 0135




Reference: 0141

## 030060 AIR CLEANER AND CONNECTION (SINGLE ELEMENT TYPE) (#35398-81675)

| Item | Part No.     | Part Name                      | Qty | Options         |
|------|--------------|--------------------------------|-----|-----------------|
| 1    | 6207-81-7210 | BODY                           | 1   | SN: 35398-@     |
|      | 600-181-6540 | ELEMENT ASS'Y                  | 1   | SN: 35398-@     |
| 2    |              | • ☆ ELEMENT                    | 1   | SN: 35398-@     |
| 3    | 600-181-6570 | • NUT,WING                     | 1   | SN: 35398-@     |
| 4    | 600-181-6580 | • WASHER,SEAL                  | 1   | SN: 35398-@     |
| 5    | 600-181-6590 | VALVE                          | 1   | SN: 35398-@     |
| 6    | 6207-81-7190 | BAND                           | 2   | SN: 35398-@     |
| 6    | 6110-21-6530 | PIN                            | 2   | SN: 35398-@     |
| 6    | 6110-21-6540 | PIN, WITH THREAD               | 2   | SN: 35398-@     |
| 7    | 6110-23-6520 | BOLT                           | 2   | SN: 35398-@     |
| 8    | 6207-11-4882 | AIR DUCT ASS'Y                 | 1   | SN: 35398-@     |
| 8    | 6207-11-4881 | □ AIR DUCT ASS'Y               | 1   | SN: 35398-81675 |
| 9    | 6207-11-4990 | • INSULATOR (K1)               | 1   | SN: 48447-81675 |
| 9    | 6207-11-4990 | • INSULATOR                    | 1   | SN: 35398-48446 |
| 10   | 6207-11-4980 | • INSULATOR (K1)               | 1   | SN: 48447-81675 |
| 10   | 6207-11-4980 | • INSULATOR                    | 1   | SN: 35398-48446 |
| 11   | 20D-09-11130 | CLAMP                          | 1   | SN: 35398-@     |
| 12   | 207-09-11120 | CLAMP                          | 1   | SN: 35398-81675 |
| 13   | 6207-11-4910 | PLATE                          | 1   | SN: 35398-@     |
| 14   | 6136-11-5120 | SPACER                         | 2   | SN: 35398-@     |
| 15   | 01436-01005  | BOLT                           | 2   | SN: 48447-@     |
| 15   | 01436-21005  | □ BOLT                         | 2   | SN: 35398-48446 |
| 16   | 01435-20820  | BOLT                           | 2   | SN: 35398-@     |
| 17   | 01584-00806  | NUT                            | 2   | SN: 35398-@     |
| 18   | 6201-81-6560 | SPACER                         | 2   | SN: 35398-@     |
| 19   | 08670-12001  | INDICATOR,DUST (NOT SHOWN)     | 1   | SN: (45001)-@   |
| 20   | 09637-00661  | PLATE, INSTRUCTION,(NOT SHOWN) | 1   | SN: (45001)-@   |

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead

Reference: 0141



PJ37631A


Reference: 0141A

## 030070 AIR CLEANER AND CONNECTION (SINGLE ELEMENT TYPE) (#81676-)

| Item | Part No.     | Part Name                      | Qty | Options        |
|------|--------------|--------------------------------|-----|----------------|
| 1    | 6207-81-7210 | BODY                           | 1   | SN: 35398-UP   |
|      | 600-181-6540 | ELEMENT ASS'Y                  | 1   | SN: 35398-UP   |
| 2    |              | • ☆ ELEMENT                    | 1   | SN: 35398-UP   |
| 3    | 600-181-6570 | • NUT,WING                     | 1   | SN: 35398-UP   |
| 4    | 600-181-6580 | • WASHER,SEAL                  | 1   | SN: 35398-UP   |
| 5    | 600-181-6590 | VALVE                          | 1   | SN: 35398-UP   |
| 6    | 6207-81-7190 | BAND                           | 2   | SN: 35398-UP   |
| 6    | 6110-21-6530 | PIN                            | 2   | SN: 35398-UP   |
| 6    | 6110-21-6540 | PIN, WITH THREAD               | 2   | SN: 35398-UP   |
| 7    | 6110-23-6520 | BOLT                           | 2   | SN: 35398-UP   |
|      | 6207-11-4882 | AIR DUCT ASS'Y                 | 1   | SN: 81676-UP   |
| 8    | 6207-11-4971 | • AIR DUCT                     | 1   | SN: 81676-UP   |
| 9    | 6207-11-4991 | • INSULATOR (K1)               | 1   | SN: 81676-UP   |
| 10   | 6207-11-4981 | • INSULATOR (K1)               | 1   | SN: 81676-UP   |
| 11   | 20D-09-11130 | CLAMP                          | 1   | SN: 35398-UP   |
| 12   | 207-09-11120 | CLAMP                          | 2   | SN: 81676-UP   |
| 13   | 6207-11-4910 | PLATE                          | 1   | SN: 35398-UP   |
| 14   | 6136-11-5120 | SPACER                         | 2   | SN: 35398-UP   |
| 15   | 01436-01005  | BOLT                           | 2   | SN: 48447-UP   |
| 16   | 01435-20820  | BOLT                           | 2   | SN: 35398-UP   |
| 17   | 01584-00806  | NUT                            | 2   | SN: 35398-UP   |
| 18   | 6201-81-6560 | SPACER                         | 2   | SN: 35398-UP   |
| 19   | 08670-12001  | INDICATOR,DUST (NOT SHOWN)     | 1   | SN: (45001)-UP |
| 20   | 09637-00661  | PLATE, INSTRUCTION,(NOT SHOWN) | 1   | SN: (45001)-UP |

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0141A



PJ35083

Reference: 0142

## 030080 AIR CLEANER AND CONNECTION (DOUBLE ELEMENT TYPE) (#35398-81675)

| Item | Part No.     | Part Name                       | Qty | Options         |
|------|--------------|---------------------------------|-----|-----------------|
| 1    | 6207-81-7210 | BODY                            | 1   | SN: 35398-@     |
|      | 600-181-6050 | ELEMENT ASS'Y                   | 1   | SN: 35398-@     |
| 2    |              | • ☆ ELEMENT, INNER              | 1   | SN: 35398-@     |
| 3    | 600-181-9671 | • NUT                           | 1   | SN: 35398-@     |
| 4    | 600-181-7511 | • WASHER, SEAL                  | 1   | SN: 35398-@     |
|      | 600-181-6540 | • ELEMENT ASS'Y, OUTER          | 1   | SN: 35398-@     |
| 5    |              | • • ☆ ELEMENT, OUTER            | 1   | SN: 35398-@     |
| 6    | 600-181-6570 | • • NUT, WING                   | 1   | SN: 35398-@     |
| 7    | 600-181-6580 | • • WASHER, SEAL                | 1   | SN: 35398-@     |
| 8    | 600-181-6590 | VALVE                           | 1   | SN: 35398-@     |
| 9    | 6207-81-7190 | BAND                            | 2   | SN: 35398-@     |
| 9    | 6110-21-6530 | PIN                             | 2   | SN: 35398-@     |
| 9    | 6110-21-6540 | PIN, WITH THREAD                | 2   | SN: 35398-@     |
| 10   | 6110-23-6520 | BOLT                            | 2   | SN: 35398-@     |
| 11   | 6207-11-4882 | AIR DUCT ASS'Y                  | 1   | SN: 35398-@     |
| 11   | 6207-11-4881 | □ AIR DUCT ASS'Y                | 1   | SN: 35398-81675 |
| 12   | 6207-11-4990 | • INSULATOR (K1)                | 1   | SN: 48447-81675 |
| 12   | 6207-11-4990 | • INSULATOR                     | 1   | SN: 35398-48446 |
| 13   | 6207-11-4980 | • INSULATOR (K1)                | 1   | SN: 48447-81675 |
| 13   | 6207-11-4980 | • INSULATOR                     | 1   | SN: 35398-48446 |
| 14   | 20D-09-11130 | CLAMP                           | 1   | SN: 35398-@     |
| 15   | 207-09-11120 | CLAMP                           | 1   | SN: 35398-81675 |
| 16   | 6207-11-4910 | PLATE                           | 1   | SN: 35398-@     |
| 17   | 6136-11-5120 | SPACER                          | 2   | SN: 35398-@     |
| 18   | 01436-01005  | BOLT                            | 2   | SN: 48447-@     |
| 18   | 01436-21005  | □ BOLT                          | 2   | SN: 35398-48446 |
| 19   | 01435-20820  | BOLT                            | 2   | SN: 35398-@     |
| 20   | 01584-00806  | NUT                             | 2   | SN: 35398-@     |
| 21   | 6201-81-6560 | SPACER                          | 2   | SN: 35398-@     |
| 22   | 08670-12001  | INDICATOR, DUST (NOT SHOWN)     | 1   | SN: (45001)-@   |
| 23   | 09637-00161  | PLATE, INSTRUCTION, (NOT SHOWN) | 1   | SN: (45001)-@   |

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead



# Get the complete PDF catalogue

Komatsu SA6D95L-1C-C S/N 35398-UP

**\$89**

with PayPal | Store cart: \$99

**Buy this PDF on Manuals Komatsu**

Check the model, serial range and language before payment.  
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.