




Reference: 0101


030010 CYLINDER HEAD(#10001-10318)

Item	Part No.	Part Name	Qty	Options
	6164-11-1100	CYLINDER HEAD ASS'Y,VALVE LESS	8	SN: 10001-@
1		• ☆ HEAD,CYLINDER	1	SN: 10001-@
2	6162-13-1130	• SLEEVE	1	SN: 10001-@
3	6162-12-1152	• O-RING (K1)	1	SN: 10001-@
4	6162-13-1330	• INSERT,INTAKE VALVE (STD)	2	SN: 10001-@
	6162-19-1330	• INSERT ? 0.25MM,INTAKE VALVE (OS)	2	SN: 10001-@
	6162-18-1330	• INSERT ? 0.50MM,INTAKE VALVE (OS)	2	SN: 10001-@
	6162-17-1330	• INSERT ? 0.75MM,INTAKE VALVE (OS)	2	SN: 10001-@
	6162-16-1330	• INSERT ? 1.00MM,INTAKE VALVE (OS)	2	SN: 10001-@
5	6162-13-1320	• INSERT,EXHAUST VALVE (STD)	2	SN: 10001-@
	6162-19-1320	• INSERT ? 0.25MM,EXHAUST VALVE (OS)	2	SN: 10001-@
	6162-18-1320	• INSERT ? 0.50MM,EXHAUST VALVE (OS)	2	SN: 10001-@
	6162-17-1320	• INSERT ? 0.75MM,EXHAUST VALVE (OS)	2	SN: 10001-@
	6162-16-1320	• INSERT ? 1.00MM,EXHAUST VALVE (OS)	2	SN: 10001-@
6	6162-16-1341	• GUIDE,VALVE	4	SN: 10001-@
7	6162-13-1160	• TUBE,PUSH ROD	2	SN: 10001-@
8	07000-63028	• O-RING (K1)	2	SN: 10001-@
9	6162-13-1140	• GUIDE,CROSSHEAD	2	SN: 10001-@
10	6164-11-1210	• PLUG	1	SN: 10001-@
11	07046-11516	• PLUG	1	SN: 10001-@
12	07043-50108	• PLUG	4	SN: 10199-@
	07043-50108	• PLUG	5	SN: 10001-10198
13	07043-50211	• PLUG	1	SN: 10001-@
14	07043-50617	• PLUG	5	SN: 10001-@
15	6162-13-1150	• PLUG,EXPANSION	12	SN: 10199-@
	6162-13-1150	• PLUG,EXPANSION	11	SN: 10001-10198
16	6162-13-1410	• PIN	2	SN: 10001-@
17	6162-43-4110	VALVE,INTAKE	16	SN: 10001-@
18	6164-41-4210	VALVE,EXHAUST	16	SN: 10001-@
19	6162-43-4410	SPRING,VALVE OUTER	32	SN: 10001-@
20	6162-43-4420	SPRING,VALVE INNER	32	SN: 10001-@
21	6162-43-4430	SEAT,SPRING	32	SN: 10001-@
22	6162-43-4511	SEAT,SPRING	32	SN: 10001-@
23	6162-42-4520	COTTER,VALVE	64	SN: 10001-@

Item	Part No.	Part Name	Qty	Options
24	6162-43-5610	CROSSHEAD	16	SN: 10001-@
25	6162-43-5640	SCREW,ADJUST	16	SN: 10001-@
26	6127-41-5630	NUT	16	SN: 10001-@
27	6164-11-1813	GASKET,HEAD (K1)	8	SN: 10319-@
	6164-11-1811	☐ GASKET,HEAD (K1)	8	SN: 10001-10318
28	6162-13-1610	BOLT,HEAD	48	SN: 10001-@
29	6162-13-1620	WASHER	48	SN: 10001-@

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: 0101



Reference: 0101A


030020 CYLINDER HEAD(#10319-)

Item	Part No.	Part Name	Qty	Options
	6164-11-1100	CYLINDER HEAD ASS'Y,VALVE LESS	8	SN: 10001-UP
1		• ☆ HEAD,CYLINDER	1	SN: 10001-UP
2	6162-13-1130	• SLEEVE	1	SN: 10001-UP
3	6162-12-1152	• O-RING (K1)	1	SN: 10001-UP
4	6162-13-1330	• INSERT,INTAKE VALVE (STD)	2	SN: 10001-UP
	6162-19-1330	• INSERT ? 0.25MM,INTAKE VALVE (OS)	2	SN: 10001-UP
	6162-18-1330	• INSERT ? 0.50MM,INTAKE VALVE (OS)	2	SN: 10001-UP
	6162-17-1330	• INSERT ? 0.75MM,INTAKE VALVE (OS)	2	SN: 10001-UP
	6162-16-1330	• INSERT ? 1.00MM,INTAKE VALVE (OS)	2	SN: 10001-UP
5	6162-13-1321	• INSERT,EXHAUST VALVE (STD)	2	SN: 10427-UP
	6162-13-1320	• □ INSERT,EXHAUST VALVE (STD)	2	SN: 10001-10426
	6162-19-1321	• INSERT ? 0.25MM,EXHAUST VALVE (OS)	2	SN: 10427-UP
	6162-19-1320	• □ INSERT ? 0.25MM,EXHAUST VALVE (OS)	2	SN: 10001-10426
	6162-18-1321	• INSERT ? 0.50MM,EXHAUST VALVE (OS)	2	SN: 10427-UP
	6162-18-1320	• □ INSERT ? 0.50MM,EXHAUST VALVE (OS)	2	SN: 10001-10426
	6162-17-1321	• INSERT ? 0.75MM,EXHAUST VALVE (OS)	2	SN: 10427-UP
	6162-17-1320	• □ INSERT ? 0.75MM,EXHAUST VALVE (OS)	2	SN: 10001-10426
	6162-16-1321	• INSERT ? 1.00MM,EXHAUST VALVE (OS)	2	SN: 10427-UP
	6162-16-1320	• □ INSERT ? 1.00MM,EXHAUST VALVE (OS)	2	SN: 10001-10426
6	6162-16-1341	• GUIDE,VALVE	4	SN: 10001-UP
7	6162-13-1160	• TUBE,PUSH ROD	2	SN: 10001-UP
8	07000-63028	• O-RING (K1)	2	SN: 10001-UP
9	6162-13-1140	• GUIDE,CROSSHEAD	2	SN: 10001-UP
10	6164-11-1210	• PLUG	1	SN: 10001-UP
11	07046-11516	• PLUG	1	SN: 10001-UP
12	07043-50108	• PLUG	4	SN: 10199-UP
13	07043-50211	• PLUG	1	SN: 10001-UP
14	07043-50617	• PLUG	5	SN: 10001-UP
15	6162-13-1150	• PLUG,EXPANSION	12	SN: 10199-UP
16	6162-13-1410	• PIN	2	SN: 10001-UP
17	6162-43-4110	VALVE,INTAKE	16	SN: 10001-UP
18	6164-41-4210	VALVE,EXHAUST	16	SN: 10001-UP
19	6162-43-4410	SPRING,VALVE OUTER	32	SN: 10001-UP
20	6162-43-4420	SPRING,VALVE INNER	32	SN: 10001-UP
21	6162-43-4430	SEAT,SPRING	32	SN: 10001-UP
22	6162-43-4511	SEAT,SPRING	32	SN: 10001-UP
23	6162-42-4520	COTTER,VALVE	64	SN: 10001-UP
24	6162-43-5610	CROSSHEAD	16	SN: 10001-UP
25	6162-43-5640	SCREW,ADJUST	16	SN: 10001-UP
26	6127-41-5630	NUT	16	SN: 10001-UP
27	6164-17-1813	GASKET,HEAD (K1)	8	SN: 10384-UP
	6164-11-1813	□ GASKET,HEAD (K1)	8	SN: 10319-10383
28	6162-13-1820	• GROMMET,OIL	2	SN: 10319-UP
29	6162-13-1831	• GROMMET,WATER	1	SN: 10319-UP
30	6162-13-1840	• GROMMET,OIL	1	SN: 10319-UP
31	6162-13-1850	• GROMMET,WATER	1	SN: 10319-UP
32	6164-11-1821	• GROMMET,OIL	1	SN: 10319-UP

Item	Part No.	Part Name	Qty	Options
33	6162-13-1611	BOLT,HEAD	48	SN: 10321-UP
	6162-13-1610	☐ BOLT,HEAD	48	SN: 10001-10320
34	6162-13-1620	WASHER	48	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: 0101A



PJ30956

Reference: 0111


030030 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
1	6164-11-7110	HOUSING,ROCKER ARM	8	SN: 10001-UP
	6162-43-5400	ROCKER ARM ASS'Y	8	SN: 10001-UP
2		• ☆ ARM,ROCKER	1	SN: 10001-UP
3	6162-43-5420	• BUSHING	1	SN: 10001-UP
4	6162-43-5340	• RIVET	2	SN: 10001-UP
5	6127-41-5445	SCREW,ADJUST	8	SN: 10001-UP
6	6127-41-5431	NUT	8	SN: 10001-UP
	6162-43-5500	ROCKER ARM ASS'Y	8	SN: 10001-UP
7		• ☆ ARM,ROCKER	1	SN: 10001-UP
8	6162-43-5420	• BUSHING	1	SN: 10001-UP
9	6162-43-5340	• RIVET	2	SN: 10001-UP
10	6127-41-5445	SCREW,ADJUST	8	SN: 10001-UP
11	6127-41-5431	NUT	8	SN: 10001-UP
	6162-43-5300	ROCKER ARM SHAFT A.	8	SN: 10001-UP
12		• ☆ SHAFT	1	SN: 10001-UP
13	6162-43-2420	• PIN,DOWEL	1	SN: 10001-UP
14	6162-43-5320	COLLAR	8	SN: 10001-UP
15	01011-31215	BOLT	8	SN: 10001-UP
16	01643-31232	WASHER	8	SN: 10001-UP
17	01010-31255	BOLT	8	SN: 10298-UP
	01010-31245	BOLT	8	SN: 10001-10297
18	6164-41-5390	SPACER	8	SN: 10298-UP
	01643-31232	WASHER	8	SN: 10001-10297
	6164-11-7803	GASKET ASS'Y (K1)	8	SN: 10445-UP
	6164-11-7802	□ GASKET ASS'Y (K1)	8	SN: 10438-10444
	6164-11-7801	□ GASKET ASS'Y (K1)	8	SN: 10269-10437
	6164-11-7800	□ GASKET ASS'Y (K1)	8	SN: 10001-10268
19	6164-11-7813	• GASKET	1	SN: 10445-UP
	6164-11-7812	• □ GASKET	1	SN: 10438-10444
	6164-11-7811	• GASKET	1	SN: 10269-10437
	6164-11-7810	• □ GASKET	1	SN: 10001-10268
20	6162-13-7822	• PACKING	1	SN: 10438-UP
	6162-13-7821	• PACKING	1	SN: 10269-10437
	6162-13-7820	• □ PACKING	1	SN: 10001-10268

Item	Part No.	Part Name	Qty	Options
21	01010-31290	BOLT	48	SN: 10001-UP
22	01643-31232	WASHER	48	SN: 10001-UP

Catalog signs: ☆ not supplied separately; assembly only ☐ part above may be used instead

Reference: 0111



PE30859


Reference: 0115

030040 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6162-13-8112	COVER,HEAD	8	SN: 10001-UP
2	6162-13-8810	GASKET (K1)	8	SN: 10001-UP
3	01010-31055	BOLT	40	SN: 10001-UP
4	01602-01030	WASHER,SPRING	40	SN: 10001-UP
5	01640-01016	WASHER	40	SN: 10001-UP
6	6162-13-8181	PACKING (K1)	8	SN: 10001-UP
	6162-13-8180	☒ PACKING (K1)	8	SN: (10001-10413)

Catalog signs: ☒ discontinued: use part above

Reference: 0115



Reference: 0131


030050 AIR INTAKE MANIFOLD AND AFTER COOLER

Item	Part No.	Part Name	Qty	Options
1	6164-11-4131	MANIFOLD,INTAKE	1	SN: 10001-UP
2	07043-50108	PLUG	4	SN: 10001-UP
3	07043-00211	PLUG	1	SN: 10001-UP
4	07043-00617	PLUG	1	SN: 10001-UP
5	07043-50108	PLUG	1	SN: 10001-UP
6	6164-21-1190	PIN	2	SN: 10001-UP
7	6164-11-4120	GROMMET (K1)	1	SN: 10001-UP
8	6164-11-4151	GASKET (K1)	1	SN: 10003-UP
	6164-11-4150	☐ GASKET (K1)	1	SN: 10001-10002
9	01010-31035	BOLT	3	SN: 10001-UP
10	01010-31085	BOLT	1	SN: 10001-UP
11	01011-51050	BOLT	5	SN: 10294-UP
	01011-31050	☐ BOLT	5	SN: 10001-10293
12	01011-31065	BOLT	1	SN: 10001-UP
13	01011-31075	BOLT	5	SN: 10001-UP
13A	562-15-16410	BOLT	2	SN: 10001-UP
13B	01011-31075	BOLT,(SEE FIG.0401)	3	SN: 10001-UP
14	01602-01030	WASHER,SPRING	20	SN: 10001-UP
15	01640-01016	WASHER	17	SN: 10001-UP
16	6165-11-4811	CONNECTOR	8	SN: 10129-UP
	6165-11-4810	☐ CONNECTOR	8	SN: 10001-10128
17	6164-11-4850	O-RING (K1)	8	SN: 10001-UP
18	6164-11-4871	O-RING (K1)	8	SN: 10255-UP
	6164-11-4870	☐ O-RING (K1)	8	SN: 10001-10254
19	01010-31025	BOLT	32	SN: 10001-UP
20	01640-01016	WASHER	32	SN: 10001-UP
21	6164-61-6150	HOUSING	1	SN: 10001-UP
22	6164-61-6111	CORE ASS'Y	1	SN: 10295-UP
	6164-61-6110	☐ CORE ASS'Y	1	SN: 10001-10294
23	6164-61-6140	HOUSING	1	SN: 10001-UP
24	04020-01024	PIN,DOWEL	2	SN: 10001-UP
25	6164-62-6122	CONNECTOR	1	SN: 10003-UP
	6164-62-6121	☐ CONNECTOR	1	SN: 10001-10002
26	6164-61-6130	GASKET (K1)	3	SN: 10001-UP
27	113-15-21240	BOLT	4	SN: 10003-UP
	700-752-31110	☐ BOLT	4	SN: 10001-10002
28	01602-21030	WASHER,SPRING	4	SN: 10001-UP
29	01640-21016	WASHER	4	SN: 10001-UP
30	6164-11-4330	GASKET (K1)	1	SN: 10001-UP
31	6164-61-7290	BOLT	14	SN: 10001-UP
32	01602-01030	WASHER,SPRING	14	SN: 10001-10210
33	01640-01016	WASHER	14	SN: 10001-UP
34	6164-11-4230	CONNECTOR	1	SN: 10001-UP
35	6164-11-4220	CONNECTOR	1	SN: 10001-UP
36	07043-00108	PLUG	4	SN: 10001-UP
37	6164-11-4240	GASKET (K1)	2	SN: 10001-UP
38	01010-31085	BOLT	3	SN: 10211-UP

Item	Part No.	Part Name	Qty	Options
	01010-31090	BOLT	3	SN: 10001-10210
39	01011-31025	BOLT	3	SN: 10001-UP
40	01602-01030	WASHER,SPRING	6	SN: 10001-10210
41	01640-01016	WASHER	6	SN: 10001-UP
42	01010-31075	BOLT	2	SN: 10211-UP
	01010-31080	BOLT	2	SN: 10001-10210
43	01011-31005	BOLT	4	SN: 10211-UP
	01011-31010	BOLT	4	SN: 10001-10210
44	01602-01030	WASHER,SPRING	6	SN: 10001-10210
45	01640-01016	WASHER	6	SN: 10001-UP

Catalog signs: ☐ part above may be used instead

Reference: 0131



Reference: 0141

030060 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
1	6164-81-7430	BODY	1	SN: 10001-UP
2	6164-81-7440	BODY	1	SN: 10001-UP
	600-181-5980	ELEMENT ASS'Y	2	SN: 10001-UP
	600-181-5970	• ELEMENT ASS'Y	1	SN: 10001-UP
3		• ☆ ELEMENT, OUTER	1	SN: 10001-UP
4	600-181-5940	• PACKING ASS'Y	1	SN: 10001-UP
5	600-181-5660	• NUT, WING	1	SN: 10001-UP
6	600-181-5670	• CLIP	1	SN: 10001-UP
7		• ☆ ELEMENT, INNER	1	SN: 10001-UP
8	600-181-7511	• WASHER, SEAL	1	SN: 10001-UP
9	600-181-5640	• NUT	1	SN: 10001-UP
	600-181-5560	CYCLONE ASS'Y	1	SN: 10001-UP
10	600-181-5370	• CYCLONE	1	SN: 10001-UP
11	600-181-5380	• CONNECTOR	1	SN: 10001-UP
12	600-181-5390	• PACKING	1	SN: 10001-UP
13	600-181-5810	• BRACKET	1	SN: 10001-UP
14	600-181-5820	• BRACKET	1	SN: 10001-UP
15	600-181-5830	• BRACKET	1	SN: 10001-UP
16	600-181-5840	• BRACKET	1	SN: 10001-UP
17	01010-31030	• BOLT	8	SN: 10001-UP
18	01602-01030	• WASHER, SPRING	8	SN: 10001-UP
19	01640-01016	• WASHER	8	SN: 10001-UP
20	01010-31020	• BOLT	4	SN: 10001-UP
21	01602-01030	• WASHER, SPRING	4	SN: 10001-UP
22	600-181-5570	HOSE	2	SN: 10001-UP
23	07281-02709	CLAMP	4	SN: 10001-UP
24	01010-31025	BOLT	4	SN: 10001-UP
25	01642-01016	WASHER	4	SN: 10001-UP
26	6164-11-4722	PLATE	1	SN: 10001-UP
27	6164-11-4820	BRACKET	1	SN: 10001-UP
28	6164-11-4830	BRACKET	1	SN: 10001-UP
29	01010-31220	BOLT	8	SN: 10001-UP
30	01602-01236	WASHER, SPRING	8	SN: 10001-UP
31	6691-13-4610	BAND ASS'Y	2	SN: 10001-UP
32	6643-11-4641	BOLT	2	SN: 10001-UP
33	04530-01018	BOLT	3	SN: 10001-UP
34	01643-31032	WASHER	3	SN: 10001-UP
35	6164-11-5491	BLOCK	1	SN: 10269-UP
	6164-12-5490	BRACKET	1	SN: 10001-10268
36	01011-31450	BOLT	2	SN: 10269-UP
	01010-31445	BOLT	2	SN: 10001-10268
37	01010-31435	BOLT	2	SN: 10001-UP
38	01602-01442	WASHER, SPRING	2	SN: 10001-UP
39	01602-01442	WASHER, SPRING	2	SN: 10001-UP
40	01643-31445	WASHER	2	SN: 10269-UP
41	6164-11-4780	BRACKET	1	SN: 10001-UP
42	01011-31215	BOLT	2	SN: 10001-UP

Get the complete PDF catalogue

Komatsu SA8V170-1A S/N 10001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.