




Reference: B0000-01A0


030010 ENGINE (AIR CLEANER MOUNTING PARTS)(#50001-50044)

Item	Part No.	Part Name	Qty	Options
	427-Z04-1210	AIR CLEANER ASS'Y	4	SN: 50005-@
	6164-81-7511	☐ AIR CLEANER ASS'Y	4	SN: 50001-50004
1	427-Z04-1290	• BODY	1	SN: 50005-@
1	6164-81-7531	• BODY	1	SN: 50001-50004
2	6127-81-7412	• ELEMENT,INNER	1	SN: 50001-@
3	6128-81-7321	• ELEMENT,OUTER	1	SN: 50001-@
4	600-181-4370	• NUT	1	SN: 50001-@
5	600-181-7511	• WASHER,SEAL	1	SN: 50001-@
6	600-181-4420	• NUT,WING	1	SN: 50001-@
7	600-181-4430	• CLIP	1	SN: 50001-@
8	600-181-4440	• GASKET	1	SN: 50001-@
9	6127-11-4360	BAND ASS'Y	8	SN: 50001-@
10	6643-11-4641	BOLT	8	SN: 50001-@
11	42C-01-11620	PRECLEANER	4	SN: 50001-50044
12	01016-51045	• BOLT	4	SN: 50001-50044
13	01580-01008	• NUT	4	SN: 50001-50044
14	6128-11-5180	HOOD ASS'Y	4	SN: 50001-@
15	42C-01-11213	TUBE	2	SN: 50001-@
15	42C-01-11212	☒ TUBE	2	SN: (50001-50041)
16	42C-01-11225	TUBE	1	SN: 50001-@
16	42C-01-11224	☒ TUBE	1	SN: (50001-50041)
16	42C-01-11223	☒ TUBE	1	SN: (50001-50010)
17	42C-01-13280	BRACKET	3	SN: 50042-@
18	01010-81235	BOLT	6	SN: 50042-@
19	01643-31232	WASHER	6	SN: 50042-@
20	428-62-14640	CLIP	3	SN: 50042-@
21	01597-01211	NUT	6	SN: 50042-@
22	01643-31232	WASHER	6	SN: 50042-@
23	42C-01-11235	TUBE	1	SN: 50001-@
23	42C-01-11234	☒ TUBE	1	SN: (50001-50041)
23	42C-01-11233	☒ TUBE	1	SN: (50001-50010)
24	6127-81-4823	GASKET	4	SN: 50001-@
25	01580-01008	NUT	32	SN: 50001-@
26	01602-21030	WASHER	32	SN: 50001-@
27	42C-01-11270	HOSE	2	SN: 50001-@
28	07299-00160	CLAMP,HOSE	8	SN: 50040-@
28	07289-00160	☐ CLAMP,HOSE	8	SN: 50001-50039
29	42C-01-11263	HOSE	2	SN: 50013-@
29	42C-01-11262	HOSE	2	SN: 50011-50012
29	42C-01-11261	☐ HOSE	2	SN: 50001-50010
30	07299-00160	CLAMP,HOSE	6	SN: 50040-@
30	07289-00160	☐ CLAMP,HOSE	4	SN: 50001-50039
31	42C-01-13190	COVER	1	SN: 50031-@
32	07289-00170	CLAMP,HOSE	3	SN: 50031-@
33	07289-00145	CLAMP,HOSE	2	SN: 50001-50010
34	42C-01-11780	INDICATOR	4	SN: 50001-50044
35	08670-22001	INDICATOR	4	SN: 50001-50044

Item	Part No.	Part Name	Qty	Options
36	281-03-12230	HOSE	4	SN: 50001-50044
37	07281-00609	CLAMP	8	SN: 50001-50044
38	42C-01-11311	TUBE,L.H.	1	SN: 50001-50044
39	42C-01-11321	TUBE,R.H.	1	SN: 50001-50044
40	42C-01-11351	BRACKET	2	SN: 50001-50044
41	07283-25150	CLIP	2	SN: 50001-50044
42	01597-01009	NUT	4	SN: 50001-@
43	01643-31032	WASHER	4	SN: 50001-@
44	01435-01230	BOLT	4	SN: 50001-@

Catalog signs: ☐ part above may be used instead ☒ discontinued: use part above

Reference: B0000-01A0




Reference: B0000-01A0A

030020 ENGINE (AIR CLEANER MOUNTING PARTS)(#50045-)

Item	Part No.	Part Name	Qty	Options
	427-Z04-1210	AIR CLEANER ASS'Y	4	SN: 50005-UP
1	427-Z04-1290	• BODY	1	SN: 50005-UP
2	6127-81-7412	• ELEMENT,INNER	1	SN: 50001-UP
3	6128-81-7321	• ELEMENT,OUTER	1	SN: 50001-UP
4	600-181-4370	• NUT	1	SN: 50001-UP
5	600-181-7511	• WASHER,SEAL	1	SN: 50001-UP
6	600-181-4420	• NUT,WING	1	SN: 50001-UP
7	600-181-4430	• CLIP	1	SN: 50001-UP
8	600-181-4440	• GASKET	1	SN: 50001-UP
9	6127-11-4360	BAND ASS'Y	8	SN: 50001-UP
10	6643-11-4641	BOLT	8	SN: 50001-UP
11	600-183-7521	CLEANER	4	SN: 50045-UP
12	6128-11-5180	HOOD ASS'Y	4	SN: 50001-UP
13	42C-01-11213	TUBE	2	SN: 50001-UP
14	42C-01-11225	TUBE	1	SN: 50001-UP
15	42C-01-13280	BRACKET	3	SN: 50042-UP
16	01010-81235	BOLT	6	SN: 50042-UP
17	01643-31232	WASHER	6	SN: 50042-UP
18	428-62-14640	CLIP	3	SN: 50042-UP
19	01597-01211	NUT	6	SN: 50042-UP
20	01643-31232	WASHER	6	SN: 50042-UP
21	42C-01-11235	TUBE	1	SN: 50001-UP
22	6127-81-4823	GASKET	4	SN: 50001-UP
23	01580-01008	NUT	32	SN: 50001-UP
24	01602-21030	WASHER	32	SN: 50001-UP
25	42C-01-11270	HOSE	2	SN: 50001-UP
26	07299-00160	CLAMP	8	SN: 50040-UP
27	42C-01-11263	HOSE	2	SN: 50013-UP
28	07299-00160	CLAMP	6	SN: 50040-UP
29	42C-01-13190	COVER	1	SN: 50031-UP
30	07289-00170	CLAMP	3	SN: 50031-UP
31	42C-01-11780	INDICATOR	4	SN: 50001-UP
32	08670-22001	INDICATOR,DUST	4	SN: 50001-UP
33	6162-13-5870	HOSE	8	SN: 50045-UP

Item	Part No.	Part Name	Qty	Options
34	07281-00709	CLAMP	16	SN: 50045-UP
35	42C-01-13630	TUBE	4	SN: 50045-UP
36	01010-81225	BOLT	8	SN: 50045-UP
37	01643-31232	WASHER	8	SN: 50045-UP
38	42C-01-13610	TUBE,L.H.	1	SN: 50045-UP
39	42C-01-13620	TUBE	1	SN: 50045-UP
40	42C-01-13520	BRACKET	2	SN: 50045-UP
41	07283-37663	CLIP	2	SN: 50045-UP
42	01597-01009	NUT	4	SN: 50001-UP
43	01643-31032	WASHER	4	SN: 50001-UP
44	01435-01230	BOLT	4	SN: 50001-UP

Reference: B0000-01A0A



Reference: B0000-01A1


030030 ENGINE (AIR CLEANER MOUNTING PARTS) (LARGE CAPACITY) (#50001-50049)

Item	Part No.	Part Name	Qty	Options
	6240-81-7401	AIR CLEANER ASS'Y	4	SN: 50001-@
1	6240-81-7411	• BODY	1	SN: 50001-@
	600-185-6100	• ELEMENT ASS'Y	1	SN: 50001-@
2	600-184-1671	•• O-RING	1	SN: 50001-@
3	600-185-6110	•• ELEMENT, OUTER	1	SN: 50001-@
4		• ☆ ELEMENT, INNER	1	SN: 50001-@
5	600-184-1631	• COVER	1	SN: 50001-@
6	600-184-2810	• PLATE	1	SN: 50001-@
7	6240-11-9910	BAND	8	SN: 50001-@
8	6643-11-4641	BOLT	8	SN: 50001-@
9	42C-01-11620	PRECLEANER	4	SN: 50001-50049
10	01016-51045	• BOLT	4	SN: 50001-50049
11	01580-01008	• NUT	4	SN: 50001-50049
12	6128-11-5180	HOOD ASS'Y	4	SN: 50001-@
13	01016-31045	• BOLT	1	SN: 50001-@
14	01580-01008	• NUT	1	SN: 50001-@
15	42C-01-13120	TUBE	2	SN: 50001-@
16	42C-01-13130	TUBE	1	SN: 50001-@
17	42C-01-13140	TUBE	1	SN: 50001-@
18	42C-01-13150	HOSE	4	SN: 50001-@
19	07299-00160	CLAMP	4	SN: 50038-@
19	07289-00160	□ CLAMP, HOSE	4	SN: 50001-50037
20	42C-01-13290	CLAMP, HOSE	4	SN: 50001-@
21	42C-01-13160	BRACKET	4	SN: 50001-@
22	01010-81225	BOLT	8	SN: 50001-@
23	01643-31232	WASHER	8	SN: 50001-@
24	428-62-14640	CLIP	4	SN: 50001-@
25	01597-01211	NUT	8	SN: 50001-@
26	01643-31232	WASHER	8	SN: 50001-@
27	42C-01-11270	HOSE	2	SN: 50001-@
28	07299-00160	CLAMP	8	SN: 50038-@
28	07289-00160	□ CLAMP, HOSE	8	SN: 50001-50037
29	42C-01-11263	HOSE	2	SN: 50001-@
30	07299-00160	CLAMP	6	SN: 50038-@
30	07289-00160	□ CLAMP, HOSE	6	SN: 50001-50037
31	42C-01-13190	COVER	1	SN: 50031-@
32	07289-00170	CLAMP, HOSE	3	SN: 50031-@
33	42C-01-11780	INDICATOR	4	SN: 50001-@
34	08670-22001	INDICATOR	4	SN: 50001-@
35	281-03-12230	HOSE	4	SN: 50001-50049
36	07281-00609	CLAMP	8	SN: 50001-50049
37	42C-01-13170	TUBE	2	SN: 50001-50049
38	42C-01-13180	TUBE	2	SN: 50001-50049
39	01010-81020	BOLT	8	SN: 50001-@
40	01643-31032	WASHER	8	SN: 50001-@

Item	Part No.	Part Name	Qty	Options
41	427-01-11170	HOSE	4	SN: 50001-50049
42	07289-00045	CLAMP	8	SN: 50001-50049
43	42C-01-11311	TUBE,L.H.	1	SN: 50001-50049
44	42C-01-11321	TUBE,R.H.	1	SN: 50001-50049
45	42C-01-11351	BRACKET	2	SN: 50001-50049
46	07283-25150	CLIP	2	SN: 50001-50049
47	01597-01009	NUT	4	SN: 50001-@
48	01643-31032	WASHER	4	SN: 50001-@
49	01435-01230	BOLT	4	SN: 50001-@

Catalog signs: ☆ not supplied separately; assembly only ☐ part above may be used instead

Reference: B0000-01A1



Reference: B0000-01A1A


030040 ENGINE (AIR CLEANER MOUNTING PARTS) (LARGE CAPACITY) (#50050-)

Item	Part No.	Part Name	Qty	Options
1	6240-81-7402	AIR CLEANER ASS'Y	4	SN: 50054-UP
	6240-81-7401	AIR CLEANER ASS'Y	4	SN: 50001-50053
	6240-81-7411	• BODY	1	SN: 50001-UP
	600-185-6100	• ELEMENT ASS'Y	1	SN: 50001-UP
2	600-184-1671	• • O-RING	1	SN: 50001-UP
3	600-185-6110	• • ELEMENT, OUTER	1	SN: 50001-UP
4		• ☆ ELEMENT, INNER	1	SN: 50001-UP
5	600-184-1632	• COVER	1	SN: 50056-UP
5	600-184-1631	• □ COVER	1	SN: 50001-50055
6	600-184-2810	• PLATE	1	SN: 50001-UP
7	6240-11-9910	BAND	8	SN: 50001-UP
8	6643-11-4641	BOLT	8	SN: 50001-UP
9	600-183-7521	CLEANER	4	SN: 50051-UP
9	600-183-7520	PRE CLEANER	4	SN: 50050-50050
10	600-181-5470	HOOD	4	SN: 50075-UP
10	6128-11-5180	□ HOOD ASS'Y	4	SN: 50001-50074
11	01016-51045	• BOLT	1	SN: 50075-UP
11	01016-31045	• □ BOLT	1	SN: 50001-50074
12	01580-11008	• NUT	1	SN: 50075-UP
12	01580-01008	• □ NUT	1	SN: 50001-50074
13	42C-01-13120	TUBE	2	SN: 50001-UP
14	42C-01-13130	TUBE	1	SN: 50001-UP
15	42C-01-13140	TUBE	1	SN: 50001-UP
16	42C-01-13150	HOSE	4	SN: 50001-UP
17	07299-00160	CLAMP	4	SN: 50038-UP
18	42C-01-13290	CLAMP, HOSE	4	SN: 50001-UP
19	42C-01-13160	BRACKET	4	SN: 50001-UP
20	01010-81225	BOLT	8	SN: 50001-UP
21	01643-31232	WASHER	8	SN: 50001-UP
22	428-62-14640	CLIP	4	SN: 50001-UP
23	01597-01211	NUT	8	SN: 50001-UP
24	01643-31232	WASHER	8	SN: 50001-UP
25	42C-01-11270	HOSE	2	SN: 50001-UP
26	07299-00160	CLAMP	8	SN: 50038-UP
27	42C-01-11263	HOSE	2	SN: 50001-UP
28	07299-00160	CLAMP	6	SN: 50038-UP
29	42C-01-13190	COVER	1	SN: 50031-UP
30	07289-00170	CLAMP, HOSE	3	SN: 50031-UP
31	42C-01-11780	INDICATOR	4	SN: 50001-UP
32	08670-22001	INDICATOR	4	SN: 50001-UP
33	42C-01-13560	TUBE	1	SN: 50050-UP
34	42C-01-13550	TUBE	1	SN: 50050-UP
35	6162-13-5870	HOSE	4	SN: 50050-UP
36	07281-00709	CLAMP	8	SN: 50050-UP
37	42C-01-13540	TUBE	1	SN: 50050-UP

Item	Part No.	Part Name	Qty	Options
38	42C-01-13530	TUBE	1	SN: 50050-UP
39	01010-81020	BOLT	8	SN: 50001-UP
40	01643-31032	WASHER	8	SN: 50001-UP
41	07260-04111	HOSE	4	SN: 50050-UP
42	07289-00055	CLAMP	8	SN: 50050-UP
43	42C-01-13580	TUBE	1	SN: 50050-UP
44	42C-01-13590	TUBE	1	SN: 50050-UP
45	42C-01-13520	BRACKET	2	SN: 50050-UP
46	07283-37663	CLIP	2	SN: 50050-UP
47	01597-01009	NUT	4	SN: 50001-UP
48	01643-31032	WASHER	4	SN: 50001-UP
49	01435-01230	BOLT	4	SN: 50001-UP

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: B0000-01A1A



Reference: B0000-01A2

030050 ENGINE (AIR CLEANER MOUNTING PARTS) (WITH EXTENSION) (#50001-50044)

Item	Part No.	Part Name	Qty	Options
	427-Z04-1210	AIR CLEANER ASS'Y	4	SN: 50005-@
	6164-81-7511	☐ AIR CLEANER ASS'Y	4	SN: 50001-50004
1	427-Z04-1290	• BODY	1	SN: 50005-@
1	6164-81-7531	• BODY	1	SN: 50001-50004
2	6127-81-7412	• ELEMENT,INNER	1	SN: 50001-@
3	6128-81-7321	• ELEMENT,OUTER	1	SN: 50001-@
4	600-181-4370	• NUT	1	SN: 50001-@
5	600-181-7511	• WASHER,SEAL	1	SN: 50001-@
6	600-181-4420	• NUT,WING	1	SN: 50001-@
7	600-181-4430	• CLIP	1	SN: 50001-@
8	600-181-4440	• GASKET	1	SN: 50001-@
9	6127-11-4360	BAND ASS'Y	8	SN: 50001-@
10	6643-11-4641	BOLT	8	SN: 50001-@
11	42C-01-11620	PRECLEANER	4	SN: 50001-50044
12	01016-51045	• BOLT	4	SN: 50001-50044
13	01580-01008	• NUT	4	SN: 50001-50044
14	6128-11-5180	HOOD ASS'Y	4	SN: 50001-@
15	6128-81-7950	EXTENSION	4	SN: 50001-@
16	42C-01-11213	TUBE	2	SN: 50001-@
16	42C-01-11212	☒ TUBE	2	SN: (50001-50041)
17	42C-01-11225	TUBE	1	SN: 50001-@
17	42C-01-11224	☒ TUBE	1	SN: (50011-50041)
17	42C-01-11223	☒ TUBE	1	SN: (50001-50010)
18	42C-01-13280	BRACKET	3	SN: 50042-@
19	01010-81235	BOLT	6	SN: 50042-@
20	01643-31232	WASHER	6	SN: 50042-@
21	428-62-14640	CLIP	3	SN: 50042-@
22	01597-01211	NUT	6	SN: 50042-@
23	01643-31232	WASHER	6	SN: 50042-@
24	42C-01-11235	TUBE	1	SN: 50001-@
24	42C-01-11234	☒ TUBE	1	SN: (50011-50041)
24	42C-01-11233	☒ TUBE	1	SN: (50001-50010)
25	6127-81-4823	GASKET	4	SN: 50001-@
26	01580-01008	NUT	32	SN: 50001-@
27	01602-21030	WASHER	32	SN: 50001-@
28	42C-01-11270	HOSE	2	SN: 50001-@
29	07299-00160	CLAMP,HOSE	8	SN: 50040-@
29	07289-00160	☐ CLAMP,HOSE	8	SN: 50001-50039
30	42C-01-11263	HOSE	2	SN: 50013-@
30	42C-01-11262	HOSE	2	SN: 50011-50012
30	42C-01-11261	☐ HOSE	2	SN: 50001-50010
31	07299-00160	CLAMP,HOSE	6	SN: 50040-@
31	07289-00160	☐ CLAMP,HOSE	6	SN: 50011-50039
31	07289-00160	CLAMP,HOSE	4	SN: 50001-50010
32	42C-01-13190	COVER	1	SN: 50031-@

Item	Part No.	Part Name	Qty	Options
33	07289-00170	CLAMP,HOSE	3	SN: 50031-@
34	07289-00145	CLAMP,HOSE	2	SN: 50001-50010
35	42C-01-11780	INDICATOR	4	SN: 50001-@
36	08670-22001	INDICATOR	4	SN: 50001-@
37	281-03-12230	HOSE	4	SN: 50001-50044
38	07281-00609	CLAMP	8	SN: 50001-50044
39	42C-01-11311	TUBE,L.H.	1	SN: 50001-50044
40	42C-01-11321	TUBE,R.H.	1	SN: 50001-50044
41	42C-01-11351	BRACKET	2	SN: 50001-50044
42	07283-25150	CLIP	2	SN: 50001-50044
43	01597-01009	NUT	4	SN: 50001-@
44	01643-31032	WASHER	4	SN: 50001-@
45	01435-01230	BOLT	4	SN: 50001-@

Catalog signs: ☐ part above may be used instead ☒ discontinued: use part above

Reference: B0000-01A2

Get the complete PDF catalogue

Komatsu WA1200-3 S/N 50001-UP (Chassis only)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.