





PD48844

Reference: 1041

030010 EXHAUST MUFFLER AND PIPE (FOR LOW NOISE)(#60001-)

Item	Part No.	Part Name	Qty	Options
1	416-Z97-2150	BRACKET	1	SN: 60001-UP
2	01435-01225	BOLT	4	SN: 60001-UP
3	416-Z97-2110	MUFFLER, EXHAUST	1	SN: 60001-UP
4	6206-11-5960	U BOLT	2	SN: 60001-UP
5	01584-00806	NAT	4	SN: 60001-UP
6	416-Z97-2160	PIPE, EXHAUST	1	SN: 60001-UP
7	416-Z97-2130	PIPE	1	SN: 60001-UP
8	416-Z97-2120	BELLOWS	1	SN: 60001-UP
9	416-Z97-2180	CLAMP	1	SN: 60001-UP
10	416-Z97-1440	CLAMP	1	SN: 60001-UP
11	416-Z97-2140	CLAMP	2	SN: 60001-UP
12	01010-51285	BOLT	4	SN: 60001-UP
13	01580-11210	NAT	8	SN: 60001-UP
14	01640-21223	WASHER	8	SN: 60001-UP
15	416-Z97-2170	TUBE	1	SN: 60001-UP
16	07261-20917	HOSE	1	SN: 60001-UP
17	07281-00197	CLAMP	1	SN: 60001-UP
18	04434-51010	CLIP	1	SN: 60001-UP
19	01435-01016	BOLT	1	SN: 60001-UP

Reference: 1041




PD48847

Reference: 1534

030020 ELECTRICAL SYSTEM (REAR FRAME LINE) (FOR SUPER LOW NOISE) (#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-06-22130	WIRING HARNESS	1	SN: 60001-UP
1	08020-10000	• DIODE	2	SN: 60001-UP
2	416-Z97-2850	WIRING HARNESS	1	SN: 60001-UP
3	416-06-22160	WIRING HARNESS	1	SN: 60001-UP
4	08037-03614	GROMMET	2	SN: 60001-UP
5	08137-62400	LAMP, LICENSE	1	SN: 60001-UP
5	08110-12410	• ELECTRIC HORN, 12W	2	SN: 60001-UP
6	417-06-22230	WIRING HARNESS	1	SN: 60001-UP
7	417-06-22220	BRACKET	1	SN: 60001-UP
8	01435-01016	BOLT	2	SN: 60001-UP
9	08028-48040	CABLE, EARTH, EARTH	1	SN: 60001-UP
10	01435-01016	BOLT	2	SN: 60001-UP
11	08036-02514	CLIP	1	SN: 60001-UP
12	01435-01016	BOLT	1	SN: 60001-UP
13	08036-01214	CLIP	2	SN: 60001-UP
14	01435-01016	BOLT	1	SN: 60001-UP

Reference: 1534



PN48849


Reference: 5035

060010 REAR FRAME (FOR LOW NOISE)(#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-Z97-2510	FRAME, REAR	1	SN: 60001-UP
2	416-46-12160	BUSH	1	SN: 60001-UP
3	07000-06150	O RING	2	SN: 60001-UP
4	417-46-27110	SUPPORT, REAR	1	SN: 60001-UP
5	416-46-12160	BUSH	1	SN: 60001-UP
6	07000-06150	O RING	1	SN: 60001-UP
7	416-46-12152	PLATE	1	SN: 60001-UP
8	01010-61250	BOLT	8	SN: 60001-UP
9	01643-31232	WASHER	8	SN: 60001-UP
10	416-46-12142	COVER	1	SN: 60001-UP
11	416-46-12170	SHIM, 0.2MM	-2	SN: 60001-UP
12	01010-61255	BOLT	8	SN: 60001-UP
13	01643-31232	WASHER	8	SN: 60001-UP
14	01011-62030	BOLT	4	SN: .-UP
14	01011-32030	BOLT	4	SN: 60001-.
15	01643-32060	WASHER	8	SN: 60001-UP
16	01580-02016	NAT	4	SN: 60001-UP
17	417-46-24120	COVER	2	SN: 60001-UP
18	01435-01225	BOLT	4	SN: 60001-UP
19	417-46-24110	BAR, LOCK	1	SN: 60001-UP
20	416-46-12230	PIN	1	SN: 60001-UP
21	04050-18055	PIN, COTTER	1	SN: 60001-UP
22	416-46-12230	PIN	1	SN: 60001-UP
23	415-46-11360	PIN, SNAP	1	SN: 60007-UP
23	363-46-21360	□ PIN, SNAP	1	SN: 60001-60006
24	416-46-11210	BUMPER	2	SN: 60001-UP
25	01010-51225	BOLT	2	SN: 60001-UP
26	01643-31232	WASHER	2	SN: 60001-UP

Catalog signs: □ part above may be used instead

Reference: 5035




Reference: 5061

060020 UNDER GUARD (FOR LOW NOISE)(#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-Z97-2210	GUARD	1	SN: 60001-UP
2	01435-01040	BOLT	4	SN: 60001-UP
3	01435-01020	BOLT	3	SN: 60001-UP
4	415-64-13120	WASHER	7	SN: 60001-UP
5	01584-01008	NAT	4	SN: 60001-UP
6	416-Z97-2420	PLATE	1	SN: 60001-UP
7	416-Z97-2190	CUSHION	4	SN: 60001-UP
8	01435-01020	BOLT	4	SN: 60001-UP
9	416-Z97-2430	PLATE	1	SN: 60001-UP
10	01435-01020	BOLT	3	SN: 60001-UP
11	417-Z97-2220	SEAT	1	SN: 60001-UP
12	01435-00825	BOLT	11	SN: 60001-UP
13	113-43-23230	WASHER	11	SN: 60001-UP
14	416-Z97-2440	PLATE	1	SN: 60001-UP
15	01435-01020	BOLT	2	SN: 60001-UP

Reference: 5061




PD48765

Reference: 5164

060030 REAR FENDER AND LADDER (WITH CAB) (FOR SUPER LOW NOISE) (#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-54-24140	FENDER, LEFT	1	SN: 60001-UP
2	417-54-24150	FENDER, RIGHT	1	SN: 60001-UP
3	418-Z80-1220	SPRING	1	SN: 60001-UP
4	417-54-24470	CUSHION	2	SN: 60001-UP
5	415-54-12680	CUSHION	2	SN: 60001-UP
6	01435-01230	BOLT	5	SN: 60001-UP
7	01435-01220	BOLT	6	SN: 60001-UP
8	417-54-24110	LADDER, LEFT	1	SN: 60001-UP
9	417-54-24210	RADIATOR, RIGHT	1	SN: 60001-UP
10	01435-01235	BOLT	2	SN: 60001-UP
11	01435-01230	BOLT	4	SN: 60001-UP
12	01435-01220	BOLT	3	SN: 60001-UP
13	417-54-24290	STEP	2	SN: 60001-UP
14	01435-01020	BOLT	8	SN: 60001-UP
15	417-54-25160	TESURI, LEFT	1	SN: 60001-UP
16	417-54-25170	TESURI, RIGHT	1	SN: 60001-UP
17	417-54-25140	TESTER	2	SN: 60001-UP
18	01435-01225	BOLT	8	SN: 60001-UP
19	417-06-11321	PLATE	4	SN: 60001-UP
20	425-54-13930	SEAL	1	SN: 60001-UP
21	425-54-13910	SEAL	1	SN: 60001-UP

Reference: 5164




PM48766A

Reference: 5174

060040 FLOOR COVER (WITH CAB) (FOR SUPER LOW NOISE) (#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-54-24380	PLATE	1	SN: 60001-UP
2	417-54-24310	COVER, LEFT	1	SN: 60001-UP
3	417-54-24320	COVER, RIGHT	1	SN: 60001-UP
4	01435-01016	BOLT	8	SN: 60001-UP
5	417-54-24330	COVER, LEFT	1	SN: 60001-UP
6	01435-01025	BOLT	4	SN: 60001-UP
7	01643-31232	WASHER	4	SN: 60001-UP
8	417-54-24340	COVER, RIGHT	1	SN: 60001-UP
9	417-54-24350	COVER, RIGHT	1	SN: 60001-UP
10	01435-01016	BOLT	6	SN: 60001-UP
11	01643-31232	WASHER	3	SN: 60070-UP
11	01643-31232	WASHER	2	SN: 60001-60069
11A	01643-31232	WASHER	3	SN: 60019-UP
12	417-54-24460	PLATE	1	SN: 60001-UP
13	01435-01016	BOLT	2	SN: 60001-UP
14	416-Z97-2490	SEAL	1	SN: 60001-UP
15	416-Z97-2470	SEAL	3	SN: 60001-UP
16	22T-54-15630	SEAL	1	SN: 60001-UP
17	416-Z97-2480	SEAL	2	SN: 60001-UP
18	417-54-21850	SEAL	1	SN: 60001-UP
19	423-54-21320	SEAL	2	SN: 60001-UP
20	23S-54-27930	SEAL	1	SN: 60001-UP
21	421-03-23220	SEAL	2	SN: 60001-UP

Reference: 5174



Reference: 5205


060050 REAR DUCT (SUPER LOW NOISE SPEC)(#60001-)

Item	Part No.	Part Name	Qty	Options
1	416-Z97-2210	DUCT,REAR	1	SN: 60001-UP
1	421-54-11364	• LOCK ASSEMBLY (WELDING)	1	SN: 60001-UP
1A	416-43-16200	MAGNET	2	SN: .-UP
2	416-Z97-2330	SEAL	1	SN: 60001-UP
3	01435-01225	BOLT	4	SN: 60001-UP
4	416-Z97-2241	PLATE	1	SN: .-UP
4	416-Z97-2240	□ PLATE	1	SN: 60001-.
5	416-Z97-2250	ROD	1	SN: 60001-UP
6	01641-21016	WASHER	1	SN: 60001-UP
7	04050-12018	PIN, SNAP	1	SN: .-UP
7	04052-11038	PIN, SNAP	1	SN: 60001-.
8	01641-20608	WASHER	4	SN: 60001-UP
9	04052-10633	PIN, SNAP	4	SN: 60001-UP
10	417-54-21610	SPRING	1	SN: 60001-UP
11	416-Z97-2261	PLATE	1	SN: .-UP
11	416-Z97-2260	□ PLATE	1	SN: 60001-.
12	01435-01020	BOLT	2	SN: 60001-UP
13	416-S06-2250	BRACKET	2	SN: .-UP
13	566-54-23460	DOVE TAIL	2	SN: 60001-.
14	424-54-11561	BLOCK	2	SN: .-UP
14	566-54-23470	DOVE TAIL	2	SN: 60001-.
15	424-54-14991	PLATE	2	SN: .-UP
15	416-Z97-2280	□ PLATE	2	SN: 60001-.
15A	416-S06-2260	PLATE	2	SN: .-UP
16	01435-00616	BOLT	8	SN: .-UP
16	01435-00616	BOLT	12	SN: 60001-.
16A	01435-01230	BOLT	4	SN: .-UP
16B	01643-30623	WASHER	2	SN: .-UP
17	416-Z97-2770	PLATE	1	SN: 60001-UP
18	01435-01025	BOLT	2	SN: 60001-UP
19	416-Z97-2760	ROD	1	SN: 60001-UP
20	01641-21016	WASHER	2	SN: 60001-UP
21	04052-10833	PIN, SNAP	2	SN: 60001-UP
22	417-Z97-2280	PLATE	1	SN: 60001-.
23	01435-01016	BOLT	3	SN: 60001-UP
24	417-Z97-2230	COVER	1	SN: 60001-UP
25	416-Z97-2310	SEAL	1	SN: 60001-UP
26	417-54-21490	SEAL	1	SN: 60001-UP
27	417-54-24470	CUSHION	2	SN: 60001-UP
28	416-Z97-2230	BRACKET	1	SN: 60001-UP
29	416-54-11171	HOSE	2	SN: 60001-UP
30	01435-00816	BOLT	2	SN: 60001-UP
31	421-09-12321	HOLDA	2	SN: 60001-UP
32	01220-40410	SCREW	10	SN: 60001-UP
33	01641-20405	WASHER	10	SN: 60001-UP
34	01580-10403	NAT	10	SN: 60001-UP
35	01601-20410	WASHER, SPRING	10	SN: 60001-UP

Item	Part No.	Part Name	Qty	Options
36	417-Z97-2240	COVER	1	SN: 60001-UP
37	01435-01016	BOLT	2	SN: 60001-UP

Catalog signs: ☐ part above may be used instead

Reference: 5205




PD48853

Reference: 5215

060060 ENGINE HOOD (FOR LOW NOISE)(#60001-)

Item	Part No.	Part Name	Qty	Options
1	417-Z97-2410	HOOD	1	SN: 60001-UP
2	01435-01235	BOLT	6	SN: 60001-UP
3	417-54-21370	SEAL	1	SN: 60001-UP
4	417-54-21380	SEAL	2	SN: 60001-UP
5	417-54-21350	FINISHER	2	SN: 60001-UP
6	417-54-21840	PLATE	2	SN: 60001-UP
7	417-54-21850	SEAL	2	SN: 60001-UP
8	01435-00816	BOLT	6	SN: 60001-UP
9	417-54-21440	PLATE	1	SN: 60001-UP
10	417-54-21430	PLATE	1	SN: 60001-UP
11	01435-00820	BOLT	4	SN: 60001-UP
12	417-54-21170	PLATE	1	SN: 60001-UP
13	01435-01016	BOLT	3	SN: 60001-UP
14	417-54-21460	SPRING	2	SN: 60001-UP
15	01435-00814	BOLT	2	SN: 60001-UP
16	417-54-17132	SPRING	1	SN: 60001-UP
17	01220-40410	SCREW	2	SN: 60001-UP
18	01642-20405	WASHER	2	SN: 60001-UP
19	01580-10403	NAT	2	SN: 60001-UP
20	08052-01911	CLIP	1	SN: .-UP
20	283-06-17130	CLIP	1	SN: 60001-.
21	01220-40608	SCREW	1	SN: 60001-UP
22	417-54-21790	PLATE	1	SN: 60001-UP
23	01435-00820	BOLT	2	SN: 60001-UP
24	416-54-21280	PLUG	4	SN: 60001-UP

Reference: 5215



Reference: 5921

060070 LOW NOISE PARTS (1/2) (FOR FLOOR FRAME AND ENGINE HOOD) (SUPER LOW NOISE)

Item	Part No.	Part Name	Qty	Options
1	416-Z97-2710	SEAT	2	SN: 60001-UP
2	416-Z97-2680	SEAT, LEFT	1	SN: 60001-UP
3	416-Z97-2690	SEAT, RIGHT	1	SN: 60001-UP
4	416-S06-2510	SEAT, LEFT	1	SN: 60001-UP
5	416-54-21240	SEAT, RIGHT	1	SN: 60001-UP
6	416-54-21360	SEAT, RIGHT	1	SN: 60001-UP
7	416-S06-2520	SEAT, RIGHT	1	SN: 60001-UP
8	416-S06-2560	SEAT	2	SN: 60001-UP
9	416-S06-2630	SEAT	1	SN: 60001-UP
10	416-Z97-2710	SEAT	1	SN: 60001-UP
11	416-S06-2540	SEAT	1	SN: 60001-UP
12	416-S06-2550	SEAT	2	SN: 60001-UP
13	416-54-21350	SEAT	2	SN: 60001-UP
14	417-54-21910	SEAT	1	SN: 60001-UP
15	417-54-21980	SEAT, LEFT	1	SN: 60001-UP
16	417-54-21970	SEAT, RIGHT	1	SN: 60001-UP
17	416-S06-2460	SEAT	1	SN: 60001-UP
18	416-S06-2410	SEAT	1	SN: 60001-UP
19	416-Z97-2480	SEAL, LEFT	1	SN: 60001-UP
20	416-Z97-2490	SEAL, RIGHT	1	SN: 60001-UP
21	417-Z97-2470	SEAT	1	SN: 60001-UP
22	417-Z97-2460	SEAT	1	SN: 60001-UP
23	417-Z97-2450	SEAT	1	SN: 60001-UP
24	417-Z97-2440	SEAT	1	SN: 60001-UP
25	417-Z97-2380	SEAT	1	SN: 60001-
26	416-54-21340	SEAT	2	SN: 60001-UP
27	416-54-21220	SEAT	2	SN: 60001-UP
28	417-Z97-2420	SEAT, LEFT	1	SN: 60001-UP
29	417-Z97-2430	SEAT, RIGHT	1	SN: 60001-UP
30	416-54-21330	SEAT, LEFT	1	SN: 60001-UP
31	417-54-21890	SEAT, RIGHT	1	SN: 60001-UP
32	417-Z97-2270	SEAT	1	SN: 60001-UP
33	417-54-21770	SEAT, LEFT	1	SN: 60001-UP

Get the complete PDF catalogue

Komatsu WA150SS-3 (JPN) WA150SS-3-X3AVANCE SUPER LOW NOISE SPEC S/N
60001-62999 (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.