





Reference: A1010-001001

A-002 A1010-001001 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6411-11-1010	CYLINDER HEAD ASSEMBLY	1	
	6411-11-1100	• HEAD ASSEMBLY	1	
1	NSS	•• HEAD	1	
2	6411-11-1340	•• SEAT, INTAKE VALVE, STANDARD	12	
	6411-19-1340	•• SEAT, INTAKE VALVE, OVERSIZE 0.25 MM	12	
	6411-18-1340	•• SEAT, INTAKE VALVE, OVERSIZE 0.50 MM	12	
	6411-17-1340	•• SEAT, INTAKE VALVE, OVERSIZE 0.75 MM	12	
	6411-16-1340	•• SEAT, INTAKE VALVE, OVERSIZE 1.00 MM	12	
3	6411-11-1350	•• SEAT, EXHAUST VALVE, STANDARD	12	
	6411-19-1350	•• SEAT, EXHAUST VALVE, OVERSIZE 0.25 MM	12	
	6411-18-1350	•• SEAT, EXHAUST VALVE, OVERSIZE 0.50 MM	12	
	6411-17-1350	•• SEAT, EXHAUST VALVE, OVERSIZE 0.75 MM	12	
	6411-16-1350	•• SEAT, EXHAUST VALVE, OVERSIZE 1.00 MM	12	
4	6411-19-1360	•• GUIDE	24	
5	07046-41810	•• PLUG, EXPANSION	12	
6	07046-42216	•• PLUG	34	
7	07046-42010	•• PLUG	30	
8	07046-42816	•• PLUG	1	
9	07046-43516	•• PLUG	5	
10	07046-43016	•• PLUG	2	
11	07046-21410	•• PLUG	1	
12	6411-11-1310	•• SLEEVE	6	
13	6411-11-1320	•• O-RING	12	
14	04020-00514	•• PIN, DOWEL	14	
15	NSS	•• CAP	1	
16	NSS	•• CAP	5	
17	NSS	•• CAP	1	
18	01437-00855	•• BOLT	28	
19	07043-70312	•• PLUG, TAPER	1	
20	6411-41-4110	• VALVE, INTAKE	12	
21	6411-41-4210	• VALVE, EXHAUST	12	
22	6411-41-4430	• SEAT	24	
23	6411-41-4510	• SEAL	24	
24	6411-41-4410	• SPRING	24	
25	6411-41-4420	• RETAINER	24	
26	6136-42-4520	• COTTER	48	
27	6411-11-1810	GASKET	1	
28	6411-11-1650	WASHER	38	
29	6411-11-1620	BOLT	38	
30	01643-31032	WASHER	2	
31	01011-81040	BOLT	2	
32	6215-81-9720	O-RING	3	
33	6215-81-9520	PLUG	3	
34	01010-81095	BOLT	1	
35	01643-31032	WASHER	1	
36	6411-41-5160	CROSSHEAD	12	




JY114268

Reference: A1010-001002

A-006 A1010-001002 CYLINDER HEAD RELATED PARTS

Item	Part No.	Part Name	Qty	Options
1	6411-11-4220	GASKET	1	
2	6411-11-4210	BLOCK	1	
3	01010-81045	BOLT	4	
4	01643-31032	WASHER	4	
5	07043-70108	PLUG, TAPER	3	
6	6219-81-1971	SENSOR, PRESSURE	1	
	6219-81-1991	• O-RING	1	
7	6755-81-1900	SENSOR, PRESSURE	1	
8	01640-20508	WASHER	1	
9	01252-60520	BOLT, HEXAGON SOCKET HEAD	1	
10	6411-11-1720	GASKET	1	
11	6411-11-1710	PLATE	1	
12	01010-81030	BOLT	6	
13	01643-31032	WASHER	6	
14	6411-11-4320	GASKET	1	
15	6411-11-4360	CONNECTOR	1	
16	01643-31032	WASHER	6	
17	01011-81095	BOLT	6	
	6560-61-7300	SENSOR, TEMPERATURE	1	
18	NSS	• SENSOR, TEMPERATURE	1	
19	6735-21-1930	• O-RING	1	

Reference: A1010-001002




JY114269

Reference: A1030-001001

A-008 A1030-001001 FRONT HANGER

Item	Part No.	Part Name	Qty	Options
1	6411-21-6210	PLATE	1	
2	01643-31645	WASHER	4	
3	01010-81645	BOLT	4	

Reference: A1030-001001




Reference: A1050-001001

A-010 A1050-001001 REAR HANGER

Item	Part No.	Part Name	Qty	Options
1	6411-21-6230	PLATE	1	
2	01643-31645	WASHER	2	
3	01010-81650	BOLT	2	

Reference: A1050-001001




Reference: A1110-001001

A-012 A1110-001001 CYLINDER HEAD COVER

Item	Part No.	Part Name	Qty	Options
1	6411-11-7110	HOUSING	1	
2	6411-11-7120	O-RING	1	
3	01010-81030	BOLT	20	
4	01643-31032	WASHER	20	
5	6411-11-7130	SEAL	6	
	6411-11-8100	COVER ASSEMBLY	3	
6	NSS	• COVER	1	
7	6411-11-8210	• GASKET	1	
8	01010-D1045	BOLT	18	
9	01643-71032	WASHER	18	
10	6411-81-9710	WIRING HARNESS	1	
11	6411-81-9730	• PROTECTOR	2	
12	6411-81-9740	• PROTECTOR	1	

Reference: A1110-001001




JY114973

Reference: A1310-001001

A-014 A1310-001001 AIR INTAKE CONNECTOR

Item	Part No.	Part Name	Qty	Options
1	600-815-3812	HEATER	1	
2	6251-11-4830	GASKET	2	
3	6411-11-4330	CONNECTOR	1	
4	01010-81070	BOLT	6	
5	01643-31032	WASHER	6	
6	07042-A0108	PLUG	2	
7	6411-11-4810	PLATE	1	
8	01010-81025	BOLT	1	
9	01643-31032	WASHER	1	
10	6411-11-4420	BRACKET	1	
11	01010-81035	BOLT	2	
12	01643-31032	WASHER	2	
13	6411-11-4410	CONNECTOR	1	
14	01010-81035	BOLT	2	
15	01643-31032	WASHER	2	
16	6152-12-4410	HOSE	1	
17	07299-00080	CLAMP, HOSE	4	
18	07042-A0108	PLUG	1	

Reference: A1310-001001




Reference: A1510-001001

A-016 A1510-001001 EXHAUST MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6411-11-5220	MANIFOLD, CENTER	1	
2	6411-11-5240	MANIFOLD, FRONT, REAR	2	
3	6151-11-5340	RING, SEAL	4	
4	6411-11-5170	GASKET	6	
5	6136-11-5120	SPACER	22	
6	01011-E1000	BOLT	22	
7	6210-11-5820	SPACER	2	
8	01010-E1055	BOLT	2	
9	6151-11-8550	STUD	2	
10	6215-11-5920	PLUG	2	

Reference: A1510-001001




Reference: A1530-001001

A-018 A1530-001001 TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
	6508-21-5010	TURBOCHARGER	1	
	6508-21-5910	• CORE ASSEMBLY	1	
1	NSS	• ROTOR	1	
2	NSS	• COLLAR	1	
3	NSS	• FLINGER	1	
4	NSS	• IMPELLER	1	
5	NSS	• NUT, LOCK	1	
6	NSS	• BEARING	2	
7	NSS	• BEARING	1	
8	NSS	• RING	4	
9	NSS	• SEAL RING	2	
10	NSS	• SEAL RING	2	
11	NSS	• SHIELD	1	
12	NSS	• HOUSING	1	
13	NSS	• PIN, DOWEL	1	
14	NSS	• O-RING	1	
15	NSS	• INSERT	1	
16	NSS	• RING, SNAP	1	
17	NSS	• O-RING	2	
18	NSS	• PLUG	2	
19	6509-11-7910	• SENSOR KIT, SPEED	1	
20	NSS	• RING	1	
21	6508-21-4410	• HOUSING	1	
22	6508-21-0520	• PLATE	2	
23	01020-11016	• BOLT	8	
24	NSS	• HOUSING	1	
25	NSS	• PLATE	1	
26	NSS	• RING, SNAP	1	
27	NSS	• CLAMP	1	
28	NSS	• PLATE, NAME	1	
29	NSS	• SCREW	2	

Reference: A1530-001001



Reference: A1530-001002

A-020 A1530-001002 TURBOCHARGER MOUNTING

Item	Part No.	Part Name	Qty	Options
1	6411-11-5830	GASKET	1	
2	6138-13-4510	BOLT	1	
3	6151-11-8550	STUD	1	
4	6114-11-5590	NUT	4	
5	6252-61-6280	O-RING	2	
6	6252-61-6340	NIPPLE	2	
7	6240-81-4431	CLIP	1	
8	01010-81020	BOLT	1	
9	01643-31032	WASHER	1	

Reference: A1530-001002

Get the complete PDF catalogue

Komatsu WA485-11 S/N A60001

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.